

**COMPLEX
SOLUTIONS
MADE
SIMPLE.**



DSEULTRA®

DSE4400 Quick Start Guide

Document Number 057-103

Q VÁ æ ~ æÁJJÉ HH



Deep Sea Electronics Plc
Highfield House
Hunmanby
North Yorkshire
YO14 0PH
ENGLAND

Sales Tel: +44 (0) 1723 890099
Sales Fax: +44 (0) 1723 893303

E-mail: sales@deepseapl.com
Website: www.deepseapl.com

DSE Model 4400 series Control and Instrumentation System Operators Manual

© Deep Sea Electronics Plc

All rights reserved. No part of this publication may be reproduced in any material form (including photocopying or storing in any medium by electronic means or other) without the written permission of the copyright holder except in accordance with the provisions of the Copyright, Designs and Patents Act 1988.

Applications for the copyright holder's written permission to reproduce any part of this publication should be addressed to Deep Sea Electronics Plc at the address above.

The DSE logo and the names DSEUltra, DSEControl, DSEPower, DSEExtra, DSEMarine and DSENet are UK registered trademarks of Deep Sea Electronics PLC.

Any reference to trademarked product names used within this publication is owned by their respective companies.

Deep Sea Electronics Plc reserves the right to change the contents of this document without prior notice.

Amendments since last publication

Amd. No.	Comments

Clarification of notation used within this publication.

 NOTE:	Highlights an essential element of a procedure to ensure correctness.
 CAUTION!	Indicates a procedure or practice, which, if not strictly observed, could result in damage or destruction of equipment.
 WARNING!	Indicates a procedure or practice, which could result in injury to personnel or loss of life if not followed correctly.

TABLE OF CONTENTS

Section	Page
1 BIBLIOGRAPHY.....	4
2 INTRODUCTION.....	4
3 DESCRIPTION OF CONTROLS.....	5
3.1 QUICKSTART GUIDE.....	7
3.1.1 STARTING THE ENGINE.....	7
3.1.2 STOPPING THE ENGINE.....	7
3.2 VIEWING THE INSTRUMENTS.....	8
3.3 EVENT LOG.....	9
4 OPERATION.....	10
4.1 AUTOMATIC MODE OF OPERATION.....	10
4.1.1 WAITING IN AUTO MODE.....	10
4.1.2 STARTING SEQUENCE.....	10
4.1.3 ENGINE RUNNING.....	11
4.1.4 STOPPING SEQUENCE.....	11
4.2 MANUAL OPERATION.....	12
4.2.1 WAITING IN MANUAL MODE.....	12
4.2.2 STARTING SEQUENCE.....	12
4.2.3 ENGINE RUNNING.....	13
4.2.4 STOPPING SEQUENCE.....	13
5 MODULE DISPLAY.....	14
5.1 BACKLIGHT.....	14
5.2 GRAPHICAL DISPLAY.....	14
5.2.1 DISPLAY EXAMPLE.....	14
5.2.2 MODE ICON.....	14
5.2.3 INSTRUMENTATION ICONS.....	15
5.2.4 ALARM ICONS.....	15

1 BIBLIOGRAPHY

This document refers to and is referred to by the following DSE publications which can be obtained from the DSE website www.deepseapl.com

DSE PART	DESCRIPTION
053-056	4410 installation instructions
053-057	4420 installation instructions
053-058	4430 installation instructions
057-004	Electronic Engines and DSE wiring manual
057-093	4400 Series Configuration Suite manual

2 INTRODUCTION

This document details the installation and operation requirements of the DSE4400 Series modules, part of the DSEUltra® range of products.

The manual forms part of the product and should be kept for the entire life of the product. If the product is passed or supplied to another party, ensure that this document is passed to them for reference purposes.

This is not a *controlled document*. You will not be automatically informed of updates. Any future updates of this document will be included on the DSE website at www.deepseapl.com

The **DSE 4400 series** module has been designed to allow the operator to start and stop the engine/generator, and if required, transfer the load.

The user also has the facility to view the system operating parameters via the LCD display.

The **DSE 4400** module monitors the engine, indicating the operational status and fault conditions, automatically shutting down the engine and giving a true first up fault condition of an engine failure. The LCD display indicates the fault.

The powerful microprocessor contained within the module allows for incorporation of a range of enhanced features:

- *Text based LCD display*
- **True RMS Voltage monitoring.**
- *Engine parameter monitoring.*
- *Fully configurable inputs for use as alarms or a range of different functions.*
- *Engine ECU interface to **electronic engines** (specify on ordering)*
- *Magnetic pickup interface for engine only applications (specify on ordering)*


Using a PC and the 4400 series configuration software allows alteration of selected operational sequences, timers and alarm trips.


Additionally, the module's integral fascia configuration editor allows full adjustment of all this information.

A robust plastic case designed for front panel mounting houses the module. Connections are via locking plug and sockets.

3 DESCRIPTION OF CONTROLS

The following section details the function and meaning of the various controls on the module.





3.1 QUICKSTART GUIDE

This section provides a quick start guide to the module's operation.

3.1.1 STARTING THE ENGINE



NOTE:- For further details, see the section entitled 'OPERATION' elsewhere in this manual.

3.1.2 STOPPING THE ENGINE



NOTE:- For further details, see the section entitled 'OPERATION' elsewhere in this manual.

3.2 VIEWING THE INSTRUMENTS

It is possible to scroll to display the different pages of information by repeatedly operating the down button 

Pressin the information  button toggles between instrumentation and event log displays

Once selected the page will remain on the LCD display until the user selects a different page or after an extended period of inactivity, the module will revert to the status display.

When scrolling manually by pressing the  button, the display will automatically return to the Status page if no buttons are pressed for the duration of the configurable *LCD Page Timer*.

If an alarm becomes active while viewing the status page, the display shows the Alarms page to draw the operator's attention to the alarm condition.

Metering:

- Generator Voltage, 3-phase, L-L and L-N
- Generator Amps L1, L2 and L3 (On/Off selectable in software)
- Generator Frequency
- Mains Voltage, 3-phase, L-L and L-N
- Battery Voltage
- Engine hours Run
- Oil Pressure Gauge
- Engine Temperature Gauge
- Fuel Level
- Fail to Start

Indicators:

- Fail to Stop
- Low Oil pressure
- High Engine Temperature
- Under/Over-speed
- Under/Over voltage – Warning, Shutdown or Electrical Trip
- Emergency Stop
- Failed to reach loading voltage
- Failed to reach loading frequency
- Charge Fail
- Over Current – Warning, Shutdown or Electrical Trip
- Low DC Voltage
- + AMF indications
- + CAN diagnostics


At power up, the display will display the software version and then display the default display screen, which will display Generator Frequency.

3.3 EVENT LOG

The info **i** button toggles between the display of the instrumentation and the event log. Pressing the down **▼** button will move to the previous event, the event log entry at position 1 being the most recent. On moving from the instrumentation value to the event log the unit will display the most recent entry.

A number in the bottom left indicates the event log entry currently being displayed. There are five event log entries in the 44xx units. When the event log is being displayed the icon in the alarm icon area indicates the alarm type at that position of the event log. The hours run at the time of the alarm will be displayed in the instrumentation area. The bottom right icon indicates the current mode as normal.

Example of Auxiliary Input Shutdown Alarm.



4 OPERATION

4.1 AUTOMATIC MODE OF OPERATION

NOTE:- If a digital input configured to *panel lock* is active, changing module modes will not be possible. Viewing the instruments and event logs is NOT affected by panel lock.

Activate auto mode by pressing the  pushbutton. The  icon is displayed to indicate Auto Mode operation if no alarms are present.

Auto mode will allow the generator to operate fully automatically, starting and stopping as required with no user intervention.

4.1.1 WAITING IN AUTO MODE

If a starting request is made, the starting sequence will begin. Starting requests can be from the following sources :

- Mains failure (DSE4420 only)
- Activation of an auxiliary input that has been configured to *remote start*
- Activation of the inbuilt exercise scheduler.

4.1.2 STARTING SEQUENCE

To allow for 'false' start requests, the *start delay* timer begins.

Should all start requests be removed during the *start delay* timer, the unit will return to a stand-by state.

If a start request is still present at the end of the *start delay* timer, the fuel relay is energised and the engine will be cranked.

NOTE:- If the unit has been configured for CAN, compatible ECU's will receive the start command via CAN.

If the engine fails to fire during this cranking attempt then the starter motor is disengaged for the *crank rest* duration after which the next start attempt is made. Should this sequence continue beyond the set number of attempts, the start sequence will be terminated and the display shows  **Fail to Start**.

When the engine fires, the starter motor is disengaged. Speed detection is factory configured to be derived from the main alternator output frequency but can additionally be measured from a Magnetic Pickup mounted on the flywheel (Selected by PC using the 3000 series configuration software).

Additionally, rising oil pressure can be used to disconnect the starter motor (but cannot detect underspeed or overspeed).

NOTE:- If the unit has been configured for CAN, speed sensing is via CAN.

After the starter motor has disengaged, the *Safety On* timer activates, allowing Oil Pressure, High Engine Temperature, Under-speed, Charge Fail and any delayed Auxiliary fault inputs to stabilise without triggering the fault.

4.1.3 ENGINE RUNNING

Once the engine is running and all starting timers have expired, the animated  icon is displayed.

DSE4410 - The generator will be placed on load if configured to do so.

 **NOTE:-The load transfer signal remains inactive until the Oil Pressure has risen. This prevents excessive wear on the engine.**

If all start requests are removed, the *stopping sequence* will begin.

4.1.4 STOPPING SEQUENCE

The *return delay* timer operates to ensure that the starting request has been permanently removed and isn't just a short term removal. Should another start request be made during the cooling down period, the set will return on load.

If there are no starting requests at the end of the *return delay* timer, the load is removed from the generator to the mains supply and the *cooling* timer is initiated.

The *cooling* timer allows the set to run off load and cool sufficiently before being stopped. This is particularly important where turbo chargers are fitted to the engine.

After the *cooling* timer has expired, the set is stopped.

4.2 MANUAL OPERATION

Manual mode allows the operator to start and stop the set manually, and if required change the state of the load switching devices. Module mode is active when the  button is pressed.

4.2.1 WAITING IN MANUAL MODE

To begin the starting sequence, press the  button. If 'protected start' is disabled, the start sequence begins immediately.

If 'Protected Start' is enabled, the  icon is displayed to indicate Manual mode and the manual LED flashes. The  button must be pressed once more to begin the start sequence.

4.2.2 STARTING SEQUENCE

 **NOTE:- There is no *start delay* in this mode of operation.**

The fuel relay is energised and the engine is cranked.

 **NOTE:- If the unit has been configured for CAN, compatible ECU's will receive the start command via CAN.**

If the engine fails to fire during this cranking attempt then the starter motor is disengaged for the *crank rest* duration after which the next start attempt is made. Should this sequence continue beyond the set number of attempts, the start sequence will be terminated and the display shows  **Fail to Start.**

When the engine fires, the starter motor is disengaged. Speed detection is factory configured to be derived from the main alternator output frequency but can additionally be measured from a Magnetic Pickup mounted on the flywheel (Selected by PC using the 3000 series configuration software).

Additionally, rising oil pressure can be used disconnect the starter motor (but cannot detect underspeed or overspeed).

 **NOTE:- If the unit has been configured for CAN, speed sensing is via CAN.**

After the starter motor has disengaged, the *Safety On* timer activates, allowing Oil Pressure, High Engine Temperature, Under-speed, Charge Fail and any delayed Auxiliary fault inputs to stabilise without triggering the fault.

4.2.3 ENGINE RUNNING

In manual mode, the load is not transferred to the generator unless a 'loading request' is made. A loading request can come from a number of sources.

- Detection of mains failure (DSE4420 only)
- Activation of an auxiliary input that has been configured to *remote start on load*

 **NOTE:-The load transfer signal remains inactive until the Oil Pressure has risen. This prevents excessive wear on the engine.**

Once the load has been transferred to the generator, it will not be automatically removed. To manually transfer the load back to the mains (DSE4420) or to remove the load from the generator (DSE4410) either:

- Press the *auto mode*  button to return to automatic mode. The set will observe all auto mode start requests and stopping timers before beginning the *Auto mode stopping sequence*.
-
- Press the *stop button* 

4.2.4 STOPPING SEQUENCE

In manual mode the set will continue to run until either :

- The *stop button*  is pressed – The set will immediately stop
- The *auto button*  is pressed. The set will observe all auto mode start requests and stopping timers before beginning the *Auto mode stopping sequence*.

5 MODULE DISPLAY

5.1 BACKLIGHT

The backlight will be on if the unit has sufficient voltage on the power connection while the unit is turned on, unless the unit is cranking for which the backlight will be turned off.


5.2 GRAPHICAL DISPLAY

A 48x132 pixel LCD is used for the display. The display is segmented into areas for instrumentation, units, alarm icons and various other icons.

Inst. Icon	Instrumentation	Units	Alarm Icon
Active config /FPE, event index	Instrumentation	Units	Mode Icon
	Instrumentation	Units	

5.2.1 DISPLAY EXAMPLE

This example shows Generator Volts as shown by the Generator  symbol.



5.2.2 MODE ICON

An icon is displayed in the mode icon area of the display to indicate what mode the unit is currently in.

Icon	Graphic	Details
Stopped		Appears when the engine is at rest and the unit is in stop mode.
Auto		Appears when the engine is at rest and the unit is in auto mode.
Manual		Appears when the engine is at rest and the unit is in manual mode.
Timer animation		Appears when a timer is active, for example cranking time, crank rest etc.
Running animation		Appears when the engine is running, and all timers have expired, either on or off load. The animation will be rate is reduced when running in idle mode.
Front panel editor		Appears when the unit is in the front panel editor

5.2.3 INSTRUMENTATION ICONS

When displaying instrumentation a small icon is displayed in the instrumentation icon area to indicate what value is currently being displayed. This is necessary to distinguish between mains and generator voltages, icons for oil pressure and coolant temperature are added for consistency.

Icon	Graphic	Details
Generator		Used for generator voltage and generator frequency
Mains		Used for mains voltages and mains frequency
Engine speed		Engine speed instrumentation screen
Hours Run		Hours run instrumentation screen
Battery voltage		Battery voltage instrumentation screen
Engine temperature		Coolant temperature instrumentation screen
Oil pressure		Oil pressure instrumentation screen
Flexible sensor		Flexible sensor instrumentation screen
Event log		Appears when the event log is being displayed

5.2.4 ALARM ICONS

When current instrumentation is being displayed the icons area will be used to display currently active conditions. In instances where more than one alarm is present the icon area will transition between icons to display all active alarm conditions. For information alarm conditions see section **Error! Reference source not found.**

When the event log is being displayed the alarm icon area will be used to indicate which alarm was logged.

Alarm	Icon
External input alarm	
Failed to start	
Failed to stop	
Low oil pressure	
Water temperature	
Under speed	
Over speed	
Charge alternator	
Low fuel	
Plant battery volts (under/over)	
Under voltage	
Over frequency	

CAN data fail 44x0-xxx-02 CAN module only	
ECU warning/fail 44x0-xxx-02 CAN module only	
Emergency stop	
Loss of MPU 44x0-xxx-01 MPU module only	
Flexible sender alarms	
MPU Open circuit 44x0-xxx-01 MPU module only	
Generator contactor alarm	
Mains Failure DSE4420 only	
Mains Return DSE4420 only	
Over voltage	
Under frequency	

CONFIGURATION PARAMETERS – MODULE (PAGE 1)			
101	Contrast	000 (%)	Protected start enable RESERVED
102	Fast loading enabled	On (1), off (0)	Event log display format
103	RESERVED	On (1), off (0)	Start in auto
104	Lamp test at startup	On (1), off (0)	Diagnostic Trouble Code string (english only)
105	Power save mode enable	On (1), off (0)	CAN

CONFIGURATION PARAMETERS – APPLICATION (PAGE 2) (CAN VERSION MODULE ONLY)			
201	Alternate engine speed	On (1), off (0)	Can ECU data fail action
202	Can ECU data fail enable	On (1), off (0)	Can ECU data fail delay

CONFIGURATION PARAMETERS – INPUTS (PAGE 3)			
301	Low oil pressure enable	On (1), off (0)	0.00 bar
302	High engine temperature trip	0 (input source)	0 (polarity)
303	Digital input A polarity	0 (action)	0 (arming)
304	Digital input A action (if source = user config)	0 (input source)	0 (polarity)
305	Digital input B polarity	0 (action)	0 (arming)
306	Digital input B action (if source = user config)	0 (input source)	0 (polarity)
307	Digital input C polarity	0 (action)	0 (arming)
308	Digital input C action (if source = user config)	0 (input source)	0 (polarity)
309	Digital input D polarity	0 (action)	0 (arming)
310	Digital input D action (if source = user config)	0 (input source)	0 (polarity)
311	Digital input E polarity	0 (action)	0 (arming)
312	Digital input E action (if source = user config)	0 (input source)	0 (polarity)
313	Digital input F polarity	0 (action)	0 (arming)
314	Digital input F action (if source = user config)	0 (input source)	0 (polarity)
315	Digital input G polarity	0 (action)	0 (arming)
316	Digital input G action (if source = user config)	0 (input source)	0 (polarity)
317	Digital input H polarity	0 (action)	0 (arming)
318	Digital input H action (if source = user config)	0 (input source)	0 (polarity)
319	Digital input I polarity	0 (action)	0 (arming)
320	Digital input I action (if source = user config)	0 (input source)	0 (polarity)
321	Digital input J polarity	0 (action)	0 (arming)
322	Digital input J action (if source = user config)	0 (input source)	0 (polarity)
323	Digital input K polarity	0 (action)	0 (arming)
324	Digital input K action (if source = user config)	0 (input source)	0 (polarity)
325	Analogue input A (set as digital) polarity	0 (action)	0 (arming)
326	Analogue input A (set as digital) action (if source = user config)	0 (input source)	0 (polarity)
327	Analogue input B (set as digital) polarity	0 (action)	0 (arming)
328	Analogue input B (set as digital) action (if source = user config)	0 (input source)	0 (polarity)
329	Analogue input C (set as digital) polarity	0 (action)	0 (arming)
330	Analogue input C (set as digital) action (if source = user config)	0 (input source)	0 (polarity)
331	Analogue input D (set as digital) polarity	0 (action)	0 (arming)
332	Analogue input D (set as digital) action (if source = user config)	0 (input source)	0 (polarity)
333	Analogue input E (set as digital) polarity	0 (action)	0 (arming)
334	Analogue input E (set as digital) action (if source = user config)	0 (input source)	0 (polarity)
335	Analogue input F (set as digital) polarity	0 (action)	0 (arming)
336	Analogue input F (set as digital) action (if source = user config)	0 (input source)	0 (polarity)
337	Analogue input G (set as digital) polarity	0 (action)	0 (arming)
338	Analogue input G (set as digital) action (if source = user config)	0 (input source)	0 (polarity)
339	Analogue input H (set as digital) polarity	0 (action)	0 (arming)
340	Analogue input H (set as digital) action (if source = user config)	0 (input source)	0 (polarity)
341	Analogue input I (set as digital) polarity	0 (action)	0 (arming)
342	Analogue input I (set as digital) action (if source = user config)	0 (input source)	0 (polarity)
343	Analogue input J (set as digital) polarity	0 (action)	0 (arming)
344	Analogue input J (set as digital) action (if source = user config)	0 (input source)	0 (polarity)
345	Oil pressure sender open circuit alarm	On (1), off (0)	0 (arming)
346	Temperature sender open circuit alarm	On (1), off (0)	0 (arming)

CONFIGURATION PARAMETERS – OUTPUTS (PAGE 4)			
401	Digital output A source	0 (output source)	0 (output source)
402	Digital output A polarity	0 (output source)	0 (output source)
403	Digital output B source	0 (output source)	0 (output source)
404	Digital output B polarity	0 (output source)	0 (output source)
405	Digital output C source	0 (output source)	0 (output source)
406	Digital output C polarity	0 (output source)	0 (output source)
407	Digital output D source	0 (output source)	0 (output source)
408	Digital output D polarity	0 (output source)	0 (output source)
409	Digital output E source	0 (output source)	0 (output source)
410	Digital output E polarity	0 (output source)	0 (output source)
411	Digital output F source	0 (output source)	0 (output source)
412	Digital output F polarity	0 (output source)	0 (output source)

CONFIGURATION PARAMETERS – TIMERS (PAGE 5)			
501	RESERVED	507	Smoke limiting off
502	Start delay	508	Safety on delay
503	Preheat timer	509	Generator transient delay
504	Crank time	510	Warm up time
505	Crank rest time	511	Return delay
506	Smoke limiting	512	Cooling time
		517	Breaker trip pulse
		518	Breaker close pulse

CONFIGURATION PARAMETERS – GENERATOR (PAGE 6)			
601	Alternator fitted	On (1), off (0)	On (1), off (0)
602	Alternator poles	0	Under frequency enable
603	RESERVED	610	Under frequency level
604	RESERVED	611	Loading frequency
605	Under voltage enabled	On (1), off (0)	0.0 Hz
606	Under voltage level	0 V	Over frequency enable
607	Loading voltage	0 V	Over frequency trip
608	Over voltage level	0 V	AC system

MAINS (PAGE 7) is not available on DSE4410 controllers.

CONFIGURATION PARAMETERS – ENGINE (PAGE 8)			
801	Magnetic pickup fitted	On (1), off (0)	00.0 V
802	Fluxhead teeth	000	Low battery volts return
803	Start Attempts	0	Low battery volts delay
804	RESERVED	821	High battery volts enable
805	RESERVED	822	High battery volts return
806	Gas choke timer	0:00	High battery volts warning
807	Gas on delay	0:00	High battery volts warning delay
808	Gas ignition off delay	0:00	Charge air shutdown enable
809	Check oil pressure prior to starting	On (1), off (0)	Charge air shutdown trip
810	Crank disconnect on Oil threshold	0.00 Bar	Charge at warning trip enable
811	Crank disconnect on frequency	0.0 Hz	Charge at warning trip
812	Crank disconnect on Engine Speed	000 rpm	Charge at warning trip
813	Under speed enable	On (1), off (0)	Low battery start
814	Under speed trip	0000 rpm	Low battery start
815	Over speed trip	0000 rpm	Low battery start
816	Low battery volts enable	On (1), off (0)	Run time

CONFIGURATION PARAMETERS – ALTERNATIVE CONFIGURATION (PAGE 9)			
901	Alt config - Default configuration	Main (0), Alternative (1)	On (1), Off (0)
902	Alt config - Alternative configuration	On (1), Off (0)	On (1), Off (0)
903	Alt config - Alternative Engine Speed	0 V	0 V
904	Alt config - Under Voltage Shutdown Enable	On (1), Off (0)	On (1), Off (0)
905	Alt config - Under Voltage Trip Level	0 V	0 V
906	Alt config - Loading Voltage	0 V	0 V
907	Alt config - Over Voltage Trip Level	0 V	0 V
908	Alt config - Under Frequency Enabled	On (1), Off (0)	0.0 Hz
909	Alt config - Under Frequency Trip Level	0.0 Hz	0.0 Hz
910	Alt config - Loading Frequency	0.0 Hz	0.0 Hz
911	Alt config - Nominal Frequency	0.0 Hz	0.0 Hz
912	Alt config - Over Frequency Enabled	On (1), Off (0)	0.0 Hz
913	Alt config - Over Frequency Trip Level	0.0 Hz	0.0 Hz
914	Alt config - AC System	AC system (see table)	AC system (see table)
915-928	RESERVED		
929	Alt config - Alternative under speed shutdown enable	On (1), Off (0)	0000 rpm
930	Alt config - Alternative under speed shutdown trip	0000 rpm	0000 rpm
931	Alt config - Alternative over speed shutdown trip	0000 rpm	0000 rpm

54N = 44xx - 02 (CAN) option only 54M = 44xx - 01 (Magnetic pickup) option only

Output source list overleaf...

CONFIGURATION PARAMETERS – FLEXIBLE SENSOR (PAGE 10)			
1001	Flexible sensor - alarm arming	0 (Arming)	0 (Action)
1002	Flexible sensor - Low alarm enable	0 (Arming)	0 (Action)
1003	Flexible sensor - Low alarm trip (units depend upon sensor type)	0 % / 0.00 bar / 0 °C	0 % / 0.00 bar / 0 °C
1004	Flexible sensor - High alarm trip (units depend upon sensor type)	0 % / 0.00 bar / 0 °C	0 % / 0.00 bar / 0 °C
1005	Flexible sensor - Low warning enable	On (1), Off (0)	On (1), Off (0)
1006	Flexible sensor - Low warning trip (units depend upon sensor type)	0 % / 0.00 bar / 0 °C	0 % / 0.00 bar / 0 °C
1007	Flexible sensor - High warning enable	On (1), Off (0)	On (1), Off (0)
1008	Flexible sensor - High warning trip (units depend upon sensor type)	0 % / 0.00 bar / 0 °C	0 % / 0.00 bar / 0 °C

CONFIGURATION PARAMETERS – SCHEDULER (PAGE 11)			
1101	Enable scheduler	On (1), off (0)	1104 Day
1102	On or off load	On (1), off (0)	Duration
1103	Start time	0:00:00	

CONFIGURATION PARAMETERS – TIME AND DAY (PAGE 12)			
1201	Time of day	0:00	Day of week
			0 (Day, 1=Monday)

Parameters with multiple choices use the following identification tables for the parameter values:

INPUT SOURCE LIST			
0	User Configured	8	Emergency Stop
1	Alarm Mute	9	External Panel Lock
2	Alarm Reset	10	RESERVED
3	Alternative Configuration	11	Generator load inhibit
4	RESERVED	12	Lamp Test
5	Auto start inhibit	13	Low Fuel Level Switch
6	RESERVED	14	RESERVED
7	Coolant Temperature Switch	15	RESERVED

INPUT ARMING LIST			
Index	Action	Index	Arming
0	Always	0	Always
1	From Safety On	1	From Safety On
2	From Starting	2	From Starting
3	Never	3	Never

OUTPUT POLARITY LIST			
Index	Arming	Index	Arming
0	Arming	0	Arming
1	De-energise	1	De-energise

CAN DATA FAIL ACTION			
Index	Action	Index	Arming
0	None	0	From Safety On
1	Shutdown	1	From Starting
2	Warning always latched		

FLEXIBLE SENSOR ALARM ACTION LIST			
Index	Action	Index	Type
0	None	0	2 phase 3 wire (L1-L2)
1	Shutdown	1	2 phase 3 wire (L1-L3)
2	Electrical Trip	2	3 phase 3 wire
3	Electrical Trip	3	3 phase 4 wire (Delta)
4	Electrical Trip	4	3 phase 4 wire (Delta)
5	Electrical Trip	5	Single phase 2 wire

FLEXIBLE SENSOR TYPE			
Index	Type	Index	Type
0	None	0	Digital Input
1	Digital Input	1	Percentage sensor
2	Percentage sensor	2	Pressure sensor
3	Pressure sensor	3	Temperature sensor
4	Temperature sensor		

SENSOR SELECTIONS FOR OIL PRESSURE			
0	Not used	0	Not used
1	Dig closed for alarm	1	Dig closed for alarm
2	Dig open for alarm	2	Dig open for alarm
3	VDO ohm (10-180)	3	VDO 5 bar
4	VDO tube (90-0)	4	VDO 10 bar
5	Us ohm (240-33)	5	Datacon 5 bar
6	GM ohm (0-90)	6	Datacon 10 bar
7	GM ohm (0-30)	7	Datacon 7 bar
8	Ford (73-10)	8	Murphy 7 bar
9	User defined	9	CHI812
10	Veglia	10	Beru
11	User defined	11	User defined

SENSOR SELECTIONS FOR COOLANT TEMPERATURE			
0	Not used	0	Not used
1	Dig closed for alarm	1	Dig closed for alarm
2	Dig open for alarm	2	Dig open for alarm
3	VDO 120 °C	3	Datacon high
4	Datacon high	4	Datacon low
5	Datacon low	5	Murphy
6	Murphy	6	PT100
7	PT100	7	Veglia
8	Veglia	8	User defined
9	User defined	9	User defined

Dig = Digital Switch

DSE4410Mk2 INSTALLATION INSTRUCTIONS



This instruction sheet is for DSE4410Mk2 controllers only. For DSE4410 Mk1 controllers use DSE publication 053-056

ACCESSING THE FRONT PANEL CONFIGURATION EDITOR
Ensure the engine is at rest and the module is in STOP mode by

pressing the Stop/Reset button.

Press the Stop/Reset and Down buttons simultaneously.

The configuration icon is displayed, along with the first configurable parameter.

EDITING A PARAMETER

Press to select the required 'page' as detailed in the configuration tables.

Press (+) to select the next parameter or (-) to select the previous parameter within the current page.

When viewing the parameter to be changed, press the button. The value begins to flash.

Press (+) or (-) to adjust the value to the required setting.

Press the save the current value, the value ceases flashing.

Press and hold the button to exit the editor, the configuration icon will be removed from the display.

NOTE: - Pressing and holding the + / - buttons will give auto-repeat functionality. Large values can be changed quicker by holding the buttons for a prolonged period. For instance large timers increment in 1 second steps to 1 minute, then in 30 second steps to 1 hour, then in 30 minute steps.

DIMENSIONS

180mm x 116mm x 42mm (7.1" x 4.6" x 1.7")


PANEL CUTOOUT

154mm x 98mm (6" x 3.9")

Deep Sea Electronics Inc.
Phone: +1 (815) 316-8706
Fax: +1 (815) 316- 8708
TOLL FREE (USA only) :
Tel: 1 866 636 9703
Email: support@deepseausa.com
Web: www.deepseausa.com

Deep Sea Electronics Plc.
Tel: +44 (0)1723 890099
Fax: +44 (0)1723 893303
Email: support@deepseapl.com
Web: www.deepseapl.com

TYPICAL WIRING DIAGRAM



NOTE 1. 120 R TERMINATING RESISTOR MAY BE REQUIRED EXTERNALLY. SEE ENGINE MANUFACTURERS LITERATURE

BATTERY NEGATIVE MUST BE GROUNDED. TERMINALS SUITABLE FOR 22-16 AWG (0.6mm - 1.3mm) FIELD WIRING. TIGHTENING TORQUE = 0.8Nm (7lb-in)

OUTPUT SOURCE LIST	DESCRIPTION
0	Not used
1	RESERVED
2	RESERVED
3	RESERVED
4	Audio Alarm
5	Battery under volts warning
6	Battery under volts warning
7	CAN ECU data fail
8	CAN ECU error
9	CAN ECU fail
10	CAN ECU power
11	CAN ECU stop
12	Charge alternator shutdown
13	Charge alternator warning
14	Close Gen output
15	Close Gen output pulse
16	Close Mains output
17	Close Mains output pulse
18	Combined mains failure
19	Common Alarm
20	RESERVED
21	Common Shutdown
22	Common Warning
23	RESERVED
24	RESERVED
25	RESERVED
26	RESERVED
27	RESERVED
28	RESERVED
29	Emergency stop
30	Emergency to stop
31	RESERVED
32	Fuel relay
33	Gas choke on
34	Gas ignition
35	Generator Available
36	RESERVED
37	RESERVED
38	RESERVED
39	RESERVED
40	RESERVED
41	Low fuel level
42	RESERVED
43	RESERVED
44	RESERVED
45	RESERVED
46	RESERVED
47	Open Gen Output
48	Open Gen Output pulse
49	RESERVED
50	RESERVED
51	RESERVED
52	RESERVED
53	Preheat During Preheat Timer
54	Preheat Unit End of Crank
55	Preheat Unit End of Safety Timer
56	Preheat Unit End of Warming Timer
57	Smoke limiting
58	Start relay
59	RESERVED
60	RESERVED
61	RESERVED

44xx - 02 (CAN option) only
44xx - 01 (Magnetic pickup option) only