IOWA MOLD TOOLING CO., INC.

P.O. Box 189 Garner, IA 50438 Tel: 641.923.3711 Fax: 641.923.2424 www.imt.com



Manual 99905678

TireHandler™ Radio Remote System

Revised: 07-23-2018

Copyright $\ensuremath{\mathbb{C}}$ 2018 Iowa Mold Tooling Co., Inc. All rights reserved

No part of this publication may be reproduced, stored in a retrieval system, or transmitted in any form or by any means, electronic, mechanical, photocopying, recording or otherwise without the prior written permission of Iowa Mold Tooling Co., Inc.

Iowa Mold Tooling Co., Inc. is an Oshkosh Corporation Company

Table of Contents

Introduction	1
IMT Safety Precautions	2
Equipment	3
Radio Remote System List of Equipment	4
Handheld Remote Layout and Labels	5
LED Diagnostic Information	
Battery Installation Handheld Radio Operation	
Proportional Output	11
Proportional Output MIN (Low End) & MAX (High End) Adjustments	
Minimum Adjustment Procedure	
Maximum Adjustment Procedure	
Ramp-Up Rate Adjustment Procedure	
Ramp-Down Rate Adjustment	
Base Unit	19
Hardware Configuration	20
Safety Link	
Base Unit Channel Configuration	
Wiring Harness Connections (If Purchased)	
Base Unit Mounting	
Specifications	25
Base Unit Specifications	26
Current Output	29
Output Current De-Rating Curve	
Troubleshooting Guide	31
Base Unit Troubleshooting Guide	
Appendix	33

Introduction

IMT Safety Precautions

- Read and follow all instructions
- Failure to abide by Safety Precautions may result in equipment failure, loss of authority to operate the equipment, and personal injury.
- Use and maintain proper wiring. Follow equipment manufacturer instructions. Improper, loose, and frayed wiring can cause system failure, equipment damage, and intermittent operation.
- Changes or modifications made to equipment not expressly approved by the manufacturer will void the warranty.
- Owner/operators of the equipment must abide by all applicable Federal, State, and Local laws concerning installation and operation of the equipment. Failure to comply could result in penalties and could void user authority to operate the equipment.
- Make sure that the machinery and surrounding area is clear before operating. Do not activate the remote control system until certain that it is safe to do so.
- Turn off the handheld remote and remove power from the base unit before attempting any maintenance. This will prevent accidental operation of the controlled machinery.
- Power can be removed from the Base Unit by detaching the 12-pin cables from the base unit connectors P1 and P2, or by removing the source power from the circuit.
- Use a damp cloth to keep units clean. Remove mud, concrete, dirt, etc. after use to prevent obstructing or clogging the buttons, levers, wiring, and switches.
- Do not allow liquid to enter the handheld or base unit enclosures. Do not use high pressure equipment to clean the handheld remote or base unit.
- Disconnect the radio base unit before welding on the machine. Failure to disconnect the base unit may result in destruction of or damage to the base unit.
- Operate and store units only within the specified operation and storage temperatures defined in the specifications of this document.
- Keep high-energy RF devices away from handheld remotes. Activation of high-power communication radios, for instance, in close proximity to handheld remotes can result in interference and "false" circuit activation.
- Do not key 2-way radios while using the handheld remote.

Equipment

Radio Remote System List of Equipment

QTY	MODEL	PART NUMBER	DESCRIPTION
1	MCB-2H02JS-10054	70735133	TRANSM-RAD REM TOGGLE TH 5K-36K
1	BU-2H18XF-10054	70735134	RECEIVER-RAD BASE TOGGLE TH 5K-36K
·	1	•	



Note: It is possible to order the system with one part number. Specify WSMB-10054 in the purchase order to receive the parts listed in the table above. If an individual part needs to be ordered, use the part number listed in the table above.

Handheld Remote Layout and Labels



Umbilical Connector

SWITCH / LED	FUNCTION	SWITCH TYPE / DESCRIPTION
SI+	Fallback Arm Forward	2 Desition Momentary Teggle
S1	Fallback Arm Reverse	S Position Momentary Toggle
S3+	Pad Rotate CW	3 Position Momentary Toggle –
S3	Pad Rotate CCW	Proportional (Pulse Width Modulated)
S4+	Side Shift Left	3 Position Momentary Toggle –
S4	Side Shift Right	Proportional (Pulse Width Modulated)
S5+	Body Rotate CW	3 Position Momentary Toggle –
S5	Body Rotate CCW	Proportional (Pulse Width Modulated)
071	Clamp	3 Position Momentary Toggle –
5/+	Clamp	Proportional (Pulse Width Modulated)
		3 Position Momentary Toggle –
S7	Release Clamp	Proportional (Pulse Width Modulated)
		Operates with S8 pressed (+)
S8+ (PRESSED)	Clamp Release Enable	Green Pushbutton
S9	Power/Associate Switch	Green Pushbutton
STOD	Ston	Red Button – Pull Up to Enable Start
510F	Stop	Push Down to Stop
LED1	Tx (Green)	Transmit
LED2	Rx (Amber)	Receive
LED3	Error (Red)	Error Indication
LED4	Battery (Amber)	Battery Indication

5

LED Diagnostic Information

LED INFORMATION	CONDITION	COLOR
TX Short Blinking	Handheld is transmitting	Croon
TX Long Blinking	Switch active on handheld	Gleen
RX Blinking (indication of RF signal integrity)	Base unit messages received	Amber
ERR*	Switch fault at power-up	Bod
ERR**	Machine Stop depressed at power-up	Reu
BATT Slow Blinking***	Low battery Indication	Amber



*LED's 1 and 3 will blink alternately with 2 and 4.

**LED's 1 and 2 will blink alternately with 3 and 4

*** Replace batteries with four fresh batteries ASAP.

Battery Installation

This SmaRT handheld unit is powered by four size AA batteries. When installing batteries, be sure to observe proper polarity as marked on the inside of the compartment to avoid damaging the unit.

To replace or install batteries in the handheld:

- 1. Loosen the four captive battery compartment cover screws on the rear of the remote and lift the cover from the handheld.
- 2. Install (or replace with) four (4) fresh size AA batteries. Observe the proper polarity by positioning the batteries as shown in Figure 3.
- 3. Replace the compartment cover and tighten the four screws. These screws should not be over-tightened, but they must be tight enough to assure the gasket provides a proper environmental seal.





Sealing Gasket



Be sure to observe proper polarity when placing batteries in the handheld battery compartment.

Note: Cover screws must be tightened enough to assure the sealing gasket is compressed. Do not over-tighten the screws.

7

Handheld Radio Operation

Turn ON the Unit

This remote is powered ON by pulling the large red STOP button UP and then pushing the green ON switch (S9).

Turn OFF the Unit

The remote is turned OFF by pushing the large red STOP button down.

MCB-2H02JS-10054 is programmed to power down after FOUR minutes of inactivity. If the unit powers down due to inactivity, the ON switch (Green S9) can be used to re-activate the unit.

Proportional Control

See Chapter 3

Toggle Switches

Toggle switches S1, S3, S4, S5, and S7 are three position momentary toggle switches.

Button Switches

S8 pressed enables the Clamp Release function for S7- (down).

M-Stop must be in the up position to allow Start (S9). Pushed down shuts down the MCB thus stopping any controlled functions.



ASSOCIATE MODE:

Associate Mode is used to establish the communications link between a remote and base unit on a 1-to-1 association basis. To associate there must be a clear line of sight between the handheld and the base, and both units must be OFF (powered down). Note: The remote is turned off by pushing the oversized mushroom STOP button. The SmaRT base unit is safely powered down by disconnecting P1 and P2 or by removing/turning-OFF the power source from the unit.



To prevent inadvertent movement to the machine, be sure to remove power from the Base Unit by disconnecting P1 & P2 or by turning OFF the power source before attempting to enter Associate Mode.





TO ASSOCIATE:

- 1. Stand near to the base unit with the remote OFF and power removed from the base unit (disconnect P1 and P2 or turn the source power OFF).
- 2. Release the STOP button on the handheld by pulling up.
- 3. Push and hold the Green Start button S9 and then immediately push and hold S1 UP (Forward). All four LEDs light solid.
- 4. Observe the LEDs. When RX goes OFF, power up the base unit. When the RX LED blinks, release S9 and S1.

A successful Association is indicated when LEDs TX and RX are rapidly blinking while the Battery and Warning LEDs are unlit.

This page left intentionally blank

Proportional Output

Proportional Output MIN (Low End) & MAX (High End) Adjustments

What You Need to Know Before You Adjust the Output Min and Max

- The operator must make sure the area around the controlled machine is safe to operate before performing dynamic MIN and MAX adjustments.
- The base unit must be powered for dynamic adjustment.
- The base unit LEDs and display should be close enough to be easily read.
- Adjust Mode timeout defaults to a ten (10) second window of opportunity, where the unit returns to normal operating mode if none of the switches are operated within the 10 second window. The timer resets to 10 seconds each time a toggle switch is operated while in Adjust Mode.
- Each toggle switch is adjusted using the following steps.

Enter Adjust Mode

- Both the handheld, MCB-2H02JS, and base unit, BU-2H18XF, must be powered up and communicating with each other.
- To enter Adjust Mode, push and hold switch S1UP and then press the green push button for approximately 4 to 5 seconds until the bottom three base unit LEDs begin to flash (Figure 6) and CAL will show in the base unit display.
- Release switch S1 and green push button.



Push and hold S1



Push and hold for approximately 5-seconds until LEDs flash



PWM Function Switches



Be aware of toggle switches activation during this process. Base Unit outputs may be active during the toggle swtich adjustment process.

Minimum Adjustment Procedure

The following charts—Figure 7 through Figure 10—can be used to adjust the minimum, maximum, ramp-up rate, and ramp-down rate of Pad Rotate (S3), Side Shift (S4), Body Rotate (S5), and Clamp-functions (S7).



Maximum Adjustment Procedure







Ramp-Down Rate Adjustment



To Abandon Adjust Mode:

• At any point during adjustment, you can abandon Adjust Mode by pressing the M-Stop button.

Exit Adjust Mode:

- Waiting approximately ten seconds for the adjustment procedure to timeout (LED 7 or LED 8 must be on solid only)
- By pressing the MCB STOP button.

Function Default Settings:

• The values expressed in Table 4 are typical and may be adjusted depending on specific circumstances.

	PROPORTIONAL SETTINGS			RAMP SETTINGS				
	FAC DEF	TORY AULT	OPERATIONAL RANGE*		FACTORY DEFAULT		OPERATIONAL RANGE**	
	MIN (%)	MAX (%)	MIN (%)	MAX (%)	UP (ms)	DN (ms)	UP (ms)	DN (ms)
CLAMP RELEASE	28	53	20	80	250	250	0-3000	0-3000
CLAMP	28	50	20	80	250	250	0-3000	0-3000
BODY ROTATE CCW	28	57	20	80	250	250	0-3000	0-3000
BODY ROTATE CW	25	51	20	80	250	250	0-3000	0-3000
PAD ROTATE CW	26	53	20	80	250	250	0-3000	0-3000
PAD ROTATE CCW	27	53	20	80	250	250	0-3000	0-3000
SIDE SHIFT RIGHT	27	55	20	80	250	250	0-3000	0-3000
SIDE SHIFT LEFT	25	53	20	80	250	250	0-3000	0-3000

*1% increments

**250ms increments

This page left intentionally blank

Base Unit

19

Hardware Configuration

REQUIRED FIELDS	DESCRIPTION	DETAILS / NOTES	
Control Power	7-32VDC	Must be able to operate @ 32VDC	
Radio Frequency (RF)	2400MHz @ 100mW	Frequency Channel Hopping DSSS	
Antenna Option	Internal		
Discrete Channels	18 Available	FET, High-Side outputs	
Digital Output Channels	13	8 PWM; 5 On/Off	
Link Loss Criteria	0.5s	Five consecutively missed messages	
Message Periodicity	10x/s	One message every 10ms	
CAN Information	J1939	Refer to J1939 Standard	
Internal CAN Termination	1.0kΩ (default)		
Proportional Channel Info	PWM Frequency: 250Hz		
	Voltage: 24VDC		
	Load Resistance: 4.7Ω		

Safety Link

BASE UNIT	SAFETY LINK
Х	
 ENABLED When any of the following occurs: Machine Stop is pressed HH unit goes out of range HH unit deactivates due to loss of power, Inactivity timeout, or deliberate deactiva- tion (off switch) All latched outputs unlatch and all momentary outputs that are active deactivate. Upon acti- vation of the HH, no outputs are allowed to be activated until all switches (unless masked) are first centered or returned to their neutral state. 	DISABLED When any of the following occurs: • Machine Stop is pressed • HH unit goes out of range • HH unit deactivates due to loss of power, Inactivity timeout, or deliberate deactivation (off switch) Then all latched outputs remain latched but all momentary commands that are active deactivate. NOTE: If HH unit is powered on and a mo- mentary command that was deactivated due to range is still active when the HH returns in range, the output will immediately be active again

Base Unit Channel Configuration

BASE UNIT CONFIGURATION					_		
CHANNEL	TYPE*	FUNCTION	ACTIVATED BY:	SETTINGS /	COMMENTS	PIN]
+VDC	+VDC IN	+VDC IN				1	
M17	UNUSED					2	
M9	LO-HS-M	Fallback Arms Rev	S1-			3	
M10	LO-HS-M	Fallback Arms Fwd	S1+			4	
M11	UNUSED					5	3
M12	LO-HS-M	Clamp Release Enable	S8(+)			6	
M13	LO-HS-M	Crane Hourmeter	M1 OR M2 OR M3 OR M4 OR M5 OR M6 OR M7 OR M8			7	
M14	UNUSED					8	I
M15	UNUSED					9	1
M16	LO-HS-M	LINK/STOP	RF LINK Loss of Link OR Stop			10	1
M18	UNUSED					11	1
-VDC	-VDC IN					12	1
M5	PWM	Clamp Release	S7- AND S8(+)	MIN: 20%	MAX: 80% See Note 1	1	
M6	PWM	Clamp	S7+	MIN: 20%	MAX: 80%	2	1
M7	PWM	Body Rotate CCW	S5-	MIN: 20%	MAX: 80%	3	
M8	PWM	Body Rotate CW	S5+	MIN: 20%	MAX: 80%	4	
CAN H		(Optional To Mcb)	Operational	Connect to umbilical co	MCB onnector pin 2	5	
UMB PWR		(Optional To Mcb)	Operational	Connect to umbilical co	MCB pnnector pin 1	6	ľ
+VDC		+VDC IN				7	ľ
CAN L		(Optional To Mcb)	Operational	Connect to umbilical co	MCB onnector pin 3	8	I
M1	PWM	Pad Rotate CW	S3+	MIN: 20%	MAX: 80%	9	
M2	PWM	Pad Rotate CCW	S3-	MIN: 20%	MAX: 80%	10	
M3	PWM	Side Shift Right	S4-	MIN: 20%	MAX: 80%	11	1
M4	PWM	Side Shift Left	S4+	MIN: 20%	MAX: 80%	12	1
		L					_

*TYPES xx-xx-xx

M = MOMENTARY LA = LATCHING

AI = ANALOG INPUT AO= ANALOG OUTPUT LI = LEVEL INPUT LS = LOW SIDE UN = UNLATCHING

LO = LEVEL OUTPUT NA = NOT APPLICABLE PWM=PULSE WIDTH MOD

NOTES:

1. Switch 8 (+) is used to enable Clamp Release (S7-) function. Operator may use the function once output M12

is enabled. Must be enabled again if no activity for 5-seconds.

2. The Machine Stop latches all functions off.

3. Outputs are not active during the minimum and maximum adjustment process and the ramp up/down adjustment process.





Wiring Harness Connections (If Purchased)



Base Unit Mounting





Specifications

Base Unit Specifications

BASE UNIT SPECS			
POWER	VIN	DESCRIPTION	
	Frequency	2405 - 2480MHz	
Radio	RF Power	100mW	
	License	No license required (license free)	
	Modulation	DSSS	
	Antenna	Internal	
	Operating Temp	See De-Rating Curve chart below for details	
	Storage Temp	-40°C to 85°C (-40°F to 185°F)	
Environment	Humidity	0 to 100%	
	Vibration / Shock	IEC60068-2-6	
		10Hz to 150Hz @ 1.0g peak acceleration	
		10.0g peak shock acceleration	
	Unmarked	Polarity reversed when lit	
	+V1	OK when active solid	
	+V2	OK when active solid	
	+V3	OK when active solid	
	1 (Health)	OK when active blinking	
Indicators (11)	2 (RF TX)	Blinks when active	
	3 (RF RX)	Solid when receiving	
	4 (CAN TX)	Blinks when active	
	5 (CAN RX)	Solid when active	
	6 (OUT)	Solid when active	
	7 (IN)	Solid when active	
	8 (Error)	Solid—channel output high or low current Blink—global voltage problem	

BASE UNIT (CONTINUED)				
POWER	VIN	DESCRIPTION		
	Dimensions	119mm x 133mm x 36mm(5.24" x 4.69" x 1.42")		
Enclosure	Durability	High Impact Polymer		
	Mounting Holes	7.4mm (0.29") dia. 102mm center-to-center(4" cen- ter-to-center.		
Outrate	Eighteen	FET—Open Drain		
Outputs	Output Current	2A per channel 15A Max. total @ 55º C		
Display	LCD	One line, four character		
Umbilical	CAN Bus	SAE J1939		

This page left intentionally blank

Current Output



Output Current De-Rating Curve

Troubleshooting Guide

Base Unit Troubleshooting Guide

INDICATION	SUGGESTIONS
Power LED (+V1,+ V2, +V3) not active	 Is +VDC input power present? Check input power polarity.
Health LED steady ON	Indicates an internal component failure
TX/RX not active	 Check for obstructions preventing line-of-sight transmission Check that the handheld remote is active Re-associate the handheld remote to the base unit.
CTX/CRX not active	Check CAN connection.
Out LED not active	 Check that the handheld LEDs are active when the appro- priate buttons are pushed.
Error LED active	 Check the outputs for loose wiring, etc. Over-temperature channel indication. Over-current channel indication. Error condition exists. Active channel current consumption less than 1A typical.(This is not a problem in cases where less than 1A draw is a normal condition.)
In LED not active when expected	Check that the input signal is referenced to P1:12.

Appendix

33

Appendix A: Exposure to Radio Frequency Energy

SmaRT handheld remote units contain radio transceivers. When active, a handheld remote sends out radio frequency (RF) energy through its internal antenna. The SmaRT handheld remote complies with limits set by the FCC for operating distance from human tissue.

Appendix B: Agency Identification Label Locations





Agency Identification Label Location

✓ Note: The Agency ID label can be found at this location for all SmaRT base units. The base unit label position is identical for both internal and external antenna base units.



IOWA MOLD TOOLING CO., INC.

P.O. Box 189 Garner, IA 50438 Tel: 641.923.3711 Fax: 641.923.2424 www.imt.com

IMT reserves the right to make changes in engineering, design, specifications, add improvements or discontinue manufacturing at any time without notice or obligation. IMT and IMT LOGO are registered trademarks of Iowa Mold Tooling Co., Inc., Garner, IA, USA. © 2018 Iowa Mold Tooling Co., Inc. All Right Reserved.