


BEAD PUSH-OFF TOOL



The IMT bead push-off tool is designed to assist the tire serviceman in removing a tire from the wheel.

To operate the tool, it must be connected to either a hand powered hydraulic pump or an air-over-hydraulic pump (IMT Part Number 73051010).

After the first bead is off the wheel, proceed as follows:

- 1. Pry the tire away from the wheel with a tire iron (Step 1).
- 2. When there is adequate clearance, hook the tool on the rim (Step 2)

WARNING

Make certain the hooks are both properly aligned on the wheel rim. Faulty alignment could result in the tool being thrown by pressure from the tire bead and may cause an injury or damage to the equipment. 3. Extend the ram by applying power to the tool (Step ;


WARNING


Keep hands clear of the tool while applying power. Failure to comply may result in a hand injury due to crushing between the tool and the wheel.

- 4. Continue working around the wheel with the tire irons and the bead push-off tool until the tire is free.
- 5. To retract the ram, depress the "RETRACT" end of the pump pedal and push the ram back into the cylinder.

NOTE

To protect the machined surfaces of the rod, it must always be stored with the ram completely retracted.





| Item No. | Part No. | Description | Qty | Item No. | Part No. | Description | Qty | - |
|-------------|-------------|--------------------------------|-----|-------------|-------------|------------------------------------|-----|---|
| 1., | 60106406 | HANDLE | 1 | 11. | 72062147 | NUT | 1 | 1 |
| 2. | 72053517 | NIPPLE; 1/4" npt | 1 . | 12, | | WASHER, wavy | *1 | İ |
| 3. | 72532287 | NIPPLE, quick disconnect | 1 | 13. | | PLATE, packing retainer | *1 | |
| 4. | 70392107 | DECAL, serial number | 1 | 14. | PA1 | PACKING | *3 | |
| . 5. | 60106355 | HOOK | 1 | 15. | 70142327 | DISC | 1 | |
| 6. | -60106859· | CLAW 60025156 | 1 | 16., | 70142329 | RING, stop | 1 | 1 |
| 7. | 79075047 | RAM (includes items 8 thru 19) | 1 | 17. | 717 (200) | RING, retaining | *1 | - |
| 8. | 72601252 | SCREW | 2 | 18. | 70142326 | ROD with saddle (includes item 19) | 1 | ĺ |
| 9., | 70142330 | CASE | 1 | 19 | 70142325 | SADDLE | 1 : | : |
| 10. | 70142328 | SPRING | 1 | | | | | |

^{*}Part of repair kit (Part Number 94074035)

CAUTION

Warranty will be void on any part of unit subjected to misuse due to overloading. When powered by an airdriven pump, the ram is capable of a force of four tons. This force, if applied at a point other than dead center on the ram, could bend the rod. Bending the rod is considered misuse due to overloading and will void the warranty on the rod.



IOWA MOLD TOOLING CO., INC.

500 HWY 18 WEST, GARNER, IA 50438