Manual Part # 99905190

IMT Telescopic Crane Operation & Safety Manual

Revised: August 4, 2022



IOWA MOLD TOOLING CO., INC. PO Box 189 Garner, IA 50438 Tel: 641-923-3711 FAX: 641-923-2424 Website: http://www.imt.com

Copyright $\textcircled{\mbox{\scriptsize C}}$ 2015 Iowa Mold Tooling Co., Inc. All rights reserved

No part of this publication may be reproduced, stored in a retrieval system, or transmitted in any form or by any means, electronic, mechanical, photocopying, recording or otherwise without the prior written permission of Iowa Mold Tooling Co., Inc.

Iowa Mold Tooling Co., Inc. is an Oshkosh Corporation Company.

Contents

Revisions	iv
roduction	5
Crane Component Identification Crane Safety	
eration	11
Initial Operation Requirements	
Daily Safety Inspections	
Preparing the Job Site	
Electrical Hazards	
Stabilizers	
Telescopic Crane Controls	
Crane Operation Using the Proportional Remote	
Overload Protection System	
Receiver Display	
Radio Elimination Cable	
Crane Capacity	
Task Performance	
Anti-Two Block System	
Auto-Release Hook Storage	
Winch	
Flip Sheave Feature	
Double & Single Line	
Load Level Indicator	
Options	
Emergency Manual Operation	
Crane Shut Down	35
Troubleshooting	
Operation in Adverse Conditions	
Cold Weather	
Signals	

Maintenance

41

Maintenance Introduction	41
Maintenance Schedule	
Greasing Instructions	43
New Crane Rotator Worm Gear Break-In Period	

i

Hydraulic Fluid Level	45
Crane Hydraulic Oil Specifications	46
Changing Hydraulic Oil & Filter	46
Purging Air from Hydraulic System	47
Hydraulic Pressure Relief	47
Hydraulic Cylinder Holding Capability	48
Winch Oil Specifications	
Wire Rope & Hook Maintenance	49
Wire Rope Inspection	49
Wire Rope Lubrication	50
Wire Rope Maintenance	
Wire Rope Inspection & Replacement	
Wire Rope Slings	
Wire Rope Lay	
Hook Maintenance	

Periodic Inspection	53
Additional Inspection	53
Corrosion Control	
Long-Term Storage	
Zong Term Storage	

Repair

57

Repair Precautions	
Systematic Repair Procedure	
Associating Radio Remote Receiver and Transmitter	
Wear Pads	
Cylinder Repair	61
Pin Removal & Inspection	
Bushings	
Wire Rope Removal & Replacement	63
Turntable Bearing Inspection	64
Turntable Bearing Tilt Test	64
Turntable Bearing Thread Tightening Sequence	
Turntable Bearing Worm End Play & Backlash	

Installation

Installation Introduction70Chassis Preparation70Frame Strength70PTO & Pump70Engine Speed Regulation71Crane Installation72

Crane Decals

Telescopic Crane Decals	76
Danger Decals	
Danger Decal Figures	
Instructional Decals	80

Reference

85

75

Inspection Checklist	85
Deficiency / Recommendation / Corrective Action Report	
Crane Stability Test	
Stability Chart	94
Thread Torque Charts	

69

Revisions

DATE	LOCATION	DESCRIPTION
20111228	THROUGHOUT	ECN 11628 – Updated stabilizer wording, safety decals, added stabilizer fully deployed instructions.
20131212	PAGE 69	Added NOTE per engineering mark-up.
20140915	Greasing Instructions	ECN 12264 – Molub-Alloy 882 was Molub-Alloy 936
	Instructional Decals	ECN 12279 – Removed Mobil Oil from 70394189.
20150928	Added Label	Label #70734592
20170309	Pgs:24,26,43,80	Updated and corrected information.
20220804	Pg. 78	Correct electrocution decal

$C \ \text{H} \ \text{A} \ \text{P} \ \text{T} \ \text{E} \ \text{R} \quad 1$

Introduction


Thank you for purchasing an IMT crane! We want you to be able to meet your material handling and lifting needs with this product, and following proper operating procedures is the best way to do this. This manual:

- Explains the operation and maintenance of this vehicle and equipment
- Reviews basic principles of operation
- Highlights common safety concerns and procedures
- Gives recommendations for using and maintaining the equipment.

This manual assumes that you:

- Have already been fully trained to operate the vehicle and equipment.
- Have demonstrated the effectiveness of your training and the extent of your knowledge.

BEFORE operating this vehicle and equipment, you, the operator or maintenance person, must read, understand, and follow the instructions found in this operation and maintenance manual and the operation and maintenance manuals from the manufacturers of major components used on this vehicle or equipment. Proper tools and service equipment must be used, taking appropriate precautions as required by accepted safety practices, to prevent personal injury and/or equipment damage. If you are uncertain about the safe operation of any aspect of this vehicle or equipment, stop immediately and seek further training. You are the only person who knows what you don't know. You must speak up about the things you don't know, so you can learn about them before someone is injured or killed because of your lack of knowledge. You are responsible for learning how to operate this vehicle and equipment under all conditions without having to pause to read this manual.



For more information on crane design and test criteria, refer to ANSI/ASME B30.5, the standard for Mobile and Locomotive Boom Cranes, (You may obtain this publication from ASME at *www.asme.org.*) Crane operators must also be familiar with OSHA 29 CFR 1926 Subpart CC and CAL-OSHA Title 8, Article 93 (California).

This volume includes information that is common to all telescopic crane manufactured after June 2011. For specific information, refer to the parts and specifications manual for your crane model. We recommend that this manual and the parts manual are stored with the crane.

MODIFICATIONS

Modifications to your crane must be performed with IMT approved accessories, parts and optional equipment. If in doubt about the safety, compatibility, or appropriateness of any modifications, contact IMT prior to making those modifications. DO NOT alter or modify any safety device! All safety devices must be inspected, tested and maintained in proper working condition.

Note that decals regarding crane safety and operation are considered safety equipment. They must be maintained just as any other safety device. Decals must be kept clean and legible to the operator, operational personnel, and bystanders as specified in the decal section of this manual. DO NOT remove, disable, or disregard any safety device attached to your crane.

WARRANTY

Warranty of this unit will be void on any part of the unit subjected to misuse due to overloading, abuse, lack of maintenance and unauthorized modifications. No warranty - verbal, written or implied - other than the official, published IMT new machinery and equipment warranty will be valid with this unit.

MANUAL STRUCTURE

Throughout this manual, symbols are used to highlight information of particular importance. They are defined as follows:

NOTE

A NOTE is used to either convey additional information or to provide further emphasis for a previous point.

A WARNING is used when there is the potential for personal injury or death.

ACAUTION

A CAUTION is used when there is the very strong possibility of damage to the equipment or premature equipment failure.

Danger indicates an imminently hazardous situation which, if not avoided, will result in death or serious injury. Danger is used in the most extreme situations.

NOTICE TO THE OWNER / USER


If your equipment is involved in a property damage accident, contact your IMT distributor immediately and provide them with the details of the accident and the serial number of the equipment. If an accident involves personal injury, immediately notify your distributor and the IMT Technical Support department at:

IOWA MOLD TOOLING CO., INC. 500 HWY 18 WEST GARNER, IA 50438


641 - 923 - 3711

Crane Component Identification

Use the following diagram to identify the components of your crane, to aid in communicating crane problems, and to provide reference during emergency situations. This diagram refers to IMT telescopic cranes only, and should not be considered universal.



Crane Safety



 OPERATE SAFELY Do NOT operate crane unless you have been trained in safe operation. Read, understand, and follow manual, labels, safety instructions, and your employer's work rules. Make sure guards, safety signs, and safety features are in place and in good condition. Read, understand and follow the crane load and work area charts. Do not exceed crane or winch ratings. Keep three wraps of loadline on winch.
 Use crane with truck level on solid surface and with stabilizers properly extended. Reduce loads when operating on uneven ground. Keep personnel clear of moving stabilizers. Operate crane controls slowly and smoothly. Do NOT operate in excessive wind speeds. Keep load under boom tip. Do NOT side load boom, drag, or swing loads. Stow boom and stabilizers before traveling. Follow all inspections and maintenance practices listed in manuals. AVOID FALLING LOADS Always stop operation before block contacts sheave. (Two-blocking) Do not rely on limit switch to stop block. If block contacts sheave, lower load by letting out cable. Inspect for damage.
 AVOID FALLS Never use crane to hoist personnel. Never ride on boom, hook, load, or any device attached to crane.
 DO NOT OVERLOAD CRANE Read, understand and follow the crane load and work area charts. Do not exceed crane or winch ratings. Weight of accessories attached to boom or loadline must be subtracted from the load rating chart or added to the load weight. Do not exceed manual boom extension load ratings at reduced boom lengths.

CHAPTER 2

Operation

In This Chapter

~
2
3
4
6
7
8
0
2
3
4
7
8
0
1
1
2
4
4
4
4
5
7
9
346780234780112444457

Initial Operation Requirements

To operate a crane, crane operators must conform to qualifications as specified by ANSI B30.5, Chapter 5-3, as well as OSHA 29 CFR 1926 Subpart CC. Prior to beginning work at a job site, the crane operator should understand:

- Crane Safety
- Crane Controls
- Crane Load Limits
- Operating Procedures

Certain inherent risks are associated with heavy vehicles due to the nature of their use. Personnel working in the area of these vehicles are subject to certain hazards that cannot be guarded against by mechanical means but only by the exercise of intelligence, care, and common sense. It is therefore essential for the owner of this equipment to have personnel involved in the use and operation of these vehicles who are competent, careful, physically and mentally qualified, and trained in the safe operation of this equipment.

The operator should also have the chance to practice operating the crane prior to using the crane in a job site application. The operator must understand what to do in case of emergency and be prepared to take emergency action at any time. Safe operation is the responsibility of the operator, maintenance and inspection personnel. Safety has been a major consideration in the design and manufacture of this equipment, but only the operator and maintenance personnel can insure a safe work environment.

Daily Safety Inspections

Use the following list as a guide when you are inspecting your unit at start-up and during operation, and log your inspection results using the Crane Log (IMT Manual No. 99900686) or the inspection checklist in the reference section of this manual:

- 1 Vehicle Check oil level, battery, lights, brakes, and tires for inflation, pressure, cuts, and loose or missing wheel lugs.
- 2 Safety Accessories Check for proper function, oil levels, leaks and malfunctions.
- 3 Anti-Two-Block System Check daily for performance. See *instructions* (see "Anti-Two Block System" on page 28) in the Operation section. Inspect sheaves for cracks, grooves, or damage from two-blocking.
- 4 Hydraulic Oil Reservoir Check for proper oil level. Check for leaks and blockages.
- 5 Weldments Check visually for damage, especially cracks or breaks in welds.
- 6 Cylinders Check for leakage and scored rods.
- 7 Fasteners Check pins, sheaves, nuts and bolts for breakage, excessive wear and tightness.
- 8 Hooks Check for the presence of a safety catch, twists, cracks, or damage.
- 9 Ropes & Slings Check for frayed edges, broken strands, kinks, flat spots, and end attachments.
- **10** Covers & Guards Check for missing or improperly maintained covers and guards.
- **11** Remote Control Check all remote functions for function and corrosion.

- 12 Operation Placards and Safety Decals Check for illegible or missing decals and placards. Refer to the Decal section of this manual for more information on the required decals.
- 13 Work Area Check for hazards including powerlines, obstructions, etc.

Replace or repair any items as needed prior to equipment operation.

Preparing the Job Site

Proper site preparation is extremely important to a safe work environment. Plan lifts carefully and watch for hazards such as powerlines, bystanders, or overhead obstructions. When planning a lift, consider:

- Powerlines
- Bystanders
- Overhead obstructions
- Solid surface support


Determine the weight of the load to be lifted. Use the crane capacity chart to make sure all lifts are performed within the rated capacity of the crane. Position the carrier vehicle with these capacities in mind and avoid any overhead obstructions which can impair the lift.

AVOID POWER LINES! Read and understand the Electrical Hazard section of this manual before attempting any crane operations near powerlines.

A WARNING

Avoid injury! The operator is responsible for being aware of unauthorized personnel in the work area. Do not operate unless the work area is clear.

Visibility is critical! Park the vehicle so the operator can see all of the working area.



After selecting an appropriate position for your vehicle:

- 1 Park the vehicle.
- 2 Activate the parking brake.
- **3** Turn on the PTO following manufacturer instructions. This will provide hydraulic and electrical power for the crane.
- 4 Follow IMT instructions to set up the stabilizers and operate the crane.

Electrical Hazards


A DANGER ELECTROCUTION HAZARD

- Vehicle is not insulated.
- Do NOT raise boom into power lines.
- Look up and use light to search for power lines in the dark.
- Keep boom and vehicle a minimum of 20 ft. (6.1 m) away from power lines.
- Do not step off a charged vehicle.
- If you touch a charged vehicle while standing on the ground, you will die.

Overhead power lines are not insulated. While some lines have a weather covering and appear to be insulated, they are not. The vehicle or parts of the vehicle do not need to touch the power line for the vehicle to become energized. Electricity will arc across gaps, and all overhead wires or cables should be considered hazardous and dangerous. Always operate the crane so that no part of the crane or load enters the "Danger Zone", the minimum clearance distance for a powerline.



The danger zone of a particular powerline is based on its voltage. High voltage levels increase the danger zone. See figure.



REQUIRED CLEARANCE OF CRANES FROM ELECTRICAL TRANSMISSION LINES		
	NORMAL VOLTAGE kV (Phase to Phase)	MINIMUM CLEARANCE REQUIRED Feet (meters)
OPERATION NEAR HIGH	From 0 to 350	20 (6.10)
VOLTAGE POWERLINES	Above 350 or unknown	50 (15.24)
OPERATION IN TRANSIT WITH	From 0 to 0.75	4 (0.22)
NO LOAD AND BOOM OR MAST	From 0.75 to 50	6 (0.83)
LOWERED	From 50 to 345	10 (3.05)
	From 345 to 750	16 (4.87)
	From 750 to 1000	20 (8.10)

GUIDELINES WHEN WORKING AROUND POWER LINES:

- Make sure the work area is clear of major obstacles and overhead obstructions
- Do not work within 20 feet (6.10 m) of high-voltage lines energized up to 35,000 volts, and 50 feet (15.24 m) of high-voltage lines energized up to 50,000 volts or of unknown voltage. It is the law. The operator can be liable if activities in violation of this law cause injury or property damage.
- Only operate in conditions where the vehicle and equipment can be stabilized. Do not set up or
 operate on soft soil, mud, snow or other unstable ground conditions that could allow the vehicle or
 equipment to shift and move within 20 feet (6.10 m) of a power line.
- Look up and live. Always check the operating vicinity for power lines before you drive into it. Tree branches can hide power lines or cables from view. If operating at night, use powerful lights to search for power lines or poles.
- During windy conditions, allow additional clearance.
- Do not rely on cage-type boom guards, insulating links, or proximity warning devices for safety. Adhere to the required distances listed in table titled REQUIRED CLEARANCE OF CRANES FROM ELECTRICAL TRANSMISSION LINES.
- Contact the utility company before beginning work near powerlines.
- Always assume overhead lines to be energized.
- Avoid transporting a crane over uneven terrain.
- When using rope to steady a load or restrain spinning of the load, be aware that rope will also conduct electricity, especially if wet or damp.
- Reduce operating speed when in close proximity to powerlines in order to allow the operator more reaction time.

IF ELECTRICAL CONTACT OCCURS:

- 1 If you are on or inside a vehicle that contacts or is energized by a power line, stay where you are. Exiting the vehicle is more hazardous than remaining inside. Unless there is a fire, it is safer to stay in the vehicle than to attempt an exit. Stay in or on the vehicle until a power company representative informs you that the line has been de-energized and grounded and that the area is safe.
- 2 If it is critical that you leave the vehicle, JUMP as far away as possible landing with both feet together. Maintain balance or fall forward, don't fall back towards the vehicle which could result in the body becoming a pathway between the vehicle and the ground. No part of your body should touch the vehicle and the ground at the same time.

- 3 If you are outside of the vehicle that contacts or is energized by a power line, move away from the vehicle and stay away. Warn others to stay away. You are safe from electrical shock as long as you do not become a pathway for current to flow to the ground. Do not approach the vehicle until a power company representative informs you that the line has been de-energized and grounded and that the area is safe
- 4 In certain circumstances the ground around a charged vehicle or downed power line may be energized. The ground becomes charged in concentric circles around the vehicle with varying voltage potential. Straddling these bands can result in serious injury or death as the current passes through your body. Stay away from the vehicle or power line, keeping both feet on the ground at the same time. This will prevent you from becoming a conductor between two areas of the ground that are charged differently.
- **5** If someone is trapped inside a vehicle that has come in contact with a power line, instruct them to stay inside and not to try to exit, unless their life is in eminent danger or a fire is present. Call 911 immediately and instruct the 911 operator to contact the power company. The power company personnel are trained to eliminate the hazard by de-energizing the line.
- 6 Do not attempt any rescue a person on or inside an energized vehicle, or who is energized themselves. If you touch someone whose body is conducting current, the current will flow through you too. Your muscles will seize up and you will not be able to escape.

ELECTRICAL CONTACT FOLLOW-UP:

- 1 Inspect and repair any equipment affected by electrical contact.
- 2 Replace any wire rope which has had high voltage contact.

Stabilizers

IMT telescopic cranes are mounted on bodies which include stabilizers to stabilize the vehicle during crane operation.



Stabilizers help stabilize the crane and carrier vehicle during a lift, but they can be hazardous due to their close proximity to the operator and other personnel. They are the only component of the crane which normally contact the ground. There are various stabilizer designs available, but all require extreme caution in their use. See figures for proper stabilizer operation sequence and warnings.

Stabilizer Operation:

Make sure the job site is properly prepared as described in the section, *Preparing the Job Site* (on page 13).

Use plates or blocks beneath the stabilizers if they are sinking into the ground. DO NOT use the crane to lift until the stabilizers are properly set up. DO NOT position vehicle near area of uncertain firmness.

1 Prior to setting up the stabilizers, measure the height of the workbench from the ground.


- 2 Extend the rear stabilizer arms (if applicable) completely. If hydraulic, turn on the engine and engage the PTO. The stabilizer hydraulic valves are located inside the crane control cabinet. If the stabilizers are manual, release the locking pin (inside the cabinet) and extend them until they lock into position. You should be able to see the word "Fully Deployed" on the yellow arrow decal on top of the stabilizer arms when the arms are fully extended.
- **3** Lower the rear stabilizer legs until full ground contact is achieved with the truck leveled such that the weight on the springs is relieved enough to raise the workbench approximately 1" (2.54 cm). Set up both rear stabilizers prior to setting the front stabilizers.



- 4 Lower the front stabilizer legs. If the front stabilizer legs do not touch the ground with the rear stabilizers as set in step #3, lower the rear stabilizers until the front stabilizers come in firm contact with the ground, the adjust the rear stabilizers until the truck is level.
- **5** Use a signal person if the stabilizers are not in view from the control station when extending or lowering the stabilizers.

Avoid stabilizer injuries including:

- 1 Hitting people while moving out.
- 2 Crushing people or equipment when contacting the ground.
- **3** Pinching people when being retracted.



Telescopic Crane Controls

Your crane is operated using a fully proportional remote control with a pre-programmed overload protection system. The handheld remote is designed as the primary means for operating the crane. The crane is equipped with a single manual lever (IMT # 70734592) which can be used with the valves to manually stow the crane in case of radio failure.



Crane Operation Using the Proportional Remote

Make sure your work site is set up properly prior to lifting or moving a load. Plan your lift carefully. Do not exceed the rated capacity of the crane. Position the vehicle at your work-site and plan your lift per the instructions in *Preparing the Job Site* (on page 13).


Once your work site is properly set up, use the handheld remote transmitter to operate your crane.

1 Power up your remote control transmitter by turning and pulling out (releasing) the large red E-STOP button, then toggling the Engine Start toggle switch upward for two seconds, then releasing.



Push and hold the trigger on the inside of the remote handle to use the joystick crane controls.

After stowing the crane, or anytime that you will not be operating the crane and wish to continue to have the chassis engine on to run other pto driven equipment, simply leave the transmitter with the E-Stop button in the pulled out/on position. The transmitter will time-out after 15 minutes of inactivity. If the unit powers down due to inactivity, use the ENGINE START switch to re-activate the unit.



2 The left joystick controls the boom up/down, and boom rotation clockwise/counterclockwise functions. The right joystick includes the boom extend/retract and the winch up/down functions. You must hold the trigger to operate the joystick functions. If you hold the trigger for 10 seconds with no joystick operation, the remote will time out due to inactivity, and you must release the trigger then push and hold it again to continue.


After the transmitter is activated, additional functions can be controlled with the toggle switches marked SW1, SW2 and SW3. Switch 1 turns the air compressor on and off. Switch 2 turns the vehicle engine on and off. Switch 3 changes the engine speed from low to high.

ENGINE POWER

Turning off the engine will interrupt all hydraulic power. The crane and any other hydraulic driven component will stop operating.

ACAUTION

The E-Stop should only be used as an emergency stop. Do not use the E-Stop to turn off the radio remote as part of the normal operation. Let the remote time out.



The crane remote includes lights which indicate the following:		
Light	Color	Condition
TX	Green-rapid blinking	Handheld is transmitting.
	Green-solid	Switch active on handheld.
\mathbb{R}	Amber-solid	Output on the receiver is active.
	Red-slow blinking	Low battery
	Amber-solid	Switch fault at power-up
	Amber-slow blinking (1 blink/second)	Machine Stop depressed at power-up.

3 If the engine is not running, the remote can be turned off by pushing in the red E-Stop button or letting the unit time-out automatically after 15 minutes.

If the remote times out due to inactivity, re- activate the transmitter using the Engine Start Switch.

Pushing the E-Stop when the crane is on and the engine or auxiliary power unit is running, will shut down the vehicle engine or auxiliary power unit.

See the *Telescopic Crane Radio Remote System* manual, IMT # 99905114, for complete details on the radio remote system.


Overload Protection System

The crane remote includes lights which indicate the following:			
Light	Color	Condition	
TX I	Green-Rapid Blinking	Handheld is transmitting	
	Green-solid	Switch active on handheld.	
RX	Amber-solid	Output on the receiver is active.	
	Red-slow blinking	Low battery.	
	Amber-solid	Switch fault at power-up.	
	Amber-slow blinking (1 blink/second)	Machine Stop, depressed at power-up	

INTRODUCTION

This crane features an overload protection system with a snubbing feature which slows down the rate of crane operation when the crane reaches 90% of the rated load. The lights on the radio remote transmitter indicate the percent of capacity at which the crane is operating. Once the crane reaches a certain capacity level, the light for that level will illuminate. For example, when the crane reaches 20% of capacity, the 20 light will illuminate, and when the crane reaches 60% of capacity, the 60 light will illuminate. To conserve battery power, only the light which shows the actual capacity will light.

OPERATING SPEED AT 90% CAPACITY




SNUBBING: When the crane reaches 90 percent of rated load (snubbing), the 90% LED will be red and steady. In this situation, the crane operating speed will be reduced by 50 percent for all joystick functions.

To get back to full speed, reduce the load moment on the crane by:

- Raising the boom
- Retracting the extensions
- Lowering the winch

When the load moment is below 90 percent, release the joysticks to neutral to regain full speed.




When the crane reaches 100 percent, the 90% LED will flash red. Once the crane reaches 100%, no crane operations will work except those which reduce the load moment of the crane. When in overload, release the joysticks to a neutral position, then reduce the load moment on the crane by:

- Raising the boom
- Retracting the extensions
- Lowering the winch

The crane will begin to move at a reduced speed once you drop below 100% of the maximum load moment, and at full speed once you drop below 90% of the maximum load moment and have released the joysticks to neutral.

Receiver Display



The receiver, mounted on the side of the crane, includes a display window which lists 3 and 4 character messages indicating various crane operating conditions or when sensors are disconnected. These include:

DISPLAY	EXPLANATION	CONDITION
A2B	A2B Fault	A2B switch is active
OVLD	CRANE OVERLOAD	90% of set point* reached
SNUB	CRANE SNUBBING	80% of set point* reached

	1	
BMDN	BOOM DWN FAULT	No connection
BMUP	BOOM UP FAULT	No connection
BMRT	BOOM RET FAULT	No connection
BMEX	BOOM EXT FAULT	No connection
WNDN	WINCH DWN FAULT	No connection
WNUP	WINCH UP FAULT	No connection
RCW	ROT CW FAULT	No connection
RCCW	ROT CCW FAULT	No connection
ESRT	ENG START FAULT	No connection
ESPD	ENG SPEED FAULT	No connection
ESTP	ENG STOP FAULT	No connection
COMP	COMPRESSOR FAULT	No connection
TRAN	TRANSDUCER FAULT	No connection
NORF	NO RADIO COMM	Loss of Link
LBAT	+ VDC LOWA2B	Input voltage <8V

See the *Telescopic Crane Radio Remote System* manual, IMT # 99905114, for complete details on the radio remote system.

Radio Elimination Cable

The IMT radio remote is equipped with a radio elimination cable for situations where radio communication is prohibited, there is too much interference, or the radio battery is dead. The radio elimination cable plugs into the tethered interface port on the main wiring harness for the crane, which is located at the bottom of the control panel inside the crane box, and into the plug at the bottom of the radio remote transmitter.



Crane Capacity

The IMT crane is designed to lift specific loads. These loads are defined on the capacity placard mounted near the operator's station and on the crane. Exceeding the limits presented on the capacity placard will create severe safety hazards and will shorten the life of the crane. The operator and other concerned personnel must know the load capacity of the crane and the weight of the load being lifted!

The capacity chart for each model is located in the specific crane technical specifications manual and on placards on the crane and body.

Prior to lifting a load:

- **1** Determine the weight of the load.
- 2 Determine the weight of any load handling devices.
- 3 Add the weight of the load and the weight of the load handling devices. The sum is the total weight of the load being lifted. This weight should not exceed the capacity noted on the chart at the position(s) at which the weight will be lifted.

Never exceed the crane's rated load capacities. Doing so will cause structural damage to winches and cables which can lead to death or serious injury.

NOTE


Capacity Placards are intentionally located near the operator to assure ready reference in determining when a load can or cannot be handled.

Load limit information on the capacity placards is formulated on 85% of tipping. Tipping refers to the crane actually tipping with its opposite stabilizer and tires having broken contact with the surface.


- 4 Determine the distance from the centerline of crane rotation to the centerline of the load being lifted.
- **5** Determine the distance from the centerline of crane rotation to the centerline of the point to which the load should be moved.
- 6 Verify that the crane is positioned such that the boom will reach both the starting and ending points.
- 7 Determine the angle at which the crane will be operated (for example, 30° or 45°) by referencing the angle indicator on the lower boom.
- 8 Locate the load distance and angle on the capacity chart on your equipment (Note - chart below is for reference only) and verify that you can lift the load. (Note - Load value determined in step #3 above.)
- **9** Use two-part line for any lift which requires two-part line.

NOTE

The red and silver tape on the boom segments is designed to be used as a boom length indicator decal. Each red segment and each white segment is 6-inches long, so a red and white pair of segments is 1-foot long. By counting the number of red and white pairs, the operator can determine how far the boom is extended. With the crane angle and the boom length, the operator can determine the capacity at a particular reach.



ANGLE INDICATOR



Task Performance

Prior to lifting a load:

- 1 Verify the load can be lifted and moved using the capacity chart.
- 2 See *Telescopic Crane Capacity* (see "Crane Capacity" on page 24)


To operate the crane:


- 1 Position the crane as close to the job as possible on a firm, dry and level surface. Avoid overhead obstructions on the work side of the unit.
- 2 Set the auxiliary (parking) brake.
- 3 Depress the clutch pedal. Shift the transmission into neutral and engage the PTO.
- 4 Operate the throttle control to achieve the proper engine speed.
- **5** Before conducting any boom operations, extend both stabilizers and level the crane side to side. Provide blocks if necessary to level the unit on sloping ground or bearing pads if the stabilizers tend to sink into soft terrain or hot asphalt. Some concrete or asphalt surfaces are relatively thin and cannot withstand the stabilizer loading. Concrete can break through and cause instability.

Avoid injury or equipment damage! Do NOT attempt to handle a load if the stabilizers are unable to make solid contact with the ground.

Stability over the front (without front stabilizers) can be hampered by raising the vehicle excessively. Use extreme caution when operating in areas around the truck which are not supported by stabilizers because of cushion of tires and springs. When swinging loads from areas supported by stabilizers, use extreme caution because of potential sudden shifting of the support point. Always keep the load as close to the ground as possible.

- 6 Raise the lower boom.
- 7 Rotate the boom to the selected location. Release the hook prior to operating the winch or extension boom. Extend the winch cable and lower the hook block so there is sufficient cable to allow for extended boom length before extending any telescoping boom sections. See *Auto-Release Hook Storage* (on page 30).





Anti-Two Block System

"Two-blocking" is the condition when the lower load block or hook assembly contacts the boom tip sheave assembly. IMT cranes all have anti-two block systems which prevent two-blocking and the subsequent winch cable and sheave damage it can cause.

The anti-two block system on IMT telescopic cranes helps prevent cable damage by sensing the position of the winch cable end attachments and shutting down the functions that cause two-blocking, which are the winch retract function, boom extend function, and lower boom down function. When there is any upward movement of the anti-two-block bracket toward the boom tip, contact to the microswitch will be broken. The lower boom down, extension boom extend, and winch up functions will be shut down until the winch cable is extended and microswitch contact is restored.


Check the anti-two-block system daily using as follows:

- 1 Examine the weldment to insure free and unrestricted mechanical operation.
- 2 Examine cord for damage, cuts or breaks. Grasp cord and pull to check operation of cord reel. The cord should retract into the reel when released.
- **3** With your hand, push the anti-two-block weldment up toward boom tip. You should hear an audible click from the microswitch when the contact is broken.
- 4 Test the two-block system. Following proper operating procedures,
 - a) Lift the boom from the saddle.
 - b) Extend the winch cable to disengage the hook from the stowed position.
 - c) Retract the winch cable until the snatch block contacts the anti-two-block weldment. When this occurs, all winch motion should stop.
 - d) Relieve the two-block condition by extending the cable or retracting the extension boom.
 - e) Test again with the lower boom down function. When the snatch block contacts the anti-two-block weldment, the lower boom down function should stop.
 - f) Relieve by raising the lower boom.

If the anti-two-block function appears to be functioning normally, winch the cable down until the snatch block swings free.

Auto-Release Hook Storage

This crane includes a hook storage bracket featuring a gravity hook release which functions once the boom is elevated to an angle above 60 degrees. The bracket has a nub which will prevent the hook from slipping off inadvertently, but when the operator raises the boom past 60 degrees above horizontal and releases some winch cable, the hook can slide off the bracket. Then the operator can further extend the cable to hook on a load.



Winch

IMT telescopic cranes are equipped with winches and wire ropes designed to be used to lift a load up and down once the boom(s) are positioned and extended as desired. The winch is powered by a hydraulic motor which drives a planetary gear box. Winch speeds and specifications vary by crane model, and specific details on the winch specifications are listed in the parts/specifications manual for each crane. The winch is equipped with a wire rope of varying length, also based on the crane model. An anti-two block device is included to prevent the lower block or hook assembly from coming in contact with the boom sheave assembly.

ACAUTION

- Avoid anti-two blocking the crane! Release sufficient wire rope before extending the crane boom.
- Avoid equipment damage and wire rope stress. Do not use the winch to drag a load.

When using the winch, keep the tip of the boom as close to the load as possible to prevent unnecessary swing. To dampen excess swing, rotate the crane in the direction of the swing. Keep three (3) full wraps of wire rope on the winch drum at all times.

WARNING Whipping Cable or Falling Load Hazard

- Inspect and replace damaged cable before use. To avoid cable damage:
- Set hook securely and take up cable slowly.
- Never cross cable on drum.
- Never wrap cable around objects. Use chains.
- Keep tension on cable when unwinding.
- Never exceed capacity of rigging or cable.
- Operate boom with winch in "free-spool" mode only.
- Whipping cable or falling loads will injure or kill.

WARNING Whipping Cable Hazard


- Keep people away during operation.
- Never exceed capacity of rigging or cable.
- Never stand on or straddle cable.
- Stop pull before hook contacts boom end.
- Always keep three (3) wraps of cable on drum.
- Whipping cable will injure or kill.

Flip Sheave Feature

This crane features a standard flip sheave at the end of the boom. Flipping the sheave to the upward position reduces the height of the end of the boom and allows crane use in smaller spaces.

With the flip sheave in the downward position, the locking pin goes into position #1. To extend the sheave,

- 1 Remove the locking pin from position #1.
- 2 Raise the sheave. Use the anti-two-block weldment as a handle, if desired.
- 3 Lock the pin into position #2 to hold the sheave in place.




NOTE

If you need to use the flip-sheave feature with the crane boom angle above 60 degrees, IMT recommends using a single-part line. See instructions to change to single part line if needed.

Double & Single Line

Your crane can be operated with two-part or single-part line. Single-part line gives you a longer load distance and faster line speed. Double-part line offers greater lifting capacities. When using double-part line winch operation at angles above 60°, make sure the flip sheave is down. If you require a longer load distance or a faster line speed, first check that you have the capacity to lift your load using single part line. If you do, change the crane to one part line using the following procedure.

- 1 Disconnect the two-part line load support pin which holds the hook/snatch block assembly in place. Store the pin and snatch block in the cab or crane box.
- 2 Disconnect the two-part line anchor pin.
- 3 Remove the downhaul weight from the crane boom.
- 4 Slide the downhaul weight onto the wire rope below the locking collar. Drop it into place on the hook.
- 5 Lift your load. When finished, return the boom tip to two-part line or stow the snatch block and pin.



Load Level Indicator

IMT equipment features a level which can be used to determine if the truck is level, side to side, before using the crane. The level, part number 72042097, is mounted in the crane compartment on IMT bodies.



Options

The wiring harness on this crane is pre-wired for several options, including:

- Boom tip flood light
- Stow sensor which will indicate when the crane is fully stowed
- Cable unwind prevention system, which will stop winch function when 2-1/2 wraps of wire rope remain on the winch spool. This will prevent the cable from completely unwinding and the load falling.


Although these options are not included on every crane, they can be easily added as they are already wired into the main harness.

Emergency Manual Operation

If your radio remote fails, you may have to manually stow the crane for service or transport. The emergency manual controls are located on the valves at the rear of the crane.

To use the emergency manual controls,

- 1 Remove the valvebank cover.
- 2 Install the handle which was shipped with the crane into top of the valve which controls the desired function. (IMT # 70734592)
- 3 Push or pull the handle to operate the function.



The manual controls are for emergency operation only. Use them ONLY to stow the crane for service or transport.

Crane Shut Down

- 1 Retract the extension booms and winch cable.
- 2 Secure the hook.
- **3** Stow the equipment in its travel configuration. Use the boom support located on the bed of the vehicle. Make sure the winch line is *slack*. After stowing, tighten the winch line just enough to keep the cable from contacting the boom.

ACAUTION

Excessive pressure on the boom support may damage the boom support or the body.

- 4 When the boom is in the transport position, toggle the lower and extend functions on the handset to relieve any trapped pressure. This will prevent the boom from bouncing out of the boom support during transit.
- 5 Stow the stabilizers.
- 6 Disengage the throttle control.
- 7 Depress clutch pedal (if applicable) and disengage PTO.
- 8 Shut off the truck engine using the *Engine Stop* function on the remote.
- 9 Secure loose items on truck bed.
- **10** Release the auxiliary brake.

Watch for highway height and length restrictions, and follow all highway regulations.

Troubleshooting

Problem	Cause	Resolution
Vehicle tires sink into ground.	Unstable work area.	Reposition truck or use blocks.
Crane does not work.	Hydraulic system. Check if the stabilizers work.	If the stabilizers work, the crane has hydraulic power. Check the electrical system.
		If the stabilizers don't work, the crane does not have hydraulic power. Check the pump and make sure the PTO is engaged to power the crane hydraulic system.
	Electrical system.	Check the receiver panel for lights. If there are no lights, check wiring.
Radio remote does not work.	Emergency stop button is pushed in.	Pull out e-stop button.
	Remote battery is dead.	Replace with fully charged battery.
	Error code on receiver.	Use <i>SIII Receiver Display</i> (see "Receiver Display" on page 22) receiver display guide to determine and resolve error cause.
	Radio interference	Connect radio elimination cable between transmitter and crane wiring harness for tethered operation.
Crane functions operate slowly.	If the red 90% light on the radio remote is on and steady, the crane is approaching overload. (Snubbing)	Raise the boom, retract the extension, or lower the winch to reduce the load moment on the crane. Release the joysticks to neutral to regain full speed.
Crane functions including boom down, extension out, and winch up do not work.	If the red 90% light on the radio remote is on and flashing, the crane is in overload.	Raise the boom, retract the extension, or lower the winch to reduce the load moment on the crane. Release the joysticks to neutral to regain full speed.
	Crane is in two-block condition.	Winch down to relieve the two- block condition.

Problem	Cause	Resolution
Winch won't lift heavy loads.	Too much load.	Rig to reduce load on winch.
	Low or no gearbox oil	Check oil level in winch. Add proper oil if necessary. See <i>Winch Oil Specifications</i> (on page 49).
	Leaks.	Determine if the leak is from the winch or hydraulic motor. Add winch oil or hydraulic motor oil.
	Check flow to winch motor with winch under load.	Test pump if not to specification.
Winch runs too slowly.	Motor worn.	Replace motor.
Winch won't run under load.	Motor seized.	Remove motor from winch. Test if operable. If not, replace.

Operation in Adverse Conditions

Operating your crane in adverse weather conditions can affect the crane performance. Please note the following operation procedures for adverse weather conditions.

- 1 Dusty and Sandy Areas Operating in dusty or sandy areas presents special problems due to the abrasive action of dust which shortens the life of parts. Make every effort to keep dust and sand out of the moving parts of the crane machinery and engine. Keep lubricants clean, and lubrication and fluid fill areas capped tightly.
- 2 High Humidity and Salt Air Moisture and salt will cause deterioration of paint, cables, wiring and all exposed metallic parts. Keep parts dry and well lubricated in high humidity or salt air conditions. Keep parts thoroughly lubricated, and remove rust and corrosion if and when it appears.
- **3** High Altitudes Operation at high altitudes presents special problems due to lower atmospheric pressure and wide temperature ranges. Consult the vehicle owner's manual regarding operating the vehicle at high altitudes.

Cold Weather

For cold weather operation with temperatures of -25° F or lower, the following procedures must be followed:

- 1 Start the truck and run at manufacturer's recommended idle speed for proper warm up.
- 2 After approximately 45 minutes of truck warm up time, engage the PTO.
- 3 With manual transmissions only, at engine idle, release the clutch pedal until the PTO is fully engaged.

4 With the PTO fully engaged and the truck engine running at idle speed, let the hydraulic system oil circulate.

Avoid pump cavitation and potential permanent damage! During the 45 minutes allowed for warm up, do not race the truck engine and overspeed hydraulic pumps.

If at any time during oil circulation, and especially during the initial warm up time, any hydraulic pump noise such as metal grinding, or a popping noise is heard, shut down the unit immediately. Check that the hydraulic oil line leading to the suction port on the pump is not clogged, or that the hydraulic oil itself has not jelled.

For crane operation in temperatures below -25°F, use hydraulic oil conforming to MIL-L-46167. For winch operation in temperatures below -25°F, change the lubrication oil in the winch gearbox to oil which conforms to MIL-L-2105C, Grade 75W (GO-75).

After the 45 minute warm up period, begin crane operation as follows:

- a) Slowly extend stabilizers approximately 6 inches and retract, extend out again approximately half way and retract, and then extend fully.
- b) Deploy the crane raising the lower boom.
- c) Rotate the crane slowly, approximately one eighth revolution one way, return to previous position and rotate in opposite direction. Do this several times, then rotate 90° and return.
- d) Raise the lower boom, deploy the hook, then begin winch operation by slowly lowering and raising the hook.
- e) With sufficient loadline, extend and retract the extension boom. Repeat several times allowing longer operation intervals.

Engage valves slowly during warm-up cycle to prevent sudden hydraulic spikes which will damage hydraulic components.

NOTE

It is normal for some oil seepage to occur around piston rod seals during the warm-up operation. Seepage should cease when hydraulic system has reached operating temperature.


Signals

Per OSHA 1926 Subpart CC, signals must be used when the operator's view of the load is obstructed or when the operator or the person handling the load determines signals are necessary. Operator signals may be by hand, voice, audible, or by some other agreed-upon method.


Standard hand signals are in this manual. See the hand signal chart.

Voice or audible signals, whether spoken, radio, telephone, or some other signal method, are acceptable signaling methods, but the signal method must be tested prior to commencing crane operation.

See ANSI B30.5 and OSHA 1926 Subpart CC for more information on signals.



EMERGENCY STOP- Both arms extended, palms down, move arms back and forth horizontally.



STOP- Arm extended, palm down, move arm back and forth horizontally.



MOVE SLOWLY- One hand gives any motion signal; place other hand motionless in front of that hand. (Hoist slowly shown.)



USE MAIN HOIST- Tap fist on head; then use regular signals.




EXTEND BOOM- (Telescoping Booms) One Hand Signal. One fist in front of chest with thumb tapping chest.



HOIST- With forearm vertical, forefinger pointing up, move hand in small horizontal circles.




SWING - Arm extended, point with finger in direction of boom swing.



EXTEND BOOM- (Telescoping Booms) Both fists in front of body with thumb pointing outward.



USE WHIPLINE- (Auxiliary Hoist) - Tap elbow with one hand; then use regular signals.



TRAVEL- Arm extended forward, hand open and slightly raised, make pushing motion in direction of travel.



LOWER- With arm extended downward, forefinger pointing down, move hand in small horizontal circle.



RETRACT BOOM- (Telescoping Booms) Both fists in front of body with thumbs pointing inward.



LOWER BOOM - RAISE LOAD Arm extended, thumb pointing down, flex fingers in and out until desired movement is completed.



LOWER BOOM - With arm extended, fingers closed, thumb pointing downward.



RAISE BOOM - With arm extended, fingers closed, thumb pointing upward.



RAISE BOOM - LOWER LOAD Arms extended, thumb pointing up flex fingers in and out until desired movement is completed.



RETRACT BOOM - (Telescopic Booms) - One Hand Signal. One fist in front of chest, thumb pointing outward and heel of fist tapping chest.

$C \ \text{H} \ \text{A} \ \text{P} \ \text{T} \ \text{E} \ \text{R} \quad 3$

Maintenance

In This Chapter

Maintenance Introduction	
Maintenance Schedule	
Greasing Instructions	
Hydraulic Fluid Level	
Crane Hydraulic Oil Specifications	45
Changing Hydraulic Oil & Filter	46
Purging Air from Hydraulic System	
Hydraulic Pressure Relief	
Hydraulic Cylinder Holding Capability	
Winch Oil Specifications	
Wire Rope & Hook Maintenance	
Periodic Inspection	
Additional Inspection	
Corrosion Control	
Long-Term Storage	
C	

Maintenance Introduction

To obtain reliable and satisfactory service, IMT telescopic cranes require a consistent preventative maintenance schedule. Take necessary safety precautions during maintenance procedures to avoid equipment damage and personal injury. Follow the maintenance schedule included with this manual for best results.

- 1 Maintenance should only be performed by authorized service personnel.
- 2 Disengage the PTO before any service or repair is performed.
- 3 DO NOT disconnect any hydraulic components or hoses while there is pressure in those components.
- 4 Stand clear of high pressure hydraulic fluid leaks. Hot hydraulic fluid will cause serious injury, burns and possibly DEATH.
- 5 Keep the crane clean and free from built-up grease, oil and dirt to prevent slippery conditions and as an aid in the inspection of the crane.
- 6 Perform all checks before each period of use.
- 7 Replace parts with factory approved parts, only.
- 8 Repair or have repaired any components found to be inadequate, immediately

Maintenance Schedule


Detailed steps on numerous maintenance procedures are described in the following pages. Use the following chart to help you determine the time schedule of the maintenance requirements.

TIME FRAME	MAINTENANCE STEP	REFERENCE
Weekly	Lubricate:	Greasing Instructions
	Grease Zerks	
	Hinge Pins	
	Turntable Bearing	
	Grease:	
	Worm Gear Teeth	
Monthly	Complete all required monthly inspections. (See IMT Inspection Checklist in the General Reference section of this manual.)	
After the first 50 hours of service	Change hydraulic filter.	Dominator manual.
Quarterly	Lubricate worm gear bearings.	Greasing Instructions
	 Complete all required quarterly inspections. (See IMT Inspection Checklist in the General Reference section of this manual.) 	
Every 6 months or 800 hours	Purge hydraulic system and replace hydraulic oil and filter.	Changing Hydraulic Oil Changing Hydraulic Filter
Every year	Replace winch oil.	Winch Oil Specifications
	 Complete all required annual inspections. (See IMT Inspection Checklist in the General Reference section of this manual.) 	(on page 49)
Every 2 years	Inspect pins.	Pin Removal & Inspection

Greasing Instructions


Different lubricants are required for different sections of your crane. Contact your lubricant supplier for specific product information. Follow the grease and lubricant specifications and intervals listed in this manual for best results.

Crane grease zerks must be greased on a weekly basis during normal operating conditions. Under severe operating conditions the zerks must be greased more frequently. Each grease zerk is marked with a decal, "Grease Weekly", as shown. Rotate the worm gear bearing when greasing the worm gear bearing grease zerks.



Crane worm gear bearing teeth must be lubricated weekly with extra heavy lubri-plate gear shield or equivalent. Cover all teeth with grease and leave no exposed metal surfaces showing.

Weekly, remove cover and lubricate with IMT recommended open-gear compound while rotating crane. IMT part number: 89086244



LOCATION	LUBRICANT	APPLICATION METHOD	FREQUENCY
Base - Turntable Bearing Grease Zerk Flip Sheave Pin Snatch Block Pin Worm Gear Bearings Grease Zerks (*Rotate crane while greasing)	Extreme Pressure Lithium Grease such as Shell Alvania 2EP, Shell Retinax "A", Mobilgrease XHP 462, Cenex ML 365, Xtreme True-Flo MP EP2 Lithium Grease or equivalent.	Apply with hand or pneumatic pressure grease gun.	Weekly
Rotation Worm Gear Teeth	Molub-Alloy 882 Heavy or equivalent	Brush or spray on.	Weekly

New Crane Rotator Worm Gear Break-In Period

Per the *Greasing Instructions*, the rotator worm gear must be greased weekly with molybdenum disulfide grease. (IMT uses Keystone Moly29 Open Gear Compound when building the crane.)

Brush on the molybdenum disulfide grease liberally on the worm gear teeth before turning the rotator. Cover all teeth with grease and leave no exposed metal surfaces showing. The first rotations of the rotator may be rough and have a scraping sound. This is normal, as the gear and worm are breaking in and will smooth out with continued use. The break-in time varies based on load moment, cycles of use, slope of boom tilt, etc.


IMT recommends running the system 10 to 15 cycles with a light load, 10 to 15 cycles with a medium load, and finally 10 to 15 cycles with a heavy load.

During the break-in period, small shavings of metal may appear in the grease. If this occurs, the grease with shavings should be removed from the gear, and new grease should be applied. This will improve rotation system performance for the life of the system.

Hydraulic Fluid Level

Check the hydraulic oil level daily using the following procedure:

- 1 Check the oil level using the dipstick in the oil reservoir.
- 2 If the hydraulic oil is below the fill line on the dipstick, add oil. Use the *Hydraulic Fluid Specifications* (see "Crane Hydraulic Oil Specifications" on page 45) chart to select the appropriate hydraulic oil.



Crane Hydraulic Oil Specifications

The hydraulic oil for your crane must be ISO VG32, low pour, anti-wear hydraulic oil. IMT recommends SAE oil based on the following temperature ranges:

SAE #	TEMPERATURE RANGE	NOTE: Mot specificatio nydraulic crane is ma	ns and oil used	when the
5W-20	-10 to 180° F (-23 to 82° C)	lowa Mold Too	oling Co., Inc.	
10W	+10 to 180° F (-12 to 82° C)	Garner, Iowa USA 641-923-3711	4 Q	
10W-30	+10 to 210° F (-12 to 99° C)			SERVOIR
		HYDRAULIC		IENT URE RANGE
		OIL	۴F	°C
		ISO 32	0° to 90°	-18° to 32°
		ISO 15	Below 0°	Below -18°
		ISO 46	Above 90°	Above 32°
		For Arctic condit	ions, consult yo	our oil supplier.


Changing Hydraulic Oil & Filter

Replace the hydraulic oil and filter every 6 months.

Purging the system requires a new oil supply sufficient to completely fill the reservoir, lines, cylinders, etc., and an extra quantity for loss during this procedure. To minimize oil loss during this process, operate the truck engine at low RPM.

Two operators are required during the purging operation: one to operate the crane controls and the other to regulate pump output (engine speed).

- 1 Locate the truck in an area with solid footing and space to accommodate the full operating range of the crane.
- 2 Stabilize the crane with the stabilizers. Move the crane to 90° on either side of the truck. Extend the lower and extension cylinders.
- **3** Disengage the PTO, drain the hydraulic oil reservoir, and drain all hoses. Disconnect the pressure hose from the pump, drain and reassemble. Reassemble the system.



4 Remove the reservoir return line. Direct flow into a sump or waste container. Plug the drain port on the reservoir and fill with new oil.

NOTE

Read and follow the following instructions without interruption or stop the engine at the end of each step. If this is not done, excess oil will be discharged through the disconnected valve bank return hose.

- **5** Start the truck engine and engage the PTO. Rotate the crane 90°, retract the extension boom and lower the main boom to the lowest position.
- 6 Return the crane to its stowed position as marked on the rotation system. Raise the stabilizers. Shut off the engine.
- 7 All components of the system are now purged. Replace the hydraulic filter (located) under the fill cap in the body.
- 8 Check hydraulic oil level. Top off if necessary.

Purging Air from Hydraulic System

Air trapped in the hydraulic cylinder will cause an erratic "bumpy" motion. To expel the air:

- 1 Hold the control open for a few seconds after the function has "bottomed out".
- 2 Move the function in the opposite direction. Again, hold the control open a few seconds after the function has "bottomed out".
- 3 Attempt to operate the crane in the normal manner to determine if the air has been purged.

Hydraulic Pressure Relief

The hydraulic system relief valve is provided to prevent the user from placing too much strain on the hydraulic components. The system relief pressure is preset and sealed at the factory, and it must not be tampered with. If you suspect the system relief pressure of malfunctioning, see your IMT dealer for testing and replacement.

Setting the pressure relief higher than the specification for your model crane is unsafe. DO NOT ATTEMPT. Excessive relief pressure will damage the equipment and can result in injury or death. Only an authorized IMT representative may adjust the relief pressure and reseal the relief valve. A broken seal on the relief valve will void the warranty.

Hydraulic Cylinder Holding Capability

The hydraulic cylinders have holding valves that prevent sudden movement of the cylinder rods in the event of a hydraulic hose or other hydraulic component failure. The valves are non-adjustable and failure is unlikely.

Check the hydraulic cylinder using the following steps:

- 1 With a full rated load, extend the cylinder in question and kill the engine.
- 2 Operate the control valve to retract the cylinder. To check the main (lower) cylinder, set the boom horizontally with the maximum load. To check the extension boom cylinder, set the crane at maximum articulation (angle).

If the cylinder "creeps", replace the holding valve. If the cylinder does not "creep", the valve is serviceable.

Winch Oil Specifications

The use of proper gear oil and regular preventive maintenance will help extend gear train life and reliable winch brake performance.

Oil Change Frequency

Gear oil should be changed after the first 100 hours or 30 days of machine operation, and then every 1000 hours or 12 months, whichever occurs first. Gear oil should also be changed whenever the ambient temperature changes significantly and an oil from a different temperature range would be more appropriate. Check and drain the oil using the fill plug in the winch. The winch should be at least 1/2 full.

Warm-Up Procedure

Warming up the winch is recommended at start-up and at ambient temperatures below 40 °F (4 °C). Run the prime mover at its lowest recommended RPM with the hydraulic winch control valve in neutral, allowing sufficient time to warm up the system. Operate the winch at low speeds, forward and reverse, several times to prime all lines with warm hydraulic oil and to circulate gear oil through the planetary gear sets.

Lubricants

The following lubricants are recommended based on ambient temperature. Other lubricants may work equally as well. We suggest you work with your lubricant supplier to find an equivalent product if needed. The winch is initially filled with Exxon Spartan EP150 or equivalent.

Prevailing Ambient Temperature	Recommended Lubricant
25 -130 °F (-4 - 54 °C)	Exxon Spartan EP220 or equivalent (AGMA 5 EP, ISO VG 200)
10 - 100 °F (-12 - 38 °C)	Exxon Spartan EP 150 or equivalent (AGMA 4 EP, ISO VG 150)
	<i>Note:</i> Avoid using Exxon Spartan EP150 above 80 °F (27 °C) in severe applications such as offshore lifting, sustained fast duty cycles, or frequent lifting.
-25 - 130 °F (-32 - 54 °C)	Mobil SHC 629 or 630 synthetic or equivalent

Wire Rope & Hook Maintenance

Wire Rope Inspection

OSHA requires regular inspections and permanent, signed record-keeping on wire rope inspections. These inspections help the crane operator determine whether the rope can be safely used. Inspection criteria, including number and location of broken wires, wear and elongation, have been established by OSHA, ANSI, ASME and similar organizations.

WIRE ROPE INSPECTION CRITERIA

- 1 INSPECTOR The wire rope inspector must keep written reports of the rope condition on file at the work site and must have the authority to order wire rope replacements and keep unsafe wire rope from being used.
- 2 PERIODS OF INSPECTION Set up inspection periods for each material hoist wire rope. Determine inspection frequency by considering environment, degree of hazard to materials, frequency of operation and the frequency with which the wire rope is subjected to its capacity limits. Inspect at least every 30 days.
- 3 METHODS OF INSPECTION To inspect, unwind the working length of the wire rope from the hoist drum. Thoroughly inspect the rope sections that pass over sheaves, drums or contact saddles or which make opposing turns. Inspect the rope close to the end attachments. DO NOT open the rope for inspection.
- **4** USED WIRE ROPE Thoroughly inspect used wire rope prior to installation.
- 5 IDLE EQUIPMENT Inspect wire rope on idle equipment prior to operation.

DAILY INSPECTION: Inspect for kinking (sharp bends), crushing, unstranding, birdcaging, core protrusion, rope diameter loss, rope strand unevenness, general corrosion, broken or cut strands, heat damage, and integrity of end attachments.

MONTHLY INSPECTION: Each month, inspect the entire length of the rope, the wire rope eye, and the sheaves, drums and other apparatus with which the rope makes contact.

When a wire rope has been removed from service because it is no longer suitable for use, it must not be re-used on another application. Every wire rope user should understand that each type of fitting attached to a wire rope has a specific efficiency rating which can reduce the working load of the rope assembly or rope system, and this must be given due consideration in determining the capacity of a wire rope system.

Wire Rope Lubrication

Wire rope used on IMT cranes does not have continuous lubrication replenishment. Use open gear lubricant to protect the wire rope on your crane. The areas of rope which experience the most wear are located over sheaves or are otherwise hidden, and these areas require the most rope lubrication.

Lubricate the wire rope using ChainMate[™] Chain and Wire Rope lubricant, Vitalife® 400, or equivalent. To lubricate the rope:

- 1 Clean dirt, dust, and foreign matter from the rope.
- 2 Apply ChainMate lubricant or equivalent, penetrating the strands of the rope. Apply according to the lubricant specifications.
- 3 Apply lubricant heavily to portions which encounter bending such as at the sheave and winch.

Wire Rope Maintenance

If the daily wire rope inspection shows a problem with the wire rope, the rope must be repaired or replaced. Use only original wire rope from IMT. Failure to do so may cause problems with the anti-two-block system and the downhaul weights.

Wire Rope Inspection & Replacement

Wire rope with any of the deficiencies shown below shall be removed and replaced immediately.


- **a** Corrosion can be cause for replacement. Any development of corrosion must be noted and monitored closely.
- **b** When there are either three broken wires in one strand or a total of six broken wires in all strands in any one rope lay.




c When flat spots on the outer wires appear and those outside wires are less than 2/3 the thickness of the unworn outer wire.



d When there is a decrease of diameter indicating a core failure.



e When kinking, crushing, birdcaging or other distortion occurs.



f When there is noticeable heat damage (discoloration) of the rope by any means.



g When the diameter is reduced from nominal size by 1/32" (0.8 mm) or more.



h If a broken wire protrudes or loops out from the core of the rope.



Wire Rope Slings

Rated load (rated capacity) of a wire rope sling is based on the nominal, or catalog strength of the wire rope used in the sling, and factors which affect the overall strength of the sling. These factors include attachment or splicing efficiency, the number of parts of rope in the sling, type of hitch (straight, choker, basket), diameter around which the body of the sling is bent, and the diameter of hook over which the eye of the sling is rigged.


Rated load of a sling is different for each of the three basic methods of rigging. These rated loads are available from your wire rope sling supplier and may be indicated on a tag attached to the sling at the time it is fabricated.

A hand-tucked eye splice can unlay (unravel) and fail if the sling is allowed to rotate during use.

- Never shock load a sling. There is no practical way to estimate the actual force applied by shock loading. The rated load of a wire rope sling can easily be exceeded by a sudden application of force, and damage can occur to the sling. The sudden release of a load can also damage a sling.
- Protect the body of a wire rope sling using corner protectors, blocking or padding against damage by sharp edges or corners of a load being lifted. Sharp bends that distort the sling body damage the wire rope and reduce its strength.

- Any angle other than vertical at which a sling is rigged increases the loading on the sling.
- Visually inspect a sling before each lift or usage to determine if it is capable of safely making the intended lift in the same method as inspecting a wire rope.
- If a sling is found to be deficient, the eyes must be cut, or other end attachments or fittings removed to
 prevent further use, and the sling body discarded.
- Never use a sling eye over a hook or pin with a body diameter larger than the natural width of the eye. Never force an eye onto a hook. The eye should always be used on a hook or pin with at least the diameter of the rope.


Wire Rope Lay





LEFT LAY


Wire rope "lay" indicates the directions strands lay in the rope - right or left. When you look down a rope, strands of a right lay rope go away from you to the right, like a right hand screw thread. Left lay is the opposite, and corresponds to a left hand screw thread.

You must choose the correct lay for your winch drum to avoid winch spooling problems and rope which does not lay correctly. Use the following graphics to help in selecting the correct wire rope based on the direction of drum winding.









RIGHT LAY-OVERWIND RIGHT UNDEF

UNDERWIND

LAY- LEFT LAY-OVERWIND

LEFT LAY-UNDERWIND

Hook Maintenance

Swivel type crane hooks must be kept lubricated. Most swivel hooks provide a grease fitting for application of lubricant to the swivel bearing.

If a crane latch becomes inoperative because of wear or deformation, it must be repaired before the hook is put back into service. It may be necessary to wire closed, or "mouse", the latch until the latch can be repaired.

Make certain that wedge socket or cable thimble attachments are secure and that wire rope clips are torqued to manufacturers specifications, lubricated and functioning properly.

Periodic Inspection

The Crane Inspection Checklist, included in the Reference Section, is designed to assist you in maintaining the crane in safe operating condition. Become familiar with the checklist prior to operating the crane, and inspect to the instructions shown on the checklist.

ANSI/ASME B30.5 requires that written, dated, and signed inspection reports and records must be maintained monthly on critical items including the brakes, crane hooks, hydraulic cylinders, and hydraulic pressure relief valves.

NOTE
A Crane Log manual, IMT # 99900686, is
available from IMT. The Crane Log provides a
convenient and precise inspection recording
method.

In addition, it is important to maintain the carrier vehicle in safe operating condition. Inspect the vehicle in accordance with the vehicle manufacturer's recommendations. Consult the documentation which accompanied your vehicle.

Additional Inspection

Every three months, and more frequently when the equipment is subject to heavy usage, perform the following inspections in addition to those specified in the Crane Inspection Checklist in the Reference Section.

LOWER AND EXTENSION BOOMS

- 1 Check structural defects evidenced in weld cracks, dents or bends.
- 2 Check slide pads for wear.
- **3** Check lower and extension cylinder pins for proper installation. Check hinge pin bushings for excessive wear.

BOOM & MAST ASSEMBLY

- 1 Check control valvebank and all other fittings for oil leaks and tightness.
- 2 Check all bolts and retainer plates on pin assemblies for proper installation.
- **3** Check torque on all unit mounting bolts. See the installation drawing in the crane parts manual for mounting bolt torque.
- 4 Check for loose bolts, fatigue cracks or corroded structural members.

BASE ASSEMBLY

- 1 Check base casting housing for cracks.
- 2 Check for proper rotation function by making several start-stop operations. Maximum allowable freeplay at mast front should be 3.2 mm (1/8") to 4.8 mm (3/ 16").

3 Check for proper gear mesh in turntable gear-bearing. Check motor and gear-mounting bolts for tightness.

HYDRAULIC SYSTEM

- 1 CYLINDERS
 - a) Check rods for damage such as scarring, nicks, dents and rust on out-of-service units.
 - b) Check for leaks at weld joints and rod seals. Check for drift indicating leakage around piston rings or defective holding valves.
 - c) Check extension cylinder head and piston positions.
 - d) Check cylinder case for dents.
- 2 HYDRAULIC PUMP
 - a) Check for leaks at shaft seal.
 - b) Check for drop in operating speed.
 - c) Check hydraulic oil for excessive heating.
 - d) Check bolts and fasteners for tightness.
 - e) Note any unusual vibration or noise.
- 3 PTO & PUMP
 - a) Inspect for proper transmission gear to PTO engagement.
 - b) When supplied, inspect driveline U-joints for securing cap tightness and adequate lubrication.
 - c) Check mounting bolts on pump and PTO for tightness.

Corrosion Control

IMT treats metal to metal surfaces and hardware on new cranes with Cortex VCI-389, a chemical for rust prevention. Surfaces sprayed with Cortex VCI-389 will have a slight yellow or cream color. The discoloration can be removed with a degreaser or citrus cleaner.

Cortex VCI-389 prevents rust for about one year from application. It can be reapplied after crane disassembly or cleaning for continued rust prevention.

In addition, to ensure the life and appearance of the crane, which includes booms, hydraulic hoses, rotation bearings and rotation gearing, the crane must be thoroughly washed and lubricated after performing job functions in harsh environments, such as dirt, sand, salt water spray, etc. If this maintenance step is neglected, you run the risk of shortening the life of the crane through corrosion and abrasion. After a thorough washing, refer to the Lubrication Products & Schedule, for proper maintenance as scheduled.

Long-Term Storage

When a crane is put into long term storage, it should be stored within a controlled environment. To prolong the life of hydraulic system seals, o-rings, hoses, filters and pumps, the crane must be operated and maintained on a regular basis. If this maintenance is neglected, hydraulic system components will dry out which will require extensive repair and expense. IMT recommends the crane be operated, with all functions cycled fully as in normal operation, at least every three months. The climate in which the crane is stored may dictate more frequent operation to prevent component deterioration.

CHAPTER 4

Repair

In This Chapter

Repair Precautions	
Systematic Repair Procedure	
Associating Radio Remote Receiver and Transmitter	59
Wear Pads	60
Cylinder Repair	61
Pin Removal & Inspection	61
Bushings	63
Wire Rope Removal & Replacement	63
Turntable Bearing Inspection	64
Turntable Bearing Tilt Test	64
Turntable Bearing Thread Tightening Sequence	65
Turntable Bearing Worm End Play & Backlash	66

Repair Precautions

Maintaining your crane regularly keeps the crane operating safely.

Prior to starting repairs on your crane:

- **1** Park the crane in an area where other equipment is not operating and where there is no through traffic.
- 2 Set the carrier vehicle's parking brake. Use wheel chocks to prevent vehicle movement.
- **3** Position the crane in its stowed position if possible, or with the boom supported to prevent boom collapse during maintenance.
- 4 Place all controls in the "OFF" position and disable any means of starting the carrier vehicle or powering the crane.
- **5** Disconnect the PTO.
- 6 Secure sheaves and/or load blocks so they will not swing or fall during maintenance.
- 7 Relieve the hydraulic oil pressure from all circuits before disconnecting any hydraulic fittings or components.
- 8 Replace any parts with only factory approved replacements.

Prior to putting your crane back into service:

- 1 Replace all shrouds, guards and safety devices removed during maintenance.
- 2 Remove all trapped air in the hydraulic system to prevent erratic operation.
- 3 Clean grease and oil from controls.
- 4 Make certain all decals are present and legible.
- 5 DO NOT return to the worksite until all repairs are proven to be in proper working condition.

Systematic Repair Procedure

- 1 Begin repairs by studying the hydraulic schematics and systematically approaching the problem.
 - Locate the source of the problem.
 - List possible causes.
 - Devise checks.
 - Conduct checks in a logical order to determine cause.
 - Consider the remaining service life of components against the cost of parts and labor needed to replace them.
 - Make the necessary repair(s).
 - Re-check to be sure nothing has been overlooked.
 - Functionally test the new part.

2 If you cannot determine or correct the problem, contact your local distributor or the IMT Technical Service Department. Have your parts manual, model number, and serial number on hand when you call. This information is usually located on the serial number placard posted on the crane mast or lower boom.

Stay clear of moving parts, understand the job, and use common sense when repairing	Always label wires, cables and hoses when disassembling.
your crane.	uisassembility.

- **3** When disassembling any part of your crane, follow these steps:
 - a) Mark and remove any hydraulic hoses connected to the area of the crane you need to work on. Cap hoses to prevent contamination.
 - b) Use a hoist or two slings to support the crane, or the section of the crane, in the center of gravity.
 - c) Remove and discard any mounting bolts. Always use new, properly-torqued bolts for reassembly.
 - d) Once the crane or section of the crane is fully supported and the bolts are removed, remove the component which requires repair.


Associating Radio Remote Receiver and Transmitter

Associate Mode is used to establish the communications link between a pistol-grip remote transmitter and receiver on a 1-to-1 association basis. To associate there must be a clear line of sight between the transmitter and the receiver, and both units must be OFF (powered down).

To Associate

- 1 Stand near the receiver on the truck with the pistol-grip remote turned OFF. Make sure there is no power to the receiver. (Unpin the electrical connections P1 and P2 from the bottom of the receiver or turn the source power OFF).
- 2 Release the STOP button on the handheld by twisting it clockwise.
- **3** Push and hold SW1 DOWN (AIR OFF) and then immediately push and hold SW2 UP (Engine Start). All four LEDs light solid.
- **4** Observe the LEDs. When RX goes OFF, power up the receiver. When the RX LED blinks, release SW1 and SW2.

A successful association is indicated when LEDs TX and RX are rapidly blinking while the Battery and Warning LEDs are unlit.



NOTE


POWER DOWN INSTRUCTIONS FOR RECEIVER AND TRANSMITTER.

The pistol-grip remote is turned off by pushing the oversized mushroom STOP button. The receiver is safely powered down by disconnecting P1 and P2 (cables plugged into the bottom of the receiver) or by removing/ turning-OFF the power source from the unit (turning off the vehicle engine or the PTO).

Wear Pads

IMT crane booms extend and retract on synthetic wear pads. The pads may be dropped in place in a cavity or snapped in place into the sides of the booms. See figure for wear pad locations. With crane use, wear pads wear and must be replaced. Replace wear pads when any of the following conditions exist:

- When pads wear such that boom sections rub on boom sections with the result of metal scraping and the removal of paint on the boom sections.
- With the boom sections extended in the horizontal position, there is noticeable droop. Any visible droop in the boom sections indicates the need for wear pad replacement.



To replace front boom wear pads:

- 1 Retract all extension boom sections.
- 2 Position the crane so the lower boom is horizontal and at a comfortable working height.
- 3 Extend the required extension boom section sufficiently to allow access to front wear pads.
- 4 Block up boom to relieve pressure on the wear pads.
- 5 Remove the wear pad mounting bracket. Slide out the wear pad and replace.

To replace side and back wear pads:

- 1 Remove the cylinder rod pin and unhook the cylinder.
- 2 Identify and remove hydraulic lines.
- 3 Cap or plug all open hydraulic fittings.
- 4 Position hoist for pulling boom sections out of boom.
- 5 Using hoist, begin pulling disconnected sections from crane. Lift and slide the boom out of position.

- 6 Snap the side wear pads out. Replace.
- 7 Lift boom end with hoist to relieve pressure on rear wear pad. Remove wear pad. Replace.
- 8 Reverse steps to re-assemble with new wear pads. Torque according to torque charts in maintenance & inspection section.
- 9 Start the crane. Slowly cycle the boom in and out with no load to purge air from system.
- **10** After the air has been purged from the system, check the reservoir oil level. Top off oil level if needed.

Cylinder Repair

The cylinders in your IMT telescopic cranes are greaseless.

- 1 If you need to replace any components on the cylinders, use the cylinder drawings in your parts / specifications manual for parts and placement reference.
- 2 Torque the rod bearing and any nuts per torques on the cylinder drawings.
- **3** Apply "Lubriplate" number 630-2 medium-heavy, multipurpose lubricant to all piston, rod bearing, and holding-valve seals.
- 4 Lock the rod bearing on the cylinder using a self-tapping #8-32 x 0.25" long set screw. Position the screw in a seam between the rod bearing and the case. See cylinder drawings for details.
- 5 Replace all seals whenever the cylinder is disassembled. See cylinder drawings for seal placement.

Pin Removal & Inspection

Avoid serious injury! Support the crane with hoists or straps prior to removing any pins. Removing crane pins can cause crane sections to suddenly come apart.

Pins are frequently used as structural components on IMT cranes. Critical structural pins which require inspection and repair include pins which secure the lower boom assembly to the mast, pins which secure the main cylinder base end to the mast, pins which secures the main cylinder rod end to the lower boom assembly, pins which secure the main cylinder to the extension cylinder section, and pins which secure the extension boom assembly to the boom tip.

Every two years, disassemble the crane and inspect the critical structural pins (noted above) for damage. Check pins for signs of wear, using the Pin Defect chart. The pin should be shiny with no galling or pitting in the contact areas. Minor blemishes (see chart) can be dressed and the pins can be reused. Pins with cracks which extend into the pin cross section must be replaced. To repair pins, dress the edges of the flaw with a file so no metal protrudes above the circular surface of the pin. Pins with defects larger than those listed, or with large cracks extending into the pin cross section, must be replaced.

PIN DEFECT	MAXIMUM TOLERANCE
Nick, gouge or scratch	Up to 1/8" (3.2 mm) diameter
Circular scratch around	Up to 1/16" (1.6 mm) wide
the pin	or deep
Lengthwise scratch	Up to 1/32" (0.8 mm)

NOTE

Use care when removing pins not to crush the snap ring groove. Apply a lubricating compound like Never-Seez prior to reinstalling pins. Avoid getting Never-Seez on Gar-Max bushings.

Bushings

Bushings are used to strengthen and support joints and to reduce pin wear. Although bushing failure is highly unlikely, it can happen. Bushing failure is demonstrated by excess movement at crane joints.

Roller bearings are used on some crane sheaves. Bushings, which are bearings without moving parts, are used on the cylinders and booms of some crane models.

To inspect bushings and bearings,

- **1** Degrease bearing.
- 2 Inspect the inside coating of the bearing. No tears and breaks in the coating are acceptable.
- 3 Inspect the metallic body of the bearing. No changes in the bearing dimensions are permitted.
- 4 Replace the bearing if needed. Otherwise, lightly grease and reassemble.

To replace bearings:

- 1 Start the bearing in its respective hole by rotating the bearing while applying pressure. Align the grease zerk hole with the bearing hole (if applicable). Once started, drive the bearing to its full counterbored depth by tapping with a rubber mallet. Use a mallet with a head larger than the bearing so the bearing isn't damaged.
- 2 If the bearing is loose, tighten the bearing by centerpunching the bore diameter in about 50 places around the 2" deep bored area.
- **3** After installing bearings, and before assembling the machine, insert the pins through both bearings in each end of the lift cylinders, and through the boom pivot bearings, to ensure alignment and fit are correct. Pins should slide freely through the leading hole and start in the opposite hole. If the pin binds, do not force it. Remove the pin, clean the hole, and reinsert.

Inspect bushings and bearings as needed, and replace any damaged or worn bushings. Lubricate with EP grease upon replacement.

Wire Rope Removal & Replacement

The maintenance section of this manual describes inspection criteria for wire rope. If the wire rope is damaged, bent or worn as defined in *Wire Rope Inspection & Replacement* (on page 50), replace it using the following steps:

- 1 Run out all wire rope from the winch and stretch it out straight. Disconnect the rope from the cable guide on the side of the lower boom.
- 2 Remove the clamp which secures the rope to the boom tip. Pull the pin to release the cable.
- 3 Unhook the wire rope from the winch spool by removing the set screw or cable wedge anchor.
- 4 Remove the wire rope.

Turntable Bearing Inspection

Turntable bearings may experience wear. One of the following conditions may indicate turntable bearing wear:


- 1 Metal particles present in the bearing lubricant.
- 2 Increased drive power required to rotate the crane.
- 3 Noise emitting from the bearing during rotation.
- 4 Rough rotation.
- 5 Uneven or excessive wear between the pinion gear and turntable gear.

If one or more of the above conditions exists, further inspection may be required. Limits are measured in "TILT" which is dependent on the internal clearances of the bearing. TILT is the most practical determination of a bearings' internal clearance once mounted on a crane. You can measure the tilt using the Turntable Bearing Tilt Test.

Periodic readings indicating a steady increase in TILT may be an indicator of bearing wear. Note that a bearing found to have no raceway cracks or other structural irregularities should be reassembled and returned to service.


Turntable Bearing Tilt Test

- 1 Place crane in vertical position.
- 2 Set a dial indicator at 0 on the pinion cover plate at back side of mast.
- **3** Lower crane to the horizontal position.
- 4 Check and record the dial indicator change. It should not exceed the tilt measurement noted below.
 - Models 7500, 8600, 9500, and 10000 cranes 0.060" (1.524 mm)
 - Models 12000 and 14000 cranes 0.070" (1.778 mm)
- 5 Return the crane to the vertical position. The dial indicator should return to 0.



Turntable Bearing Thread Tightening Sequence

Refer to the turntable bearing thread tightening diagram below for proper tightening/torquing sequence of the turntable bearing to the crane base and crane mast. The total quantity of cap screws varies dependent on crane model.



TIGHTENING PROCEDURE

- 1 Refer to the Torque Data Chart to determine the proper torque value to apply to the size of capscrew used.
- 2 Follow the tightening sequence shown in the diagram. Note that the quantity of capscrews may differ from the diagram, but the sequence must follow the criss-cross pattern as shown in the diagram.
- 3 Torque all capscrews to approximately 40% of the specified torque value, by following the sequence.

(EXAMPLE: .40 x 265 FT-LB = 106 FT-LB)

(EXAMPLE-METRIC: .40 x 36 KG-M = 14.4 KG-M)

4 Repeat Step 3, but torquing all capscrews to 75% of the specified torque value. Continue to follow the tightening sequence.

(EXAMPLE: .75 x 265 FT-LB = 199 FT-LB)

(EXAMPLE-METRIC: .75 x 36 KG-M = 27 KG-M)

5 Using the proper sequence, torque all capscrews to the listed torque value as determined from the Torque Data Chart.


Turntable Bearing Worm End Play & Backlash

IMT telescopic cranes have an integral base and worm drive rotation system.

Backlash, measured at the highest spot on the turntable bearing, is the shortest distance between nondriving tooth surfaces in mating gears. Measure backlash using a feeler gauge at or near the pitch diameter and tangent to the gear.

To set both Worm End Play and Backlash, you must locate the high tooth on the gear. Usually this spot is marked by the manufacturer with light blue paint. If you cannot find the paint mark, identify the high tooth using a dial indicator with a magnetic base and a round steel pin which is large enough to contact the bearing near the pitch line of the bearing tooth. Set the indicator base on the face of the bearing race that does not have teeth. Place the pin between two of the teeth. Set the indicator probe on the pin and adjust the dial to zero. Rotate the bearing, checking every third tooth until you find the highest indicator reading. Check three teeth in both directions in this area to determine the highest tooth. The amount of run-out varies depending on the diameter of the bearing. Once you find the high tooth, mark it for future reference.

Bearing Tooth Contact Point



Pin and Indicator Tip



To set the worm end play:

- 1 Locate the high tooth on the gear. (The high spot on the bearing is marked by the manufacturer with paint.)
- 2 Screw a bolt into the threaded hole nearest the high tooth. Screw additional bolts into threaded holes at 90° from the high tooth.
- **3** Mount a magnetic base with an indicator attached on top of the worm housing and at the opposite end from the motor mount.
- 4 Adjust the indicator to read from the end of the worm shaft. Set the indicator to "0".

5 Using two of the bolts as handles, rotate the outer race back and forth. Read the total indicator movement. The measurement is the end play of the worm. The specification for end play is +0.000/-0.004" (+0.000/-0.1016 mm). If your end play does not meet the specification, remove the bearing retainer and add or remove shims from the unit. Repeat the measurement process until the end play meets the specification.

Dial Indicator Set-Up



To set the gear bearing backlash:

- 1 Locate the high tooth on the gear. (The high spot on the bearing is marked by the manufacturer with paint.)
- 2 Rotate the bearing until the high tooth is engaged with the worm. Loosen the three bearing retaining allen head capscrews just enough to be able to move the bearing toward or away from the worm. Screw a bolt into the threaded hole in the bearing nearest the worm.
- 3 Set the magnetic indicator base on the worm housing with the indicator probe against the bolt, and set the indicator dial at zero.
- 4 Move the bearing back and forth. Watch the indicator dial, and adjust the bearing in or out of the worm until the total indicator movement is 0.005". NOTE: Deduct any end play in the worm from the indicator reading.
- **5** Rotate the bearing 180°. Recheck the backlash. Total backlash should be 0.005" to 0.012" (0.127 to 0.3048 mm.)
- 6 After setting the backlash, torque the bearing retaining allen head capscrews while watching the indicator dial so the correct backlash setting is maintained. Torque per the torque specifications on the turntable gear bearing drawing in the parts/specifications manual. See the *Turntable Bearing Thread Tightening Sequence* (on page 65).

Anytime the gear-bearing bolts have been removed, they must be replaced with new bolts of identical grade and size. Failure to replace gear-bearing bolts may result in bolt failure due to metal fatigue, causing death or serious injury.

Torque per *Turntable Bearing Thread Tightening Sequence* (on page 65). Check all bolts after swinging the full rated load. Applying full load against all of the bolts will test bolt torques.

CHAPTER 5

Installation

In This Chapter

Installation Introduction	70
Chassis Preparation	70
Frame Strength	70
PTO & Pump	70
Engine Speed Regulation	71
Crane Installation	72

Installation Introduction

IMT cranes must be mounted on truck chassis of the appropriate size with the appropriate frame reinforcement, PTO, pump, and hydraulics. Refer to the parts and specifications manual for your crane model for the minimum chassis requirements for your crane.

Chassis Preparation

Prior to installing the crane, follow these steps:

- 1 Inspect the carrier vehicle to be certain it complies with the minimum chassis specifications for your crane model.
- 2 Clear obstructions from the portion of the chassis frame where the crane body will rest. Check that you have adequate mounting space. Space will be available for gas tanks, etc. after the crane is installed.
- 3 Install the PTO according to the PTO manufacturer's instructions.
- 4 Install the pump. Make sure that the pump rotates in the proper direction and tighten the pump mounting bolts.
- 5 Connect the pump suction line to the barbed nipple on the bottom side of the reservoir.
- 6 Connect pump pressure line to pressure port on crane valvebank. (Note: If stabilizers are hydraulic, connect to pressure port on stabilizer valvebank.)
- 7 Be sure to open ball valve at the reservoir outlet prior to engaging PTO.
- 8 Spray paint all unpainted surfaces.

Frame Strength

Select the proper truck frame to avoid overstressing the truck frame by loads imposed by the crane and its load. You may have the reinforce the frame. The minimum truck frame resistance-to-bending moment (RBM) is listed in the crane minimum chassis specifications in the specifications section of your manual.

PTO & Pump

A Power Take Off (PTO) must be properly matched to the vehicle's transmission as well as the requirements of the crane. In order to properly select a PTO, determine:

- 1 Carrier vehicle transmission make and model
- 2 Crane and auxiliary equipment power requirements
- 3 Necessary PTO speed
- 4 Direction in which PTO must turn
- 5 PTO torque required

If possible, use a hydraulic pump mounted directly to the PTO. Follow the PTO manufacturer's instructions to install the PTO and the pump.



Engine Speed Regulation

The delivery rate of the hydraulic pump determines the operating speed of the crane. In order for the crane to function at speeds stated in the Crane Specifications, the pump must operate at the speed required for the proper delivery rate (required pump speed). To determine the required pump speed, you must know the rated capacity of the pump, the pump speed required for the rated capacity, and the required delivery rate for the proper crane performance.

To determine the engine RPM necessary for required pump speed, the required pump speed is divided by the engine to PTO ratio. (The PTO ratio is generally specified as a percentage of engine speed.)

If you don't know the engine to PTO ratio, or the pump capacity, contact your dealer or IMT. To find the engine to PTO ratio, you must know the PTO and transmission model numbers as well as the make, model, and year of the truck. To find the proper pump capacity, you must know the pump make and model. Record this information below.

PUMP CAPACITY	ENGINE TO PTO RATIO

Efficient operation of your crane is dependent upon proper pump speed. When operation is too slow, check the pump speed when diagnosing the cause. A tachometer with accurate calibration may be used to check engine speed.

FORMULA TO DETERMINE REQUIRED PUMP SPEED: C = Rated Pump Capacity D = Delivery Rate Required for Proper Pump Performance RPM = Pump Speed Required for Rated Pump Capacity D To calculate: Required Pump Speed = $(D / C) \times RPM$ Example: If D = 9 GPM, C = 13 GPM, and RPM = 2000, Required Pump Speed = $(9 GPM / 13 GPM) \times 2000 =$ 1385 RPM

FORMULA TO DETERMINE ENGINE RPM: Required Engine RPM = Required Pump Speed / PTO Ratio (%) Example: If Required Pump Speed = 1385 RPM and PTO Ratio = 70%,

Required Engine RPM = 1385 RPM / 0.70 = 1980 RPM

Crane Installation

Your crane is designed for use with an IMT body installed on a vehicle meeting minimum chassis requirements including a specific body style, wheelbase dimension, cab-to-axle dimension, frame section modulus, RBM*, axle ratings, and gross vehicle ratings. A chart with this information is included in your crane parts / specifications manual.

(*RBM, Resistance-to-Bending-Moment, is a figure of relative strength of a specific frame which is made of a specific grade of steel. RBM is calculated by multiplying the Frame Section Modulus (in cubic inches) by the Frame Yield Strength.)

If the crane is being installed on a body other than an IMT mechanic's body, check with IMT to determine if that body is suitable.

Do NOT use this crane on a body not capable of handling the loads imposed on it. Avoid death or serious injury.

In addition to meeting minimum chassis specifications, make sure there is sufficient room to mount the crane, and that the platform is strong enough to support the crane and rated load. The body must be designed to sustain the forces imposed by the crane when lifting the full rated load.

Install the body before installing the crane. Do not unfold or open the crane before installation.

NOTE: Installing an IMT telescopic crane onto an IMT dominator body of a different series may require one of the following:

Use adapter harness 77441564 to install a Series III crane onto a series I or Series II Dominator .

Use adapter harness 77441463 to install a series I or series II crane onto a series III dominator.

Crane Installation Steps:

- 1 Use a lifting device which can handle the weight of the crane. (See the Specifications section of the crane parts / specifications manual for the crane weight.) Attach fabric slings to the crane lower boom, centered approximately 18" (46 cm) from the mast hinge. Make sure the crane is well balanced by lifting only approximately 6" (15 cm) above the ground. After lifting the crane, apply a bead of waterproof compound, such as silicon-based caulk, to the bottom of the base. Move the chassis under the crane and lower the crane into the desired position.
- 2 Install the mounting screws and washers to secure the crane base to the truck body. Torque per the installation drawing. Please find the installation drawings in the parts / specifications manual for the specific crane.


CHAPTER 6

Crane Decals

In This Chapter

Telescopic Crane Decals	76
Danger Decals	77
Danger Decal Figures	
Instructional Decals	83

Telescopic Crane Decals





NOTE: SEE THE CRANE PARTS MANUAL FOR MORE PLACEMENT INFORMATION.

Danger Decals

All operators must familiarize themselves with the "DANGER" decals shown in this section. Your equipment may have additional safety decals that are not described here. Any safety decals affixed to your equipment must be identified, read and understood.

The materials and adhesives used in the production of these decals were designed for maximum durability, adhesion and legibility. Nevertheless, if a decal (including capacity chart) becomes damaged or illegible, replace it at your earliest opportunity. If a crane is repaired or repainted, replace all decals before the crane is put back into service. Individual decals as well as complete decal kits are available from IMT.

The following figures show examples of the safety decals used on IMT cranes, along with an explanation of their purpose, location, and the normal quantity used on each crane.

Danger Decal Figures

A. Crane Operations Hazard

Part #: 70396613

Function: To inform operator of hazards associated with untrained operation, contact or proximity to electrical lines, crane two-blocking, and lifting personnel. The decal defines the possible consequences and how to avoid the hazard.

Placement: At or near control handle storage point.

Quantity: 1

B. Electrocution Hazard


Part #: 70394445

Function: To inform the operator and other personnel in the work area of the hazard associated with contact or proximity to electrical lines, the possible consequences should the hazard occur, and how to avoid the hazard.

Placement: On all four sides of the carrier vehicle.


Quantity: 4







Instructional Decals

Decals in this section are instructional decals which may be affixed to your crane. Some are relevant to maintenance while others focus on operation. They are provided here as reference to help you understand their purpose and placement.





N. Load Block Rating	LOAD B		ATING		
Part #: Depends on load block.					
Function: To inform operator of the amount the load block can lift.	5.5	0	NS		
Placement: On snatch block.	SNATCH BLO	CK WEIGHT: 2	22 POUNDS 70393860)	
Quantity: 1 per side.					
O. Caution – Oil Level					
Part #: 71039134	AVOID F	QUIPME		AGE	
Function: To caution the operator to check the hydraulic reservoir oil level regularly.	AVOID EQUIPMENT DAMAGE Check oil level regularly.				
Placement: On cranes with hydraulic fluid reservoirs, at or near operating station.	id				
Quantity: 1 per side.					
P. Hydraulic Oil Reservoir Fill Recommendations	lowa Mold Too Garner, lowa	oling Co., Inc.	\sim		
Part #: 70394189	USA 641-923-3711				
Function: To inform operator and maintenance personnel of the recommended hydraulic oil to be used	HYDRAU	JLIC OIL RES			
under differing climatic conditions.	HYDRAULIC		IENT URE RANGE		
Placement: On or near hydraulic oil	OIL	°F	°C		
reservoir.	ISO 32	0° to 90°	-18° to 32°		
Quantity: 1	ISO 15	Below 0°	Below -18°		
	ISO 46	Above 90°	Above 32°		
	For Arctic condit	ions, consult yo	our oil supplier.		



$C \ \text{HAPTER} \ 7$

Reference

In This Chapter

Inspection Checklist	85
Deficiency / Recommendation / Corrective Action Report	
Crane Stability Test	
Thread Torque Charts	
	-

Inspection Checklist

NOTICE:

The user of this form is responsible for determining that these inspections satisfy all applicable regulatory requirements.

OWNER/COMPANY:	TYPE OF INSPECTION (circle one):			
CONTACT PERSON:	DAILY	MONTHLY	QUARTERLY	ANNUAL
CRANE MAKE & MODEL:	DATE INSPECTED:			
CRANE SERIAL NUMBER:	HOURMETER READING (if applicable):			
UNIT I.D. NUMBER:	INSPECTED BY (print):			
LOCATION OF UNIT:	SIGNATURE OF INSPECTOR:			

TYPE OF INSPECTION

NOTES:

Daily and monthly inspections are to be performed by a "competent person", who is capable of identifying existing and predictable hazards in the surroundings or working conditions which are unsanitary, hazardous, or dangerous to employees, and who has authorization to take prompt corrective measures to eliminate them.

Quarterly and annual inspections are to be performed by a "qualified person" who, by possession of a recognized degree, certificate, or professional standing, or who by extensive knowledge, training and experience, successfully demonstrated the ability to solve/resolve problems relating to the subject matter, the work, or the project.

One hour of normal crane operation assumes 20 complete cycles per hour. If operation exceeds 20 cycles per hour, inspection frequency should be increased accordingly.

Consult Operator / Service Manual for additional inspection items, service bulletins and other information.

Before inspecting and operating crane, crane must be set up away from power lines and leveled with stabilizers fully extended.

DAILY (D): Before each shift of operation, those items designated with a (D) must be inspected.

MONTHLY (M): Monthly inspections or 100 hours of normal operation (whichever comes first) includes all daily inspections plus items designated with an (M). This inspection must be recorded and retained for a minimum of 3 months.

QUARTERLY (Q): Every three to four months or 300 hours of normal operation (whichever comes first) includes all daily and monthly inspection items plus items designated with a (Q). This inspection must be documented, maintained, and retained for a minimum of 12 months, by the employer that conducts the inspection.

ANNUAL (A): Each year or 1200 hours of normal operation (whichever comes first) includes all items on this form which encompasses daily, monthly and quarterly inspections plus those items designated by (A). This inspection must be documented, maintained, and retained for a minimum of 12 months, by the employer that conducts the inspection.

INSPECTION CHECKLIST STATUS KEY:

S = Satisfactory	X = Deficient
R = Recommendation	(NOTE: If a deficiency is found, an immediate determination must
(Should be considered for corrective action)	be made as to whether the deficiency constitutes a safety hazard
NA = Not Applicable	and must be corrected prior to operation.)

FREQUENCY	ITEM	КЕҮ	INSPECTION DESCRIPTION	STATUS (S,R,X,NA)
D	1	Labels	All load charts, safety & warning labels, and control labels are present and legible.	
D	2	Crane	Check all safety devices for proper operation.	
D	3	Controls	Control mechanisms for proper operation of all functions, leaks and cracks.	
D	4	Station	Control and operator's station for dirt, contamination by lubricants, and foreign material.	
D	5	Hydraulic System	Hydraulic system (hoses, tubes, fittings) for leakage and proper oil level.	
D	6	Hook	Presence and proper operation of hook safety latches.	

FREQUENCY	ITEM	KEY	INSPECTION DESCRIPTION	STATUS
				(S,R,X,NA)
D	7	Wire Rope	Inspect for apparent deficiencies per applicable requirements and manufacturer's specifications.	
D	8	Pins	Proper engagement of all connecting pins and pin retaining devices.	
D	9	General	Overall observation of crane for damaged or missing parts, cracked welds, and presence of safety covers.	
D	10	Operation	During operation, observe crane for abnormal performance, unusual wear (loose pins, wire rope damage, etc.). If observed, discontinue use and determine cause and severity of hazard.	
D	11	Remote Ctrl	Operate remote control devices to check for proper operation.	
D	12	Electrical	Operate all lights, alarms, etc. to check for proper operation.	
D	13	Anti-Two- Block or Two-Block Damage Prevention	Operate anti two-block or two-block damage prevention device to check for proper operation.	
D	14	Tires	Check tires (when in use) for proper inflation and condition.	
D	15	Ground Conditions	Check ground conditions around the equipment for proper support, watching for ground settling under and around stabilizers and supporting foundations, ground water accumulation, or similar conditions.	
D	16	Level	Check the equipment for level position within the tolerances specified by the equipment manufacturer's recommendations, both before each shift and after each move and setup.	
D	17	Operator cab windows	Check windows for cracks, breaks, or other deficiencies which would hamper the operator's view.	
D	18	Rails, rail stops, rail clamps and supporting surfaces	Check rails, rail stops, rail clamps and supporting surfaces when the equipment has rail traveling.	
D	19	Safety devices	Check safety devices and operational aids for proper operation.	
D	20	Electrical	Check electrical apparatus for malfunctioning, signs of apparent excessive deterioration, dirt or moisture accumulation.	
D	21		Other	
D	22	1	Other	
М	23	Daily	All daily inspection items.	1
М	24	Cylinders	Visual inspection of cylinders for leakage at rod, fittings, and welds. Damage to rod and case.	
Μ	25	Valves	Holding valves for proper operation.	
Μ	26	Valves	Control valves for leaks at fittings and between stations.	
М	27	Valves	Control valve linkages for wear, smoothness of operation, and tightness of fasteners. Relief valve for proper pressure settings.	
М	28	General	Bent, broken, or significantly rusted/corroded parts.	
М	29	Electrical	Electrical apparatus for malfunctioning, signs of apparent excessive deterioration, dirt or moisture accumulation. Electrical	
М	30	Structure	systems for presence of dirt, moisture, and frayed wires. All structural members for damage.	
M	31	Welds	All welds for breaks and cracks.	
M	32	Pins	All pins for proper installation and condition.	

FREQUENCY	ITEM	КЕҮ	INSPECTION DESCRIPTION	STATUS
				(S,R,X,NA)
М	33	Hardware	All bolts, fasteners and retaining rings for tightness, wear and corrosion.	
М	34	Wear Pads	Presence of wear pads.	
M	35	Pump &	Hydraulic pumps and motors for leakage at fittings, seals, and	
		Motor	between sections. Check tightness of mounting bolts.	
М	36	PTO	Transmission/PTO for leakage, abnormal vibration & noise,	
	07		alignment, and mounting bolt torque.	
M	37	Hyd Fluid	Quality of hydraulic fluid and presence of water.	
Μ	38	Hyd Lines	Hoses & tubes for leakage, abrasion damage, blistering, cracking, deterioration, fitting leakage, and secured properly.	
М	39	Hook	Load hook for abnormal throat distance, twist, wear, and cracks.	
М	40	Wire Rope	Condition of load line.	
М	41	Manual	Presence of operator's manual with unit.	
М	42		Other	
М	43		Other	
Q	44	Daily	All daily inspection items.	
Q	45	Monthly	All monthly inspection items.	
Q	46	Rotation Sys	Rotation bearing for proper torque of all mounting bolts.	
Q	47	Hardware	Base mounting bolts for proper torque.	
Q	48	Structure	All structural members for deformation, cracks and corrosion.	
	49		• Base	
	50		Stabilizer beams and legs	
	51		• Mast	
	52		Inner Boom	
	53		Outer Boom	
	54		• Extension(s)	
	55 56		• Jib boom	
	50		Jib extension(s) Other	
Q	58	Hardware	Pins, bearing, shafts, gears, rollers, and locking devices for wear, cracks, corrosion and distortion.	
	59		Rotation bearing(s)	
	60		Inner boom pivot pin(s) and retainer(s)	
	61		• Outer boom pivot pin(s) and retainer(s)	
	62		 Inner boom cylinder pin(s) and retainer(s) 	
	63		Outer boom cylinder pin(s) and retainer(s)	
	64		Extension cylinder pin(s) and retainer(s)	
	65		• Jib boom pin(s) and retainer(s)	
	66		• Jib cylinder pin(s) and retainer(s)	
	67		Jib extension cylinder pin(s) and retainer(s)	
	68		Boom tip attachment	
	69		• Other	
Q	70	Hyd Lines	Hoses, fittings and tubing for proper routing, leakage, blistering, deformation and excessive abrasion.	
	71	1	Pressure line(s) from pump to control valve	
	72		Return line(s) from control valve to reservoir	
	73		Suction line(s) from reservoir to pump	
	74		Pressure line(s) from control valve to each function	
	75		Load holding valve pipe(s) and hose(s)	
	76		• Other	

FREQUENCY	ITEM	KEY	INSPECTION DESCRIPTION	STATUS
		-		(S,R,X,NA)
Q	77	Pumps & Motors	Pumps and Motors for loose bolts/fasteners, leaks, noise, vibration, loss of performance, heating & excess pressure.	
	78	IVIOLOIS	• Winch motor(s)	
	79		Rotation motor(s)	
	79 80		• Other	
0		Mahuaa		
Q	81	Valves	Hydraulic valves for cracks, spool return to neutral, sticking spools, proper relief valve setting, relief valve failure.	
	82		Main control valve	
	83		Load holding valve(s)	
	84		Stabilizer or auxiliary control valve(s)	
	85		• Other	
	86		• Other	
Q	87	Cylinders	Hydraulic cylinders for drifting, rod seal leakage and leakage at welds. Rods for nicks, scores and dents. Case for damage. Case and rod ends for damage and abnormal wear.	
	88		Stabilizer cylinder(s)	
	89		Inner boom cylinder(s)	
	90		Outer boom cylinder(s)	
	91		• Extension cylinder(s)	
	92		Rotation cylinder(s)	
	93		• Jib lift cylinder(s)	
	94		Jib extension cylinder(s)	
	95		• Other	
Q	96	Winch	Winch, sheaves and drums for damage, abnormal wear, abrasions and other irregularities.	
Q	97	Hyd Filters	Hydraulic filters for replacement per maintenance schedule.	
Α	98	Daily	All daily inspection items.	
Α	99	Monthly	All monthly inspection items.	
А	100	Quarterly	All quarterly inspection items.	
A	101	Hyd Sys	Hydraulic fluid change per maintenance schedule.	
A	102	Controls	Control valve calibration for correct pressure & relief valve settings.	
A	103	Valves	Safety valve calibration for correct pressure & relief valve settings.	
A	104	Valves	Valves for failure to maintain correct settings.	
A	105	Rotation Sys	Rotation drive system for proper backlash clearance & abnormal wear, deformation and cracks.	
A	106	Lubrication	Gear oil change in rotation drive system per maintenance schedule.	
A	107	Hardware	Check tightness of all fasteners and bolts, using torque specifications on component drawings or torque chart.	
A	108	Wear Pads	Wear pads for excessive wear.	
A	109	Loadline	Loadline for proper attachment to drum.	

Deficiency / Recommendation / Corrective Action Report

DA	TE:	OWNER:		UNIT I.D. NUMBER:		
GU	DELINES					
а	A deficiency (X) may co before resuming op		cy must be co	rrected and/or faulty parts replaced		
b	Recommendations (R) should be considered for corrective actions. Corrective action for a particular recommendation depends on the facts in each situation.					
С	Corrective actions (CA), repairs, adjustments, parts replacement, etc. are to be performed by a qualified person in accordance with all manufacturer's recommendations, specifications and requirements.					
NC	NOTE: Deficiencies (X) listed must be followed by the corresponding corrective action taken (CA).					
X = DEFICIENCY R = RECOMMENDATION CA = CORRECTIVE ACTION TAKEN						

X,R,CA	ITEM #	EXPLANATION	DATE CORRECTED
	\/		<u>_</u>

X,R,CA	ITEM #	EXPLANATION	DATE CORRECTED
л, к , СА			DATE CORRECTED
	-		
	T		

Crane Stability Test

Every IMT factory-installed crane includes a completed stability chart. Any installer other than IMT also has the responsibility to complete a stability chart. Cranes are tested for stability to 85% of the balance point, which per SAE J765a is defined as the point where the load on the crane is balanced with the load of the truck and stabilizers. Any additional load will cause the truck to tip.

The values on the factory-installed capacity chart are based on 85% of the balance point (tipping point) for a specific truck and crane combination. If the crane or vehicle is modified or replaced with other equipment, stability must be recalculated. By referring to the stability chart for your crane and chassis combination, it is possible to determine the loads permitted in the derated load range of your crane.

Set-Up:

- 1 Perform the stability test on a flat hard surface. Ideally this surface will be concrete, but asphalt or hard-packed gravel are acceptable. Only authorized testing personnel may be in or near the test area. Per SAE J765a, the area must be within 1% of level.
- 2 Prior to setting up the stabilizers, measure the height of the workbench from the ground.
- **3** Position the rear stabilizers and level the truck such that the weight on the springs is relieved enough to raise the workbench approximately 1" (2.54 cm).
- 4 Set up the front stabilizers. If they don't touch the ground with the rear stabilizers as set in step #3, lower the rear stabilizers until the front stabilizers come in firm contact with the ground, then adjust the rear stabilizers until the truck is level.
- 5 Operate the crane under partial load to assure operator proficiency and proper machine function.

Stability Test:

- 1 Once the stabilizers are properly set, extend the crane to the fully-extended horizontal position, centered over the rear of the truck. See Figure 1.
- 2 From the crane capacity placard, determine the rated load at the maximum horizontal reach. Multiply that load by 1.18 (118%) to get the test load.

Test Load Value: _____(lb)

Place that weight at the maximum horizontal reach. Keep the load close to the ground to avoid excessive tipping.

Maximum horizontal reach (L):

At 118% of rated capacity, you are in overload and your crane will not extend with the radio remote. Use the manual levers at the back of the crane to extend the crane to maximum horizontal reach. Then, use the radio to rotate the crane. Keep the load within 3.9" (0.1 m) of the ground at all times, and operate the crane very slowly.

3 Slowly start rotating the load counterclockwise, keeping it within 3.9" (0.1 m) of the ground. Through each area, check for stability. (NOTE: The tires can lift from the ground without the truck becoming unstable.) If the crane carries the load through the entire area without becoming unstable, the crane is stable in that area and 100% can be noted in the box in that section.

- 4 If at any point through the rotation cycle, the vehicle becomes unstable, stop the rotation and note the area in which the crane is positioned. This is the balance point which determines 85% of tipping for the rated load.
- **5** At the balance point, retract the extension boom until stability is regained. Measure the horizontal reach in this position (center of rotation to boom tip). This is the stable horizontal reach in this zone. Note this reach in Figure 1.
- 6 Continue rotating the boom after stability has been regained. Again, watch the vehicle for instability. If a point of instability re-occurs, retract the extension boom until stability is regained. Again, measure the stable horizontal reach at this point, and note this distance in Figure 1.
- **7** Repeat this cycle through a full 180°. Complete all of the reach boxes for Areas 1 through 5 in Figure 1.
- 8 Repeat for Areas 6 through 10.
- 9 If the crane was stable in all areas, fill in 100% in all of the percentage boxes in Figure 1.
- **10** If the stable horizontal reach in any area was less than the maximum horizontal reach (L, determined in step 2), divide the stable horizontal reach by the maximum horizontal reach. Multiply this figure by 100 to gain the percent of full capacity allowed in this area.

Stable Horizontal Reach / Maximum Horizontal Reach (L) x 100 = _____%

11 Enter the derated percent of full capacity obtained in step 10 on Figure 1. In the derated zone, each individual capacity on the capacity chart must be multiplied by the derated percent of full capacity. The reduced capacities must maintain 85% of tipping in the derated zone.

NOTES:

- 1 The figures obtained indicate the stability range of the particular truck and crane combination only. If either the truck or crane is changes or modified, the stability calculations must be repeated.
- 2 Contact IMT if you need a modified stability chart for your vehicle.
- **3** Rotate the crane at least 5 times using the completed figure to ensure the rating is accurate.
- 4 Be sure all information has been recorded on the appropriate figure, and in the service manual.

Record the total length of time to test the crane (total crane test and inspection time should approximate 4 hours per SAE J765a (1990). Total Hours = _____

When applicable, this stability test conforms to SAE J765a and ANSI B30.5.

Lifting in the Derated Zone

If it is absolutely necessary to perform a lift within the derated load capacity zones (Y or Y1), proceed as follows:

- 1 Determine the distance from centerline of rotation to the centerline of the load being lifted.
- 2 Determine the distance from centerline of rotation to the centerline of where the load is to be moved to.
- 3 The actual distance used should be figured as the larger of items 1 and 2 above.
- 4 Refer to the crane's capacity placard and determine within which range the lift will be accomplished.
- 5 Refer to the capacity of that range and multiply that figure by the derated capacity percentage.


6 Make certain that the weight of the load plus any load handling devices does not exceed that figure.

Example:

If the derated percent in Area 3 = 70% and crane capacity at the desired range = 2000 lb, then 0.70 x 2000 lb = 1400 lb

Thus, even though the crane is rated for 2000 lb at that particular range, by making the lift within the derated load capacity zone the load must not exceed 1400 lb.

Stability Chart



Thread Torque Charts

FINE THREAD BOLTS (ENGLISH)					COARSE THREAD BOLTS (ENGLISH)						
SIZE	BOLT DIA.	GRADE 5	\$ `	GRADE		SIZE	BOLT DIA.	GRADE		GRADE	\rangle
(DIA-TPI)	(INCHES)	PLAIN	PLATED	PLAIN	PLATED	(DIA-TPI)	(INCHES)	PLAIN	PLATED	PLAIN	PLATED
		(FT-LB)	(FT-LB)	(FT-LB)	(FT-LB)			(FT-LB)	(FT-LB)	(FT-LB)	(FT-LB)
5/16-24	0.3125	19	14	27	20	5/16-18	0.3125	17	13	25	18
3/8-24	0.375	35	26	49	35	3/8-16	0.375	31	23	44	33
7/16-20	0.4375	55	41	78	58	7/16-14	0.4375	49	37	70	52
1/2-20	0.5	90	64	120	90	1/2-13	0.5	75	57	105	80
9/16-18	0.5625	120	90	170	130	9/16-12	0.5625	110	82	155	115
5/8-18	0.625	170	130	240	180	5/8-11	0.625	150	115	220	160
3/4-16	0.75	300	225	420	315	3/4-10	0.75	265	200	375	280
7/8-11	0.875	445	325	670	500	7/8-9	0.875	395	295	605	455
1-12	1	645	485	995	745	1-8	1	590	445	910	680
1 1/8-12	1.125	890	670	1445	1085	1 1/8-7	1.125	795	595	1290	965
1 1/4-12	1.25	1240	930	2010	1510	1 1/4-7	1.25	1120	840	1815	1360
1 3/8-12	1.375	1675	1255	2710	2035	1 3/8-6	1.375	1470	1100	2380	1780
1 1/2-12	1.5	2195	1645	3560	2670	1 1/2-6	1.5	1950	1460	3160	2370

NOTES

- 1 Tightening torques provided are midrange.
- 2 Consult bolt manufacturer's particular specifications, when provided.
- 3 Use flat washers of equal strength.
- 4 All torque measurements are given in foot-pounds.
- **5** Torque values specified are for bolts with residual oils or no special lubricants applied. If special lubricants of high stress ability, such as Never-Seez compound graphite and oil, molybdenum disulphide, colloidal copper or white lead are applied, multiply the torque values in the charts by the factor .90. The use of Loctite does not affect the torque values listed above.

AWARNING

Anytime a gear-bearing bolt is removed, it must be replaced with a new bolt of the identical grade and size. Once a bolt has been torqued to 75% of its proof load and then removed, the torque coefficient may no longer be the same as when the bolt was new thus giving indeterminate clamp loads after torqueing. Failure to replace gear-bearing bolts may result in bolt failure due to metal fatigue causing death or serious injury.

FINE THREAD TORQUE CHART (METRIC)							
TIGHTENING TORQUE							
SIZE (DIA- TPI)	BOLT DIA. (INCHES)	SAE J429 GRADE 5		SAE J429 GRADE 8			
		PLAIN (KG-M)	PLATED (KG-M)	PLAIN (KG- M)	PLATED (KG-M)		
5/16-24	0.3125	3	2	4	3		
3/8-24	0.375	5	4	7	5		
7/16-20	0.4375	8	6	11	8		
1/2-20	0.5	12	9	17	12		
9/16-18	0.5625	17	12	24	18		
5/8-18	0.625	24	18	33	25		
3/4-16	0.75	41	31	58	44		
7/8-11	0.875	62	45	93	69		
1-12	1	89	67	138	103		
1 1/8-12	1.125	123	93	200	150		
1 1/4-12	1.25	171	129	278	209		
1 3/8-12	1.375	232	174	375	281		
1 1/2-12	1.5	304	228	492	369		

COARSE THREAD TORQUE CHART (METRIC)							
TIGHTENING TORQUE							
SIZE (DIA- TPI)	BOLT DIA (INCHES)	SAE J429 GRADE 5		SAE J429 GRADE 8			
		PLAIN (KG-M)	PLATED (KG-M)	PLAIN (KG-M)	PLATED (KG-M)		
5/16-18	0.3125	2	2	3	2		
3/8-16	0.375	4	3	6	5		
7/16-14	0.4375	7	5	10	7		
1/2-13	0.5	10	8	15	11		
9/16-12	0.5625	15	11	21	16		
5/8-11	0.625	21	16	30	22		
3/4-10	0.75	37	28	52	39		
7/8-9	0.875	55	41	84	63		
1-8	1	82	62	126	94		
1 1/8-7	1.125	110	82	178	133		
1 1/4-7	1.25	155	116	251	188		
1 3/8-6	1.375	203	152	329	246		
1 1/2-6	1.5	270	210	438	328		

NOTES

- 1 Tightening torques provided are midrange.
- 2 Consult bolt manufacturer's particular specifications, when provided.
- 3 Use flat washers of equal strength.
- 4 All torque measurements are given in kilogram-meters.
- **5** Torque values specified are for bolts with residual oils or no special lubricants applied. If special lubricants of high stress ability, such as Never-Seez compound graphite and oil, molybdenum disulphide, colloidal copper or white lead are applied, multiply the torque values in the charts by the factor .90. The use of Loctite does not affect the torque values listed above.

AWARNING

Anytime a gear-bearing bolt is removed, it must be replaced with a new bolt of the identical grade and size. Once a bolt has been torqued to 75% of its proof load and then removed, the torque coefficient may no longer be the same as when the bolt was new thus giving indeterminate clamp loads after torqueing. Failure to replace gear-bearing bolts may result in bolt failure due to metal fatigue causing death or serious injury.