



P.O. Box 189 Garner, IA 50438 Tel: 641.923.3711 Fax: 641.923.2424

www.imt.com

# Manual # 99905541

# TH15K160 PARTS & SPECIFICATIONS

## Revised 05-27-2020

Copyright © 2020 Iowa Mold Tooling Co., Inc.

All rights reserved

No part of this publication may be reproduced, stored in a retrieval system, or transmitted in any form or by any means, electronic, mechanical, photocopying, recording or otherwise without the prior written permission of Iowa Mold Tooling Co., Inc.

Iowa Mold Tooling Co., Inc. is an Oshkosh Corporation Company

# **WARNING**

Operating, servicing and maintaining this vehicle or equipment can expose you to chemicals including engine exhaust, carbon monoxide, phthalates, and lead, which are known to the State of California to cause cancer and birth defects or other reproductive harm. To minimize exposure, avoid breathing exhaust, do not idle the engine except as necessary, service your vehicle or equipment in a well-ventilated area and wear gloves or wash your hands frequently when servicing. For more information go to www.P65Warnings.ca.gov.

# **Table of Contents**

Introduction	1
TH15K160 - Introduction	2
Specifications	5
TH15K160 - Specifications	
6	
TH15K160 - Dimensional Drawing, Forklift Mounting	7
TH15K160 - Dimensional Drawing, Loader Mounting	8
TH15K160 - Recommended Spare Parts	9
TH15K160 - Capacity Chart	10
Assemblies & Installations	11
TH15K160 - Installation Introduction	12
TH15K160 - Hydraulic Installation	13
TH15K160 - Loader Installation	14
TH15K160 - Bulkhead Installation	15
TH15K160 - Valve Bank Installation	
TH15K160 - Operator Training	17
TH15K160 - Intended Use and Identification	
TH15K160 - Component Identification	
TH15K160 - Equipment Inspection	
TH15K160 - Work Station Positioning	
TH15K160 - Controls	
TH15K160 - Task Performance	
TH15K160 - Operating Restrictions	
TH15K160 - Electrical Safety	
TH15K160 - Warnings	25
Maintenance	27
TH15K160 - Maintenance Introduction	
TH15K160 - Lubrication Points	
TH15K160 - Hydraulic System	
TH15K160 - Purging Trapped Air	
TH15K160 - Preventative Maintenance	
TH15K160 - Inspection Chart	31
Parts	33
TH15K160 - Parts Ordering Information	34
TH15K160 - Sub Base Assembly (40727628)	36
TH15K135 - Sub Base Asm w/o Side Shift (40727629)	38
TH15K135 - Body Assembly, Motor Rotation (40727614)	40
TH15K160 - Hyd Kit, Motor Rotation (91727622)	
TH15K160 - Hyd Kit, Motor Rotation, No Valve Bank (91727651)	50
TH15K160 - Body Assembly (40724864) EFFECTIVE THROUGH 10/31/2018	
TH15K160 - Clamp Assembly (40726421)	
TH15K160 - Hand Assembly (40726415)	
TH15K160 - Cylinder (51724677)	
TH15K160 - Cylinder (51726428)	
TH15K160 - Cylinder (51726426)	
TH15K160 - Cylinders (51726419)	
TH15K160 - Valve Bank (73540632)	62

TH15K160 - Hydraulic Kit W/Valve Bank (91724924)	
TH15K160 - Valve Bank (73540533) EFFECTIVE THROUGH 10/31/2	01866
TH15K160 - Hydraulic Kit w/o Valve Bank (91724925)	
Electrical & Lighting	71
TH15K160 - Harness (77441525)	72
TH15K160 - Radio Remote Harness (77441524)	73
TH15K160 - Chassis Interface Harness (77441525)	
General Information	77
TH15K160 - Decal Kit (95724919)	78
TH15K160 - Troubleshooting	
TH15K160 - Cylinders	81
TH15K160 - Replacement Parts	83
TH15K160 - Hydraulic Motors	
TH15K160 - Relief Valve Adjustment	
TH15K160 - Bearings	
TH15K160 - Turntable Bearing Inspection	
TH15K160 - Camera Kit Dual (40724922)	
TH15K160 - Turntable Bearing Thread Tightening Sequence	
TH15K160 - Thread Torque Chart (English)	
TH15K160 - Thread Torque Chart (Metric)	
TH15K160 Padio Pemote	

Section - 1

Section - 1 Introduction

Section - 1 2

# TH15K160 - Introduction

This manual includes operation, safety, and maintenance instructions and replacement parts for your IMT Tirehand.

In addition to reading the manual, it is your responsibility to become familiar with government regulations, hazards, and the specific operation of your equipment. Use caution and common sense while operating and maintaining the equipment and follow all safety procedures and regulations. Treat this equipment with respect and service it regularly.

#### **MODIFICATIONS**

Modifications to your equipment must be performed with IMT approved accessories, parts and optional equipment. If in doubt, contact IMT prior to making any modifications. DO NOT alter or modify any safety device! All safety devices must be inspected, tested and maintained in proper working condition.

Decals regarding safety and operation are considered safety equipment, and must be kept clean and legible.

The equipment owner and/or designated employee is responsible for informing all operators, maintenance personnel, and others involved in equipment operation about the safe operation and maintenance of the equipment. If questions arise concerning safe operation, contact IMT or your IMT distributor for clarification.

#### WARRANTY

Warranty of this unit will be void on any part of the unit subjected to misuse due to overloading, abuse, lack of maintenance and unauthorized modifications. No warranty - verbal, written or implied - other than the official, published IMT new machinery and equipment warranty will be valid with this unit.

## NOTICE TO THE OWNER / USER

If your equipment is involved in a property damage accident, contact your IMT distributor immediately and provide them with the details of the accident and the serial number of the equipment. If an accident involves personal injury, immediately notify your distributor and IMT Technical Support at:

IOWA MOLD TOOLING CO., INC. 500 HWY 18 WEST GARNER, IA 50438 641-923-3711 Section - 1 3

## INTRODUCTION, CONTINUED

## RESPONSIBILITY

It is the user's responsibility to maintain and operate this unit in a manner that will result in the safest working conditions possible. In addition, it is the user's responsibility to be aware of existing Federal, State, and Local codes and regulations governing the safe use and maintenance of this equipment.

## MANUAL STRUCTURE

Throughout this manual, four means are used to draw the attention of personnel. They are NOTE, CAUTION and WARNING and DANGER and are defined as follows:

## NOTE

A NOTE is used to either convey additional information or to provide further emphasis for a previous point.

## CAUTION

A CAUTION is used when there is the very strong possibility of damage to the equipment or premature equipment failure.

## WARNING

A WARNING is used when there is the potential for personal injury or death.

## **DANGER**

Danger indicates an imminently hazardous situation which, if not avoided, will result in death or serious injury. Danger is used in the extreme situations.

This page left intentionally blank

Section - 2

**Specifications** 

TH15K160 - Specifications

GENERAL SPECIFICATIONS	
Tirehand maximum capacity	15,000 lb (6804 kg)
Body rotation	100°
Pad rotation system	360°
Tirehand weight (forklift mounted)	8900 lb <i>(4037 kg</i>
Tirehand weight (loader mounted)	10,700 lb <i>(4853 kg)</i>
Clamping span	43" to 160" (109.2 to 406.4 cm)
HORIZONTAL CENTER OF GRAVITY F	FROM VEHICLE ATTACHMENT POINT:
Forklift-mounted Tirehand with 10,000 lb (4536 kg) tire & rim assembly at 131" (333 cm)  Clamp opening	91" (231 cm)
Loader-mounted Tirehand with 10,000 lb (4536 kg) tire & rim assembly at 131" (333 cm)  Clamp opening	92" (234 cm)
Method of clamping	Parallelogram
Clamping load holding valves	Counterbalance valve
Hydraulic control valve	Located on base assembly
Hydraulic controls	5-Function remote control (radio or cab-mounted)
Optimum pump capacity (supplied from carrier vehicle)	12 U.S. gpm (45.4 Lpm) @ 3000 psi (207 bar) (57 Lpm @ 207 bar)
Counterweight needed	As required for stabilization

#### STANDARD FEATURES:

- 1. Hydraulic fallback protection
- 2. Rim flange hardware on pads
- 3. Forklift or loader mounting

## **OPTIONAL FEATURES:**

- 1. Electric controls
- 2. Lateral shifting capabilities


## **VEHICLE COMPATIBILITY**

The Tirehand TH15K160 will permanently adapt to either a forklift truck or a front-end loader. When mounting to a forklift truck, it is recommended that the truck be equipped with a side-shifter. If adapted to a front-end loader, quick couplers are available which enable the disconnection of the Tirehand so that the original bucket can be quickly coupled to the machine for normal operations.


IMT reserves the right to change specifications and design without notice. Where applicable, specifications are in accordance with SAE standard and ISO/DIS 3691-1, the international standard for Industrial Trucks - Safety Requirements and Verification.

IOWA MOLD TOOLING CO., INC. BOX 189, GARNER, IA 50438-0189 TEL: 652-923-3711 FAX: 641-923-2424

# TH15K160 - Dimensional Drawing, Forklift Mounting



# TH15K160 - Dimensional Drawing, Loader Mounting



# **TH15K160 - Recommended Spare Parts**

PART NO.	TH15K160 DESCRIPTION	QTY.
60020167	BUSHING-BRZ 2.50X 3.00X 3.75	16
60020181	BUSHING-B148 ROTATION	2
60020182	BUSHING-B148 ROTATION	2
60020246	BUSHING-BRZ 1.50X 2.25X 0.94	2
60020247	BUSHING-BRZ 1.50X 2.25X 1.00	2
60030253	WEAR PAD-SIDE SHIFTER TH2557B	1
60030468	SPACER-INTERMEDIATE GEAR	2
60106309	GEAR-DRIVE 1.875 PD X 3.75 LG	2
71056264	GEAR-INTMD 301-10103-1	2
71056265	GEAR-PINION 301-10104-1	2
71056389	GEAR-TRNTBL BRG 449-05190-1	1
71056678	GEAR-TRNTBL BRG S7C-73HA-25.4ML-DC104	1
71415014	KEEPER-PIN .38	6
71415017	KEEPER-PIN .75	8
73540465	VALVE-BI-DIRECTIONAL RELIEF 1600 PSI #6	4
73511285	MOTOR ASM W/CBAL VALVE	2
9B015930	SEAL KIT-IMT 4.02B 2.00R 1.44S	1
9C160920	SEAL KIT-IMT 4.02B 2.50R 1.44S	2
71415915	SEAL KIT FOR 51724677	1
94399967	SEAL KIT - JARP 432126B	2
70055370	BEARING-POLYGON PWR24M28-32	2
70055402	BEARING-POLYGON PWR24M28-44	1
70034283	BEARING-GAR-MAX 2.50X3.00X2.00	4
70055408	BEARING-POLYGON PWR24M28-30	4

# TH15K160 - Capacity Chart



70399423

MAX: 160" (406 cm)

Section - 3

Assemblies & Installations

# TH15K160 - Installation Introduction

#### VEHICLE COMPATIBILITY

The Tirehand will permanently adapt to either a forklift truck or a front-end loader which has sufficient capacity and stability, per the Tirehand specifications. When mounting to a forklift truck, it is recommended that the truck be equipped with a side shift. If adapted to a front-end loader, quick couplers are available which enable the disconnection of the Tirehand so that the original bucket can be quickly coupled to the machine for normal operations.

Typical Tirehand hydraulic installations include:

- Bulkhead plate hydraulic installation all of the Tirehand hydraulics hoses connect together in a bulkhead plate, which then connects hydraulically to the loader or forklift. With a bulkhead plate installation, the valve bank is part of the forklift or loader rather than the Tirehand. In many cases, bulkhead installations are used on forklifts.
- Valve bank hydraulic installation when the valve bank is part of the Tirehand, rather than the loader or
  forklift. The forklift or loader must be equipped with a pressure line and a return line which connects the
  forklift or loader hydraulic system to the valve bank in the Tirehand. In many cases, valve bank hydraulic
  installations are used on loaders.

Typical Tirehand controls include:


- 1. Hydraulic cab controls, where additional functions in forklift or loader control valves are hydraulically connected to the Tirehand.
- 2. Electric cab controls, which includes a control box with toggles used to control the Tirehand.
- 3. Radio remote controls.

For all installations, the Tirehand requires 12 gpm (45.4 Lpm) of hydraulic fluid at 3000 psi (207 bar). A flow divider may be required if the forklift or loader pump provides excess flow. Contact IMT for specific installation instructions on any type of installation.


Prior to connecting any electrical connections between the Tirehand and the loader or forklift, check the Tirehand voltage. IMT Tirehand may be 12V or 24V.

# TH15K160 - Hydraulic Installation

# PREFERRED INSTALLATION:



# ALTERNATE INSTALLATION:



# TH15K160 - Loader Installation

- 1. Mount the Tirehand to loader arms using the original loader pins.
- 2. Splice the flow control divider into the existing pressure line. Continue the original line to its original destination (bucket, etc.), and route the controlled line with 12 gpm (45.4 *Lpm*) at 3000 psi (207 bar) to the Tirehand valve bank.
- Route the hoses.
- 4. Locate the control handle inside the cab where convenient to operate.
- 5. Connect the three-wire power cable to 12-volt power. The green wire connects to 12V positive, the black wire to the coil on the flow divider, and the white wire to ground.
- 6. Route the control cable to the Tirehand and connect.
- 7. Check all hoses and cables for clearances. Make sure that steering or moving the arms will not pinch or overstress the hoses or cables.
- 8. Fill the reservoir. Start the loader's engine and operate all controls to purge air from the system. With the loader running, check for leaks and repair if necessary.
- 9. Recheck all hoses and cables for clearance.
- 10. Check the reservoir oil level and fill if necessary.
- 11. Test operate the Tirehand

## NOTE

Stop blocks should be welded to the loader arms to limit articulation if necessary.

Locations and sizes of stops to be determined at the time of installation.

# TH15K160 - Bulkhead Installation

If the forklift on which the Tirehand is installed includes control valves, all of the hydraulic lines from the forklift control valves must culminate at the front of the carriage. The forklift will connect to the Tirehand using a bulkhead plate. The forklift manufacturer must furnish oil for all hydraulic functions. Install the Tirehand with a bulkhead plate as follows:

- Install the Tirehand on the forklift, using the bulkhead plate for hydraulic connections. Use the required hydraulic fluid flow at the correct pressure, per the Tirehand specifications.
- 2. Check lubrication points for adequate lubrication.
- 3. Operate the forklift to check for vertical obstructions.

#### **TESTING**

 Raise the Tirehand to provide adequate clearance for operating all Tirehand functions. Operate all Tirehand functions and check for leaks.

# **AWARNING**

AVOID SERIOUS INJURY! KEEP CLEAR
OF ALL PINCH POINTS WHILE OPERATING
THIS UNIT.

## NOTE

IF THE TIREHAND OPERATION IS ERRATIC, PURGE AIR FROM THE HYDRAULIC SYSTEM.

2. Test the unit at rated capacity. Note any points of instability. Add counterweights if needed.

If the carrier vehicle is articulating, make certain that steering of the vehicle is not hindered by the routing of the hydraulic hoses. Check for wear points and re-route if needed.

# TH15K160 - Valve Bank Installation

When the Tirehand has a valve bank, connect the valve bank to the forklift or loader hydraulic system using the hydraulic pressure and return line from the forklift or loader

- Install the Tirehand on the loader or forklift, connecting the suction and return lines from the forklift or loader to the Tirehand valve bank. See the hydraulic layout drawing in the parts manual for hydraulic information for a valve bank installation.
- 2. Check lubrication points for adequate lubrication.
- 3. Operate the forklift or loader to check for vertical obstructions. Add stop blocks, if needed, to prevent the Tirehand from contacting the carrier vehicle.

## **TESTING**

- 1. Raise the Tirehand to provide adequate clearance for operating all Tirehand functions. Operate all Tirehand functions and check for leaks.
- Test the unit at rated capacity. Note any points of instability. Add counterweights if needed.

If the carrier vehicle is articulating, make certain that steering of the vehicle is not hindered by the routing of the hydraulic hoses. Check for wear points and re-route if needed

# NOTE

IF THE TIREHAND OPERATION IS ERRATIC, PURGE AIR FROM THE HYDRAULIC SYSTEM.

# **A** WARNING

AVOID SERIOUS INJURY! KEEP CLEAR
OF ALL PINCH POINTS WHILE OPERATING
THIS UNIT.

# TH15K160 - Operator Training




Prior to operating the Tirehand, read and follow the manual and all warning and safety decals. The Tirehand is designed for operator simplicity. Prior to operating this unit, the operator should become thoroughly familiar with the controls, operating procedures, and safety precautions.


## TH15K160 - Intended Use and Identification

This Tirehand is a tire lifting and positioning device. It should be used to remove, transport, replace, and storage stack tires. It is designed only as a tire handling device and should not be used for any other purposes. It is intended to permanently attach to either a forklift truck or a front-end loader.

This Tirehand has an identification placard, as shown below, fastened to the body assembly. When ordering parts, communicating warranty information, or referring to the unit in any way, always include the assigned model and serial numbers. All inquiries should be directed to Iowa Mold Tooling Co., Inc., 500 Highway 18 West, Garner, Iowa 50438, U.S.A.



# **TH15K160 - Component Identification**



**NOTE:** \* Forklift-style base shown. See parts section for all base options.

# TH15K160 - Equipment Inspection

Before using, the operator should inspect as listed:

ITEM	DESCRIPTION	FREQUENCY	
ITEM	DESCRIPTION	DAILY	WEEKLY
WALK- AROUND INSPECTION	Inspect for hydraulic leaks, loose parts and obvious structural member damage.		
ROTATION SYSTEM	Check for excessive backlash (play) between pinion gear and turntable gear-bearing. If there is excess play, use a feeler gauge to measure the play and service the Tirehand if needed.		
ELECTRICAL	Check remote controls, auxiliary lighting, etc. for proper function.		
	Check for deterioration, dirt and moisture.		
HYDRAULIC	Check for leaks on surface and at ends.		
HOSE	Check for blistering, deformation and abrasion.		
CONTROL VALVES	Check for leaks, cracks and slow return to neutral.		
CARRIER VEHICLE	Follow all inspection procedures provided by the carrier vehicle manufacturer.		

In addition, the Tirehand requires periodic inspection as noted in the maintenance section. Use the inspection chart in the maintenance section to determine critical inspection tasks.


# **TH15K160 - Work Station Positioning**

Before using the Tirehand, set the work area up correctly.

- Operate this equipment on a firm, level, and dry surface.
- Avoid overhead obstructions.
- Keep unauthorized personnel clear of the work area before beginning work.
- When the job site terrain is graded or soft, exercise extra caution.

# **A** WARNING

Avoid injury! The operator is responsible for being aware of unauthorized personnel in the work area. Suspend operations until the work area is cleared.



**NOTES:** See the Tirehandler, *Radio Remote System*, IMT manual #99905678, for complete radio remote control system instructions. The Tirehand radio remote control is a cab-mounted or tethered remote with a radio option.

## TO OPERATE:

- Power up the remote using the power switch.
- Use the fallback arm switch to activate the fallback arms prior to lifting a tire.
- Use the desired function to manipulate the tire.
- To release a clamped tire, hold the clamp toggle switch while operating the clamp release joystick. This
  prevents tires from being inadvertently released.


## **TIREHAND CONTROLS, CONTINUED**

The Tirehand is equipped with fallback arms to prevent tire movement toward the working area between the tire and the back of the Tirehand. When deployed, the fallback arms are positioned perpendicular to the arm assembly to prevent the tire from falling into the work area. They need to be positioned in-line with the arm assembly when rotating the tire.

The hydraulic assembly for the fallback arms includes a holding valve to prevent the fallback arm from being forced open in case of an unexpected force from the tire or another object



Fallback arms must be deployed when personnel are in the working area between the tire and the carrier vehicle.



# **A** DANGER

**DO NOT** enter the work area unless the fallback arms are deployed! Use the fallback arms when people are in the work area to create a safe work environment.

# TH15K160 - Task Performance

# To begin operation:


To begin operation:				
ITEM NO.	OPERATION / DESCRIPTION			
1.	Open Tirehand clamps.			
	Maneuver the vehicle into a position so that the Tirehand can be used to clamp the center of the tire with the Tirehand body parallel to the ground.			
2.	Make certain personnel are clear before continuing the operation.			
	Advance the carrier vehicle and center the clamp pads on the tire. Clamp tire securely.			
3.				
4.	Remove tire and rim hardware, if needed. Following tire and rim manufacturer instructions, carefully remove the tire and / or rim from the vehicle.			
5.	To transport tire, rotate so that tire is in horizontal position and close to the ground. If possible, keep the lowest part of the tire approximately 12" (305 mm) from the ground.  Tire is positioned parallel and low to the ground for transport.  MARNING  If the tire is in a vertical position, the tire blocks operator visibility during transport.  DO NOT transport tire in this position! Rotate the pads so that the tire is in a horizontal position, parallel to the ground, before transporting. It is the operator's responsibility to position the tire and tirehand for maximum visibility when transporting the tire.			

Assemblies & Installations 23 Section - 3


ITEM NO.	OPERATION / DESCRIPTION			
	Place tire per tire manufacturer recommendations.			
6.	Avoid equipment damage! Never drag or push tire. Make sure the tire is lifted off the ground before moving it.			
7.	To reinstall tire, rotate pads so the tire is in a vertical position, perpendicular to the ground and rotate the body so it is parallel to the ground.  A CAUTION  Clamp pressure can change as the tire rotates and the weight shifts on the clamps.  Observe clamp pressure and adjust if needed.  Watch clamp pressure when body is rotated.  As tirehand body rotates, the tire weight will shift to the lower clamp pad.  Tirehand body in horizontal position for tire installation.			
8.	Clamp the tire securely. Remember, clamp pressure changes as the weight shifts between the clamps. When the tire is vertical, the fallback arms, a safety device in case of operator error, will prevent the tire from falling into the space between the clamp and the body. Make sure the fallback arms are engaged when the tire is in the vertical position.  Fallback arms prevent tire slippage toward tirehand body.  Clamp arms hold tire in vertical position.			
9.	To reinstall a tire, maneuver the forklift or loader so that the Tirehand can be used to position the tire back onto the carrier vehicle. Raise the loader or forklift so the tire is elevated correctly. When the tire is in position and secured properly per the tire, rim, and vehicle manufacturer recommendations, release the Tirehand clamps.			

# TH15K160 - Operating Restrictions

The Tirehand is intended to be a tire lifting and positioning device. There are possible misapplications of this machine that can cause serious damage to the Tirehand rotation gears. It is possible to break the teeth on the Tirehand rotation bearing by applying forces while attempting to break tire beads with one arm of the Tirehand, or by slinging a load under one arm of the Tirehand. Use of a single Tirehand arm for lifting or carrying a load will void the tire hand warranty.



The rotation system on the Tirehand is designed to allow the user to manipulate large tires. It is a precision function that was not designed to apply high loads. However, the load holding valves that are built into this system to help control the tire during handling will also prevent the body of the Tirehand from rotating freely when loads are applied to a single Tirehand arm. When one arm is used for bead breaking, these forces can translate into torques that attempt to rotate the body of the Tirehand. The load holding valves will not allow this to occur. In this situation, the forces that are created in the Tirehand rotation turntable are well in excess of what the gear teeth can tolerate. Using one arm of the Tirehand for bead breaking will void the warranty of the Tirehand



A bead breaker must be used to separate the tire from the rim. It is acceptable to use the Tirehand for holding the sidewall and flange away from the bead while o-rings and locking rings are being installed.

# TH15K160 - Electrical Safety

Keep away from power lines! If you must operate the Tirehand near powerlines:

- 1. For lines rated 350 kV or below, keep a minimum clearance of 20' (6.1 m) between the lines and any part of the Tirehand or load.
- 2. For lines rated over 350 kV, keep a minimum clearance between 50' (15.25 m)
- 3. In transit, keep a minimum clearance of 4' (1.22 m)
- 4. Use a signal person to observe the clearance and give timely warning for all operations where it is difficult for the operator to maintain the desired clearance by visual means.

# TH15K160 - Warnings

Warning decals are installed on the Tirehand, as well as on the loader or forklift, to give information about possible hazards. All decals must be installed and legible. If decals are damaged, they must be replaced. Refer to the parts section for the decal part numbers and locations on the Tirehand.



# FAILURE TO OBEY THE FOLLOWING WILL RESULT IN

# **DEATH OR SERIOUS INJURY,**

## INSTABILITY OR EQUIPMENT DAMAGE

- ALWAYS use this unit for removing, transporting, replacing and storage stacking of tires specified.
- ALWAYS use this unit as a tire handling device ONLY.
- ALWAYS keep load in position low to ground and backward (upward) tilted when transporting to ensure maximum vehicle stability.
- ALWAYS travel and operate at reasonable speeds.
- ALWAYS transport tires with arms rotated in a plane parallel (horizontal) to the ground.
- ALWAYS check the security of clamping action when rotating a load to a position perpendicular to the ground.

70393672

## **TIREHAND WARNINGS, CONTINUED**



FAILURE TO OBE Y THE FOLLOWING WILL RESULT IN

# DEATH, SERIOUS INJURY, INSTABILITY OR EQUIPMENT DAMAGE

NEVER attempt to handle tires filled with ballast. Stability or structural failure may result if load limit is exceeded.



NFVFR drag the tire - the unit is designed to lift and carry.



NEVER transport a tire rotated more than 30° off the horizontal plane.

FOR EXAMPLE: Do not transport in a vertical plane.



NEVER use the unit for any jacking, pulling or dragging operation involving an object or another vehicle.



NEVER impact-load or hammer-push with the unit.




NEVER operate hand below ground level.



NEVER operate the unit while persons not required for operation are in the work area.



NEVER clamp an uninflated tire and then inflate. Damage or injury WILL result.






NEVER sling a load using one arm of the Tirehand.



NEVER use one arm of the Tirehand to break beads.



Section - 4 Maintenance

# TH15K160 - Maintenance Introduction

Proper, regularly scheduled maintenance is essential in keeping your Tirehand at peak operating efficiency. This section outlines maintenance information and service intervals. Personnel responsible for Tirehand maintenance should familiarize themselves with the service intervals and maintenance operations described.

Following the designated lubrication procedures is important in providing maximum Tirehand life. The procedures and lubrication charts in this section include information on the types of lubricants used, location of lubrication points and frequency of lubrication. Information concerning the lubrication requirements of the truck chassis is not included. Refer to the appropriate truck manufacturer's manuals for chassis lubrication requirements.

The service intervals specified are for normal operation where moderate temperatures, humidity and atmospheric conditions prevail. In areas of extreme conditions, the service periods and lubrication specifications should be altered to meet those conditions. For information concerning extreme condition lubrication, contact your local service representative.

**Note:** The service schedule in this manual pertains only to the IMT Tirehand. In addition to Tirehand maintenance, it is your responsibility to follow all inspection and maintenance procedures for the forklift or loader, as defined in the forklift or loader maintenance manual.

# TH15K160 - Lubrication Points

LUBRICATION CHART			
APPLICATION POINT	LUBRICATION	APPLICATION	INTERVAL
Side Shift Pins (if applicable)			
Body - Arm Link Pins (Top			
& Bottom, both sides)			
Arm / Hand Link Pins (Top	Shell Alvainia 2EP		
& Bottom, both sides)	or	Hand Grease Gun	
Pad Rotation Gear	Shell Retinax "A"	or	Weekly
Pad Pinion Gear	or Equivalent	Pnuematic Pressure Gun	
Body Rotation Turntable			
Gear			
Body Drive Gear			
Body Pinion Gear			

# TH15K160 - Hydraulic System

Whenever disconnecting a hydraulic component:

- ALWAYS relieve internal hydraulic pressure before proceeding with the repair.
- 2. **NEVER** allow foreign matter dirt, water, metal particles, etc. to enter the hydraulic system through the open connection. Seal the connection as tightly as possible. If dirt does get in, a filter change is required after about 50 hours of operation.
- **3. ALWAYS** cycle all of the controls after completing a repair. This will eliminate trapped air and prevent bumpy, erratic behavior during actual working conditions.
- 4. ALWAYS check for hydraulic leaks after a repair. A high pressure leak is hazardous and must be repaired before putting the unit to work.

# TH15K160 - Purging Trapped Air

Air can be introduced into the system from a leak or when a hydraulic component is disconnected for servicing. Air in the system will cause erratic operation and must be corrected.

To purge air from the system, extend and retract the affected cylinder several times. At the end of the stroke, hold the valve open for a few seconds. Repeat this procedure until operation is smooth and continuous.

# TH15K160 - Preventative Maintenance

The Tirehand Inspection Checklist is designed to assist in keeping the Tirehand in peak operating condition. The information in this section refers to the Tirehand only. Items which apply to your Tirehand should be checked before it is put into operation. Inspect to the frequency indicated in the chart. Consult the manufacturer's service guide for information on the carrier vehicle.

#### REGULAR INSPECTION

Every three months, or more often when the equipment is subjected to heavy use, complete the following inspections in addition to the preventative maintenance checklist.

## **TIREHAND ARM ASSEMBLIES**

- 1. Check for structural defects such as weld cracks, dents, or bends.
- Check cylinder holding valves.
- Check cylinders for leaks.
- 4. Check both internal and external clamping arm bearings for wear and lubrication.
- 5. Check operating timing. Both clamping arms should function together at the same rate of motion.

#### **AXIAL PAD ROTATION**

- Check for structural defects.
- 2. Check motors for leaks.
- Check disc bearings located on support shafts.
- 4. Check all pins, and their retainers.

## **CYLINDERS**

- Check rods for damage such as scarring. Check for rust on out of service units.
- Check for weld joint and seal leaks.
- 3. Check for drift, indicating possible leakage around the piston.
- 4. Check cylinder case for cracks and dents.

## HYDRAULIC PUMP


- Check for leaks at shaft seal and section joints.
- 2. Check for drop in operating speed.
- Check hydraulic oil for excessive heating.
- 4. Check bolts and fasteners for tightness and note unusual vibration or noise.

## **HYDRAULIC CONTROL VALVES**

- 1. Check spools for sticking and failure to return to neutral position. Inspect for leaks at joints and spools.
- 2. Inspect valve housing for cracks.
- 3. Make certain relief valve reaches the proper relief setting.

## **HYDRAULIC OIL RESERVOIR AND HOSES**

- Check filters for clogged elements.
- 2. Check oil level in the reservoir.
- 3. Check all hoses for damage.



## **CARRIER BOOM AND CYLINDERS**

- 1. Check for structural defects, such as dents, bends, and weld cracks.
- 2. Check all pins and their retainers.
- 3. Check cylinder rods for damage, and check for leaks.

## SIDE SHIFT ASSEMBLY

- Check cylinder for leaks and damage.
- 2. Check linear bushings for damage and lubrication.
- 3. Check for structural defects.
- Check cylinder retaining pins.

## **ROTATION ASSEMBLY**

- 1. Check gear box for proper anchoring and bolt torque.
- Check gear-bearing bolt torque.
- 3. Check pinion gear/gear-bearing backlash.

# **TH15K160 - Inspection Chart**

	FREQUEN		FREQUENC	CY	
ITEM	DESCRIPTION	DAILY	WEEKLY	MONTHLY	
WALK-AROUND INSPECTION	Inspect for hydraulic leaks, loose parts and obvious structural member damage.				
*MOUNTING BOLTS	Check torque (power-wrench tight).				
ROTATION SYSTEM	Check for excessive backlash (play) between pinion gear and turntable gear-bearing. If there is excess play, use a feeler. gauge to measure the play and adjust the backlash if needed. See the parts manual for				
	clamp and body backlash specifications.				
*STRUCTURAL DAMAGE	Check for broken welds, fatigue cracks, structural defects, bends and dents.				
CONTROLS	Check for excessive wear and cleanliness.				
LEAKAGE	Check for hydraulic fluid leaks.				
*ROTATION SYSTEM MOUNTING BOLTS	Check torque of top and bottom gear-bearing bolts. (See Torque Data Chart)				
ELECTRICAL	Check remote controls, auxiliary lighting, etc. for proper function.				
	Check for deterioration, dirt and moisture.				
HYDRAULIC FLUID RESERVOIR	Check for proper oil level. (Carrier Vehicle)				
HYDRAULIC OIL	Check oil quality. (Carrier Vehicle)				
	Check for leakage on surface and at ends.				
HYDRAULIC HOSE	Check for blistering, deformation and abrasion.				
PUMP AND MOTOR	Check for loose bolts, leaks, unusual noises, vibration, reduced operating speed and excessive oil heating.				
HYDRAULIC FILTER	Check vacuum reading with engine running and PTO engaged. A vacuum of 8" of mercury or higher indicates an obstructed filter. (Carrier Vehicle)				
CONTROL VALVES	Check for leaks, cracks and slow return to neutral.				
*CYLINDERS	Check for leaks, scores, nicked or dented rods, dented cases, deformed pin bosses, rust on rod.				
CARRIER VEHICLE	Follow all inspection and maintenance procedures provided by the carrier vehicle manufacturer.				
* INDICATES A CRITICAL ITEM					

This page left intentionally blank

Parts 33 Section - 5

Section - 5 Parts


### **TH15K160 - Parts Ordering Information**

#### **GENERAL**

This section contains the exploded parts drawings, with accompanying parts lists, for the assemblies used on the Tirehand. These drawings are intended to be used for ordering parts only.

#### CYLINDER IDENTIFICATION

To ensure proper replacement parts are received, it is necessary to specify the complete number/letter sequence for any part request. You must include the part number stamped on the cylinder case when ordering parts



#### WELDMENT IDENTIFICATION


Each of the major weldments on the Tirehand bears a stamped part number. Any time a major weldment is replaced, you must specify the complete part number as stamped on the weldment. The locations of the part numbers are as shown below.

#### **ORDERING REPAIR PARTS**

When ordering replacement parts:


- Give the model number of the unit.
- 2. Give the serial number of the unit.
- Specify the complete part number. When ordering cylinder parts, or one of the main weldments, always give the stamped part number.
- 4. Give a complete description of the part.
- 5. Specify the quantity required.

<sup>\*</sup> Forklift style base shown in picture.



This page left intentionally blank

# TH15K160 - Sub Base Assembly (40727628)




HARDWARE IS CONTAINED IN KIT NO. 91727632

ITEM NO.	PART NO.	DESCRIPTION	QTY.		
1.	51726426	CYL-4.0/2.0 12.00S 23.00CC	1		
2.	52724902	BASE WELDMENT-SIDE SHIFTER	1		
3.	52727630	SUB BASE WLDMT-TH10K-20K	1		
4.	60030253	WEAR PAD-SIDE SHIFTER TH2557B	1		
5.	60117735	CAP-SIDE SHIFTER PIN TH2557B	4		
6.	60117737	PIN-TYPE F 3.50X23.94	2		
7.	60118798	PIN-TYPE A 1.50X 2.94 ( 2.44)	1		
8.	72053507	ZERK-STR THD .25-28	4		
9.	72060795	CAP SCR .50-13X 1.50 SH PLAIN	14		
10.	72063037	MACHY BUSHING 1.50X10 GA NR	2		
11.	72063056	WASHER .75 LOCK	16		
12.	72063116	WASHER .75 N FLAT H ASTMF436Z	18		
13.	72066132	RETAINING RING-EXT 1.50 HD	2		
14.	72601485	CAP SCR .75-10X 1.50 HH GR8 Z	17		
15.	72602157	CAP SCR .75-10X 6.75 HH GR8 Z	18		
REV. INITIAL	REV. INITIAL RELEASE CN883				

This page left intentionally blank


# TH15K135 - Sub Base Asm w/o Side Shift (40727629)



HARDWARE IS CONTAINED IN KIT NO. 91727636


ITEM NO.	PART NO.	DESCRIPTION	QTY.			
1.	52727631	SUB BASE WLDMT-TH10K-20K WO SIDE SHIFT	1			
2.	72063116	WASHER .75 N FLAT H ASTMF436Z	18			
3.	72602157	CAP SCR .75-10X 6.75 HH GR8 Z	18			
REV. INITIAL	REV. INITIAL RELEASE CN883					

# TH15K135 - Body Assembly, Motor Rotation (40727614)



ITEM NO.	PART NO.	DESCRIPTION	KIT NO.	QTY.
1.	52727612	BODY-WLDMT TH15K MOTOR ROT		1
2.	52727613	WLDMT-MOTOR COVER TH10-15K		2
3.	53000713	GREASE EXT-38.00 OAL 36.00HOSE		1
4.	60010844	GREASE PLATE-DRIVE GEAR		1
5.	60105964	SUPPORT PLT-PINION		1
6.	60106032	STUD50-13X1.75	37	2
7.	60146492	COVER-TH10K-15K ROT. GEAR - PINION SIDE		1
8.	52727912	WLDMT-COVER-TH10K-15K ROT. GEAR - PINION SIDE		1
9.	60146491	COVER-TH10K-15K ROT. GEAR - MOTOR SIDE		1
10.	60146001	BRACKET-BULKHEAD MOUNT TH10K-TH15K		1
11.	70055409	GEAR-TURNTABLE BEARING TH20K		1
12.	71056073	GEAR-PINION 301-10052-1		1
13.	71056264	GEAR-INTMD 301-10103-1		1
14.	72053508	ZERK-NPT .12	37	1
15.	72053561	ZERK-NPT .12X90 DEG	37	2
16.	72060008	CAP SCR .25-20X 2.00 HH GR5 Z	38	2
17.	72060029	CAP SCR .31-18X 2.00 HH GR5 Z	37	2
18.	72060046	CAP SCR .38-16X 1.00 HH GR5 Z	38	6
19.	72060050	CAP SCR .38-16X 2.00 HH GR5ZC	37	4
20.	72060101	CAP SCR .50-13X 5.00 HH GR5 Z	37	24
21.	72060117	CAP SCR .50-13X 1.50 HH GR8 Z	37	2
22.	72062080	NUT .50-13 HEX NYLOCK	37	2
23.	72062103	NUT .38-16 HEX NYLOCK	38	4
24.	72062104	NUT .25-20 HEX NYLOCK	38	2
25.	72062109	NUT .31-18 HEX NYLOCK	37	2
26.	72063003	WASHER .38 FLAT	37, 38	14
27.	72063039	MACHY BUSHING 2.00X10 GA NR		1
28.	72063051	WASHER .38 LOCK	38	6
29.	72063053	WASHER .50 LOCK	37	26
30.	72063116	WASHER .75 N FLAT H ASTMF436Z	37	23
31.	72063117	WASHER .56 FLAT ASTM F436	37	4
32.	72066095	RETAINING RING-EXT 2.00 STD	37	1
33.	72531130	ELBOW-STREET STL .12 X 90 DEG	37	1
34.	72601144	CAP SCR .56-12X 2.00 HH GR8 Z	37	4
35.	72601468	CAP SCR .75-10X 4.50 HH GR8 Z	37	23
36.	73054614	FLOW DIV-COMB-FD50-45-8DD-N-66	38	1
37.	91727615	KIT-HRDW TH15K BODY ASM MOTOR ROT		1
38.	91727622	HYD KIT-TH15K MOTOR ROTATION		1
39.	73054829	FLOW DIV-ROT GEAR GD-07BB00G0	38	1
40.	73540004	MOTOR ASM W/ CB 103-3085-012		1
41.	72531098	ELBOW-STL .12 X 90 DEG	37	1
42.	72053000	NIPPLE-PIPE BLK .12X CLOSE	37	1
REV. C	•	·		


#### 40727614-2



### 40727614-2 PARTS LIST

ITEM NO.	PART NO.	DESCRIPTION	KIT NO.	QTY.
1.	52727612	BODY-WLDMT TH15K MOTOR ROT		1
2.	52727613	WLDMT-MOTOR COVER TH10-15K		2
3.	53000713	GREASE EXT-38.00 OAL 36.00HOSE		1
4.	60010844	GREASE PLATE-DRIVE GEAR		1
5.	60105964	SUPPORT PLT-PINION		1
6.	60106032	STUD50-13X1.75	37	2
7.	60146492	COVER-TH10K-15K ROT. GEAR - PINION SIDE		1
8.	52727912	WLDMT-COVER-TH10K-15K ROT. GEAR - PINION SIDE		1
9.	60146491	COVER-TH10K-15K ROT. GEAR - MOTOR SIDE		1
10.	60146001	BRACKET-BULKHEAD MOUNT TH10K-TH15K		1
11.	70055409	GEAR-TURNTABLE BEARING TH20K		1
12.	71056073	GEAR-PINION 301-10052-1		1
13.	71056264	GEAR-INTMD 301-10103-1		1
14.	72053508	ZERK-NPT .12	37	1
15.	72053561	ZERK-NPT .12X90 DEG	37	2
16.	72060008	CAP SCR .25-20X 2.00 HH GR5 Z	38	2
17.	72060029	CAP SCR .31-18X 2.00 HH GR5 Z	37	2
18.	72060046	CAP SCR .38-16X 1.00 HH GR5 Z	38	6
19.	72060050	CAP SCR .38-16X 2.00 HH GR5ZC	37	4
20.	72060101	CAP SCR .50-13X 5.00 HH GR5 Z	37	24
21.	72060117	CAP SCR .50-13X 1.50 HH GR8 Z	37	2
22.	72062080	NUT .50-13 HEX NYLOCK	37	2
23.	72062103	NUT .38-16 HEX NYLOCK	38	4
24.	72062104	NUT .25-20 HEX NYLOCK	38	2
25.	72062109	NUT .31-18 HEX NYLOCK	37	2
26.	72063003	WASHER .38 FLAT	37, 38	14
27.	72063039	MACHY BUSHING 2.00X10 GA NR		1
28.	72063051	WASHER .38 LOCK	38	6
29.	72063053	WASHER .50 LOCK	37	26
30.	72063116	WASHER .75 N FLAT H ASTMF436Z	37	23
31.	72063117	WASHER .56 FLAT ASTM F436	37	4
32.	72066095	RETAINING RING-EXT 2.00 STD	37	1
33.	72531130	ELBOW-STREET STL .12 X 90 DEG	37	1
34.	72601144	CAP SCR .56-12X 2.00 HH GR8 Z	37	4
35.	72601468	CAP SCR .75-10X 4.50 HH GR8 Z	37	23
36.	73054614	FLOW DIV-COMB-FD50-45-8DD-N-66	38	1
37.	91727615	KIT-HRDW TH15K BODY ASM MOTOR ROT		1
38.	91727622	HYD KIT-TH15K MOTOR ROTATION		1
39.	73054829	FLOW DIV-ROT GEAR GD-07BB00G0	38	1
40.	73540004	MOTOR ASM W/ CB 103-3085-012		1
41.	72531098	ELBOW-STL .12 X 90 DEG	37	1
42.	72053000	NIPPLE-PIPE BLK .12X CLOSE	37	1
REV. C	•	•		


### 40724614-3



#### 40727614-3

ITEM NO.	PART NO.	DESCRIPTION	KIT NO.	QTY.
1.	52727612	BODY-WLDMT TH15K MOTOR ROT		1
2.	52727613	WLDMT-MOTOR COVER TH10-15K		2
3.	53000713	GREASE EXT-38.00 OAL 36.00HOSE		1
4.	60010844	GREASE PLATE-DRIVE GEAR		1
5.	60105964	SUPPORT PLT-PINION		1
6.	60106032	STUD50-13X1.75	37	2
7.	60146492	COVER-TH10K-15K ROT. GEAR - PINION SIDE		1
8.	52727912	WLDMT-COVER-TH10K-15K ROT. GEAR - PINION SIDE		1
9.	60146491	COVER-TH10K-15K ROT. GEAR - MOTOR SIDE		1
10.	60146001	BRACKET-BULKHEAD MOUNT TH10K-TH15K		1
11.	70055409	GEAR-TURNTABLE BEARING TH20K		1
12.	71056073	GEAR-PINION 301-10052-1		1
13.	71056264	GEAR-INTMD 301-10103-1		1
14.	72053508	ZERK-NPT .12	37	1
15.	72053561	ZERK-NPT .12X90 DEG	37	2
16.	72060008	CAP SCR .25-20X 2.00 HH GR5 Z	38	2
17.	72060029	CAP SCR .31-18X 2.00 HH GR5 Z	37	2
18.	72060046	CAP SCR .38-16X 1.00 HH GR5 Z	38	6
19.	72060050	CAP SCR .38-16X 2.00 HH GR5ZC	37	4
20.	72060101	CAP SCR .50-13X 5.00 HH GR5 Z	37	24
21.	72060117	CAP SCR .50-13X 1.50 HH GR8 Z	37	2
22.	72062080	NUT .50-13 HEX NYLOCK	37	2
23.	72062103	NUT .38-16 HEX NYLOCK	38	4
24.	72062104	NUT .25-20 HEX NYLOCK	38	2
25.	72062109	NUT .31-18 HEX NYLOCK	37	2
26.	72063003	WASHER .38 FLAT	37, 38	14
27.	72063039	MACHY BUSHING 2.00X10 GA NR		1
28.	72063051	WASHER .38 LOCK	38	6
29.	72063053	WASHER .50 LOCK	37	26
30.	72063116	WASHER .75 N FLAT H ASTMF436Z	37	23
31.	72063117	WASHER .56 FLAT ASTM F436	37	4
32.	72066095	RETAINING RING-EXT 2.00 STD	37	1
33.	72531130	ELBOW-STREET STL .12 X 90 DEG	37	1
34.	72601144	CAP SCR .56-12X 2.00 HH GR8 Z	37	4
35.	72601468	CAP SCR .75-10X 4.50 HH GR8 Z	37	23
36.	73054614	FLOW DIV-COMB-FD50-45-8DD-N-66	38	1
37.	91727615	KIT-HRDW TH15K BODY ASM MOTOR ROT		1
38.	91727622	HYD KIT-TH15K MOTOR ROTATION		1
39.	73054829	FLOW DIV-ROT GEAR GD-07BB00G0	38	1
40.	73540004	MOTOR ASM W/ CB 103-3085-012		1
41.	72531098	ELBOW-STL .12 X 90 DEG	37	1
42.	72053000	NIPPLE-PIPE BLK .12X CLOSE	37	1
REV. C			<u> </u>	

# TH15K160 - Hyd Kit, Motor Rotation (91727622)




ITEM NO.	PART NO.	DESCRIPTION	KIT NO.	QTY.
1.	91727624	HOSE KIT-15K VALVE BANK MOTOR ROT	-	1
2.	91727654	HRDW KIT-TH15K W/VALVE BANK	-	1
3.	73540632	VALVE BANK-5-SECT PSL2 TH10-15K MTRBR 24	-	1
4.	60140348	MTG BRKT-VALVE BANK TH5K - TH20K	_	1
5.	73054614	FLOW DIV-COMB-FD50-45-8DD-N-66	_	1
6.	73054829	FLOW DIV-ROT GEAR GD-07BB00G0	_	1
7.	72060008	CAP SCR .25-20X 2.00 HH GR5 Z	2	2
8.	72060046	CAP SCR .38-16X 1.00 HH GR5 Z	2	4
9.	72060050	CAP SCR .38-16X 2.00 HH GR5 Z	2	4
10.	72062103	NUT .38-16 HEX GR5 Z NYLOCK	2	4
11.	72062104	NUT .25-20 HEX GR5 Z NYLOCK	2	2
12.	72063003	WASHER-FLAT .38 W ANSI B27.2 Z	2	12
13.	72063051	WASHER-LOCK .38 ZINC	2	4
14.	72601278	CAP SCR M 8-1.25X 20 HHZ	2	3
15.	72601797	WASHER-LOCK M 8	2	3
16.	72601799	WASHER-FLAT M 8 N	2	3
17.	72053758	ELBOW-M STR/90/M JIC 4 4	1	2
18.	72053762	ELBOW-M STR/90/M JIC 6 8	1	1
19.	72053763	ELBOW-M STR/90/M JIC 8 8	1	5
20.	72532356	ADPTR-M STR/M JIC 8 6	1	2
21.	72532358	ADPTR-M STR/M JIC 8 8	1	11
22.	72532360	ADPTR-M STR/M JIC 12 8	1	2
23.	72532658	ELBOW-M JIC/90/F JIC SW 8 8	1	3
24.	72532690	ELBOW-M JIC/90/F JIC SW 4 4	1	2
25.	72532772	ELBOW-M JIC/90/F JIC SW 6 6	1	4
26.	72532775	ADPTR-M STR/M JIC 4 6	1	2
27.	72532779	ELBOW-M STR/90/M JIC XLG 6 8	1	1
28.	72532792	ADPTR-M STR/M JIC 8 4	1	4
29.	72532963	ADPTR-M STR/F STR 16 8	1	1
30.	72533024	UNION-BULKHEAD JIC 4 (7/16-20)	1	4
31.	72533050	TEE-BULKHEAD RUN .44 JIC	1	2
32.	72533373	UNION-BULKHEAD JIC 8 (3/4-16)	1	4
33.	72533591	TEE-BULKHEAD RUN .75 (8)	1	2
34.	72533594	ELBOW-M STR/90/M JIC 4 6	1	4
35.	72534858	TEE-STL STR/JIC/JIC 4 6 6 RUN	1	4
36.	51394008	HOSE-FF .25 X 93.00 (4-4) 100R2	1	4
37.	51394035	HOSE-FF .25 X 38.00 (4-4) 100R2	1	4
38.	51395574	HOSE-FJ .25 X 28.50 (4-4) 100R2	1	2
39.	51395887	HOSE-FJ .38 X 17.50 (6-6) 100R17	1	4
40.	51395900	HOSE-FF .50 X 70.00 (8-8) 100R17	1	2
41.	51396212	HOSE-FF .50 X 93.00 (8-8) 100R17	1	4
42.	51396230	HOSE-FJ .50 X 92.00 (8-8) 100R17	1	1
43.	51397082	HOSE-FJ .50 X 31.00 (8-8) 100R17	1	2
44.	51399714	HOSE-FJ .50 X 50.00 (8-8) 100R17	1	5
45.	51490072	HOSE-FF .38 X 55.00 (6-8) 100R2	1	4
46.	51490073	HOSE-FF .38 X 30.00 (6-6) 100R17	1	2
	1	1		

ITEM NO.	PART NO.	DESCRIPTION	KIT NO.	QTY.	
47,.	70733889	CABLE ASM-33ft BATT & RADIO ELIMINATION	-	1	
48,.	70734590	TRANSM-RAD REM TH3565 5K-36K	1	1	
49.	70734591	RECEIVER-RAD REM TH3565 5K-36K	-	1	
50.	77441524	HARNESS-TIREHAND RADIO REMOTE TH5k-TH36k	-	1	
51.	77441525	HARNESS-TIREHAND CHASS INTERFACE TH5k-36	-	1	
REV. INITIAL	REV. INITIAL RELEASE CN883				

This page left intentionally blank

### TH15K160 - Hyd Kit, Motor Rotation, No Valve Bank (91727651)




# NOTES:

- 1. Side shift cylinder: extend = hand left.
  - 2. Clamp cylinders: extend = clamp.
- 3. Fallback cylinders: extend = deploy.

ITEM NO.	PART NO.	DESCRIPTION	KIT NO.	QTY.
1.	91727658	HOSE KIT-15K W/O VALVE BANK MOTOR ROT	-	1
2.	91727656	HRDW KIT-TH15K W/O VALVE BANK	-	1
3.	73054614	FLOW DIV-COMB-FD50-45-8DD-N-66	-	1
4.	73054915	FLOW DIV-ROT GEAR GD-07BB00GV	-	1
5.	72060008	CAP SCR .25-20X 2.00 HH GR5 Z	2	2
6.	72060050	CAP SCR .38-16X 2.00 HH GR5 Z	2	4
7.	72062103	NUT .38-16 HEX GR5 Z NYLOCK	2	4
8.	72062104	NUT .25-20 HEX GR5 Z NYLOCK	2	2
9.	72063003	WASHER-FLAT .38 W ANSI B27.2 Z	2	8
10.	72053758	ELBOW-M STR/90/M JIC 4 4	1	2
11.	72053762	ELBOW-M STR/90/M JIC 6 8	1	1
12.	72053763	ELBOW-M STR/90/M JIC 8 8	1	5
13.	72532358	ADPTR-M STR/M JIC 8 8	1	4
14.	72532360	ADPTR-M STR/M JIC 12 8	1	2
15.	72532658	ELBOW-M JIC/90/F JIC SW 8 8	1	3
16.	72532690	ELBOW-M JIC/90/F JIC SW 4 4	1	2
17.	72532772	ELBOW-M JIC/90/F JIC SW 6 6	1	4
18.	72532775	ADPTR-M STR/M JIC 4 6	1	2
19.	72532779	ELBOW-M STR/90/M JIC XLG 6 8	1	1
20.	72532792	ADPTR-M STR/M JIC 8 4	1	2
21.	72532963	ADPTR-M STR/F STR 16 8	1	1
22.	72533024	UNION-BULKHEAD JIC 4 (7/16-20)	1	4
23.	72533050	TEE-BULKHEAD RUN .44 JIC	1	2
24.	72533373	UNION-BULKHEAD JIC 8 (3/4-16)	1	4
25.	72533591	TEE-BULKHEAD RUN .75 (8)	1	2
26.	72533594	ELBOW-M STR/90/M JIC 4 6	1	4
27.	72534858	TEE-STL STR/JIC/JIC 4 6 6 RUN	1	4
28.	51394008	HOSE-FF .25 X 93.00 (4-4) 100R2	1	4
29.	51394035	HOSE-FF .25 X 38.00 (4-4) 100R2	1	4
30.	51395574	HOSE-FJ .25 X 28.50 (4-4) 100R2	1	2
31.	51395887	HOSE-FJ .38 X 17.50 (6-6) 100R17	1	4
32.	51395900	HOSE-FF .50 X 70.00 (8-8) 100R17	1	2
33.	51396212	HOSE-FF .50 X 93.00 (8-8) 100R17	1	4
34.	51396230	HOSE-FJ .50 X 92.00 (8-8) 100R17	1	1
35.	51397082	HOSE-FJ .50 X 31.00 (8-8) 100R17	1	2
36.	51399714	HOSE-FJ .50 X 50.00 (8-8) 100R17	1	5
37.	51490072	HOSE-FF .38 X 55.00 (6-8) 100R2	1	4
38.	51490073	HOSE-FF .38 X 30.00 (6-6) 100R17	1	2
REV. INITIA	L RELEASE C	N883	•	

# TH15K160 - Body Assembly (40724864) EFFECTIVE THROUGH 10/31/2018




### NOTES:

- 1. Use Loctite 277 on all 3 / 4" bolts.
- 2. Torque all 3 / 4" bolts to 280 ft-lb.


ITEM NO.	PART NO.	DESCRIPTION	KIT NO.	QTY.
1.	52724624	BODY-WLDMT TH15K	-	1
2.	52726400	WLDMT-TH20 BODY ROTATION BRKT	-	1
3.	53000713	GREASE EXT-38.00 OAL 36.00HOSE	-	4
4.	60117741	COVER PLATE- BODY	-	2
5.	60143602	BRACKET-BULKHEAD MOUNT TH10K-TH20K	-	1
6.	71056676	GEAR-TRNTBL BRG-20K TIREHAND 450-05327-1	-	1
7.	72053301	COUPLING-GLV .12 SCH 40	27	4
8.	72053508	ZERK-NPT .12	27	4
9.	72060008	CAP SCR .25-20X 2.00 HH GR5 Z	27	2
10.	72060029	CAP SCR .31-18X 2.00 HH GR5 Z	27	2
11.	72060038	CAP SCR .31-18X 4.50 HH GR5 Z	27	1
12.	72060050	CAP SCR .38-16X 2.00 HH GR5ZC	27	4
13.	72060092	CAP SCR .50-13X 1.25 HH GR5 Z	27	24
14.	72062103	NUT .38-16 HEX NYLOCK	27	4
15.	72062104	NUT .25-20 HEX NYLOCK	27	2
16.	72062109	NUT .31-18 HEX NYLOCK	27	3
17.	72063003	WASHER .38 FLAT	27	8
18.	72063053	WASHER .50 LOCK	27	24
19.	72063116	WASHER .75 N FLAT H ASTMF436Z	27	23
20.	72531130	ELBOW-STREET STL .12 X 90 DEG	-	4
21.	72534886	VALVE-FLOW CONTROL	REF	2
22.	72601466	CAP SCR .75-10X 5.00 HH GR8 Z	27	12
23.	72601624	CAP SCR .75-10X 6.00 HH GR8 Z	27	11
24.	73054614	FLOW DIV-COMB-FD50-45-8DD-N-66	REF	1
25.	73054829	FLOW DIV-ROT GEAR GD-07BB00G0	REF	1
26.	77045927	RETAINER-ZIP TIE ELEC HARNESS (BODIES)	27	2
27.	91724888	KIT-HRDW TH20K BODY ASM	-	1
REV. H <b>EFF</b>	ECTIVE THRO	UGH 10/31/2018		

# TH15K160 - Clamp Assembly (40726421)



ITEM NO.	PART NO.	DESCRIPTION	KIT NO.	QTY.
1.	0727614	BODY ASM-TH15K MOTOR ROT	-	1
2.	40726415	HAND ASM-TH20K	-	2
3.	51726428	CYL-3.0/1.5 5.00S 13.75 CC C	-	2
4.	51726419	CYL-4.0/2.5 19.25S 42.00CC C	-	2
5.	52711931	ARM WLDMT TIREHAND 2557B	-	2
6.	52724551	FLAG-WLDMT TH20K W-FALLBACK	-	2
7.	52724552	WLDMT-PIVOT, FALLBACK ARM	-	2
8.	52724762	ARM WLDMT TIREHAND 2557B	-	2
9.	60139297	PIN-TYPE H 2.50X19.00	-	8
10.	60139298	PIN-TYPE H 1.50 X 4.00	-	4
11.	60139307	COVER- FALL BACK CYL	-	2
12.	71415014	KEEPER-PIN .38	-	4
13.	71415017	KEEPER-PIN .75	-	8
14.	72060046	CAP SCR .38-16X 1.00 HH GR5 Z	23	4
15.	72060092	CAP SCR .50-13X 1.25 HH GR5 Z	23	16
16.	72060181	CAP SCR .75-10X 1.00 HH GR5 Z	23	2
17.	72060206	CAP SCR .75-10X 2.00 HH GR8 Z	23	8
18.	72063051	WASHER .38 LOCK	23	4
19.	72063053	WASHER .50 LOCK	23	16
20.	72063056	WASHER .75 LOCK	23	8
21.	72063116	WASHER .75 N FLAT H ASTMF436Z	23	2
22.	72601989	CAP SCR .75-10X 1.25 HH GR8 Z	23	2
23.	91726420	KIT-HRDW TH10K-TH20K CLAMP ASM	-	1
REV. B CN	857			

# TH15K160 - Hand Assembly (40726415)




**DETAIL: GEAR TRAIN** 

#### NOTE:

- 1. Use loctite 277 on all 5/8" bolts.
- 2. Torque all 5/8" bolts to 160 ft-lb
- 3. Apply loctite 242 on bolts marked with.\*
- 4. Install turntable bearing where.

ITEM NO.	PART NO.	DESCRIPTION	KIT NO.	QTY.
1.	52724549	HAND WLDMT-TH20K	-	1
2.	52724550	CLAW-WLDMT TH20K	-	1
3.	53000700	GREASE EXT- 8.00 OAL 6.00HOSE	-	1
4.	60030468	SPACER- INTERMEDIATE GEAR	-	2
5.	60106032	STUD50-13X1.75	32	4
6.	60139294	GEAR GUARD-20K TH TIP	-	1
7.	60139295	COVER- TH INTERMEDIATE GEAR	-	2
8.	60139308	PLATE-GREASE	-	2
9.	60139309	COVER-ACCESS HOLE CLAW	-	1
10.	60140334	COVER-PINION GEAR	-	2
11.	71056264	GEAR-INTMD 301-10103-1	-	2
12.	71056265	GEAR-PINION 301-10104-1	-	2
13.	71056389	GEAR-TRNTBL BRG 449-05190-1	-	1
14.	72053508	ZERK-NPT .12	32	5
15.	72053638	ADPTR-MPT/FPT SWVL .12 .12	-	1
16.	72060091	CAP SCR .50-13X 1.00 HH GR5 Z	32	4
17.	72060092	CAP SCR .50-13X 1.25 HH GR5 Z	32	7
18.	72060738	CAP SCR .31-18 2.50 SH PLAIN	32	8
19.	72060793	CAP SCR .50-13X 1.00 SH ZINC	32	4
20.	72060833	SCR-THRD.CUT .31-18X.75 HWH-1	32	4
21.	72060931	CAP SCR .62-11X 2.75 HH GR8 Z	32	16
22.	72062080	NUT .50-13 HEX NYLOCK	32	4
23.	72063002	WASHER .31 FLAT	32	4
24.	72063005	WASHER .50 FLAT	32	3
25.	72063038	MACHY BUSHING 2.00X14 GA NR	32	2
26.	72063053	WASHER .50 LOCK	32	15
27.	72063119	WASHER .62 FLAT ASTM F436	32	28
28.	72066095	RETAINING RING-EXT 2.00 STD	32	2
29.	72601482	CAP SCR .62-11X 2.50 HH GR8 Z	32	12
30.	73511285	MOTOR ASM W/ CB VALVE	-	2
31.	7Q072112	O RING .50X .69X .09 70	32	4
32.	91726416	KIT-HRDW TH20K HAND ASM	-	1
33.	73511286	MOTOR-HYD 151-2477	30	2
34.	73540008	VALVE BLK-DBL 12 gpm .44-20SAE	30	2
35.	73051941	VALVE-CBAL 02-371063 (CBCH-LJN)	30	4
36.	60020181	BUSHING-B148 ROTATION	1	2
37.	60020182	BUSHING-B148 ROTATION	1	2
38.	60020246	BUSHING-BRZ 1.50X 2.25X 0.94	1	2
39.	60020247	BUSHING-BRZ 1.50X 2.25X 1.00	1	2
REV. D				


# TH15K160 - Cylinder (51724677)



USE SEAL KIT NUMBER: 71415915

ITEM NO.	PART NO.	DESCRIPTION	QTY.
1.	70055370	BEARING - CASE	2
2.	70055402	BEARING - ROD	1
REV. B			


# TH15K160 - Cylinder (51726428)



USE SEAL KIT NUMBER: 94399967

ITEM NO.	PART NO.	DESCRIPTION	QTY.
1.	73540621	VALVE-CBAL	2
REV. A			

### TH15K160 - Cylinder (51726426)




USE SEAL KIT NUMBER: 9B015930

ITEM NO.	PART NO.	DESCRIPTION	QTY.		
1.	73054242	VALVE-CBAL	2		
REV. INITIAL RELEASE					

#### **NOTES:**

- Apply never-seez regular grade anti-seez and lubricating compound to threads on the cylinder head only, keep away from all seals.
- Apply lubriplate no. 630-2 Medium heavy, multi-purpose lubricant, to all piston, head gland, and holding valve seals, nylon lock ring, cast iron piston rings, and rod stinger threads.

### TH15K160 - Cylinders (51726419)




USE SEAL KIT NUMBER: 9C160920

ITEM NO.	PART NO.	DESCRIPTION	QTY.		
1.	73540622	VALVE-CBAL	1		
2.	70034283	BEARING	4		
REV. INITIAL RELEASE					

#### **NOTES:**

- Apply never-seez regular grade anti-seez and lubricating compound to threads on the cylinder head only, keep away from all seals.
- Apply lubriplate no. 630-2 Medium heavy, multi-purpose lubricant, to all piston, head gland, and holding valve seals, nylon lock ring, cast iron piston rings, and rod stinger threads.

# TH15K160 - Valve Bank (73540632)




CONNECTION PORTS
P, P1, R, R1 = SAE-8
LS, M, Z = SAE-4
A, B = SAE-8
T. Y = SAE-4

#### **TYPE CODE**

- PSL UNF 2H1/D200-2
- A5 H40/40 /EA1 /UNF 2
- A5 O40/40 /EA1 /UNF 2
- A2 O16/16 /EA1 /UNF 2
- A5 O40/40 /EA1 /UNF 2
- A2 O25/25 /EA1 /UNF


# TH15K160 - Hydraulic Kit W/Valve Bank (91724924)




NOTES:
SIDE SHIFT CYLINDER - EXTEND EQUALS HAND LEFT
BODY ROTATION CYLINDER - EXTEND EQUALS HAND CLOCKWISE
CLAMP CYLINDERS - EXTEND EQUALS CLAMP
FALLBACK CYLINDERS - EXTEND EQUALS DEPLOY

ITEM NO.	PART NO.	DESCRIPTION	QTY.
1.	73540533	VALVE BANK	1
2.	60140348	MOUNTING BRACKET-VALVE BANK	1
3.	72601278	CAP SCR M 8-1.25X 20 HHZ	3
4.	72601797	LOCK WASHER 8 MM	3
5.	72601799	WASHER 8 MM	3
6.	72060047	CAP SCR .38-16X 1.25 HH GR5 Z	4
7.	72063051	WASHER-LOCK .38 ZINC	4
8.	72063003	WASHER-FLAT .38 W ANSI B27.2 Z	12
9.	72060050	CAP SCR .38-16X 2.00 HH GR5 Z	4
10.	72062103	NUT .38-16 HEX GR5 Z NYLOCK	4
11.	72532358	ADAPTER, #8 MALE STR/#8 MALE JIC	19
12.	72532792	ADPTR-M STR/M JIC 8 4	4
13.	72053763	ELBOW, #8 MALE JIC/90"/#8 M STR	5
14.	73054829	FLOW DIVIDER	1
15.	73054614	FLOW DIVIDER	1
16.	72532963	ADAPTER, #16 MALE STR/#8 FEMALE STR	1
17.	72532360	ADAPTER, #12 MALE STR/#8 MALE JIC	2
18.	72532779	ELBOW-M STR/90/M JIC XLG 6 8	1
19.	72053762	ELBOW-M STR/90/M JIC 6 8	1
20.	72053758	ELBOW, M STR/M JIC #4	2
21.	72533024	UNION-BULKHEAD JIC 4 (7 /16-20)	4
22.	72533050	TEE-BULKHEAD RUN .44 JIC	2
23.	72533591	TEE-BULKHEAD RUN .75 (8)	2
24.	72533373	UNION-BULKHEAD JIC 8 (3/4-16)	4
25.	72534858	TEE-STL STR/JIC/JIC 4 6 6 RUN	4
26.	72533594	ELBOW-M STR/90/M JIC 4 6	4
27.	72532772	ELBOW-M JIC/90/F JIC SW 6 6	4
28.	51395574	HOSE-FJ .25 X 28.50 (4-4)	2
29.	51394008	HOSE-FF .25 X 93.00 (4-4)	4
30.	51394035	HOSE-FF .25 X 38.00 (4-4) 100R2	4
31.	51399714	HOSE-FJ .50 X 50.00 (8-8)	5
32.	51395900	HOSE-FF .50 X 70.00	2
33.	51396230	HOSE-FJ .50 X 92.00	1
34.	51396828	HOSE-FJ .50 X 27.00 (8-8)	2
35.	51392461	HOSE-FF .50 X 25.00 (8-8) 100R2	2
36.	51397082	HOSE-FJ .50 X 31.00 (8-8)	2
37.	51396212	HOSE-FF .50 X 93.00 (8-8) 100R17	4
38.	51490072	HOSE-FF .38 X 55.00 (6-8) 100R2	4
39.	51395887	HOSE-FJ .38 X 17.50 (6-6)	4
40.	72534886	VALVE-FLOW CONTROL	2
41.	72532658	ELBOW-M JIC/90/F JIC SW 8 8	3
42.	72532690	ELBOW-M JIC/90/F JIC SW 4 4	2
43.	70733889	CABLE ASM-33ft BATT & RADIO ELIMINATION	1
REV.F CN80	00 EFFECTIVE	THROUGH 10/31/2018	

### TH15K160 - Valve Bank (73540533) EFFECTIVE THROUGH 10/31/2018






Porting
A, B, P, R = SAE -8
LS, M, T, Y, Z = SAE -4

This page left intentionally blank

### TH15K160 - Hydraulic Kit w/o Valve Bank (91724925)

#### EFFECTIVE THROUGH 10/31/2018



HOSE KIT: 51724979 HARDWARE KIT: 91724977

#### **NOTES:**

- Side shift cylinder extend equals hand left.
- Body rotation cylinder extend equals hand clockwise.
- · Clamp cylinders extend equals clamp.
- Fallback cylinders extend equals deploy.

#### **91724925 PARTS LIST**

ITEM NO.	PART NO.	DESCRIPTION	QTY.
1.	70354915	FLOW DIVIDER	1
2.	73054614	FLOW DIVIDER	2
3.	72063003	WASHER-FLAT .38 W ANSI B27.2 Z	4
4.	72060050	CAP SCR .38-16X 2.00 HH GR5 Z	4
5.	72062103	NUT .38-16 HEX GR5 Z NYLOCK	2
6.	72532358	ADAPTER, #8 MALE STR/#8 MALE JIC	2
7.	72053763	ELBOW, #8 MALE JIC/90"/#8 M STR	2
8.	72532963	ADAPTER, #16 MALE STR/#8 FEMALE STR	1
9.	72532360	ADAPTER, #12 MALE STR/#8 MALE JIC	2
10.	72532779	ELBOW-M STR/90/M JIC XLG 6 8	1
11.	72053762	ELBOW-M STR/90/M JIC 6 8	4
12.	72053758	ELBOW, M STR/M JIC #4	4
13.	72532792	ADAPTER, M STR/M JIC 8 4	4
14.	72533024	UNION-BULKHEAD JIC 4 (7 /16-20)	2
15.	72533050	TEE-BULKHEAD RUN .44 JIC	4
16.	72533591	TEE-BULKHEAD RUN .75 (8)	4
17.	72533373	UNION-BULKHEAD JIC 8 (3/4-16)	2
18.	72534858	TEE-STL STR/JIC/JIC 4 6 6 RUN	4
19.	72533594	ELBOW-M STIR/90/M JIC 4 6	4
20.	72532772	ELBOW-M JIC/90/F JIC SW 6 6	4
21.		HOSE25 X xx (4-4)	2
22.	51394008	HOSE-FF .25 X 93.00 (4-4)	4
23.	51394035	HOSE-FF .25 X 38.00 (4-4) 100R2	4
24.		HOSE50 X xx (8-8)	4
25.	51399714	HOSE-FJ .50 X 50.00 (8-8)	1
26.	51395900	HOSE-FF .50 X 70.00	2
27.	51713837	HOSE-FJ .50 X 93.00 (8-8) 100R2	1
28.		HOSE50 X xx (8-8)	2
29.	51392461	HOSE-FF .50 X 25.00 (8-8) 100R2	2
30.		HOSE50 X xx (8-8)	2
31.	51394000	HOSE-FF .50 X 95.00 (8-8) 100R2	4
32.	51490072	HOSE-FF .38 X 55.00 (6-8) 100R2	4
33.	51395887	HOSE-FJ .38 X 17.50 (6-6)	4
34.	72534886	VALVE-FLOW CONTIROL	2
35.	72532658	ELBOW-M JIC/90/F JIC SW 8 8	1
REV. C EFFEC	TIVE THROUGH	10/31/2018	

**NOTE:** Items shown are common service items, for part numbers not assigned contact:


IOWA MOLD TOOLING CO., INC. TECHNICAL SUPPORT TEAM TELEPHONE: 800-554-4421

This page left intentionally blank


Section - 6

**Electrical & Lighting** 


# TH15K160 - Harness (77441525)




# TH15K160 - Radio Remote Harness (77441524)



#### 77441524-1



# TH15K160 - Chassis Interface Harness (77441525)



#### 77441525-1 RADIO REMOTE HARNESS


	CP-600 TIREHAND CONNECTOR	
POWER 1————		W1 POWER
GROUND 2		W2 GROUND
LIGHT GROUND 3		W3 LIGHT GROUND
LIGHT POWER 4		W4 LIGHT POWER
CRANE HOURMETER 5		W5 CRANE HOURMETER
N/C 6		

This page left intentionally blank

Section - 7

**General Information** 

# TH15K160 - Decal Kit (95724919)



**NOTE:** This drawing denotes the location of the decals only. It does not identify the individual models. The appearance of the tirehand may be different than shown.

### **95724919 PARTS LIST**

ITEM NO.	PART NO.	DESCRIPTION	QTY.
1.	70029119	PLACARD-SERIAL NUMBER	1
2.	70391612	DECAL-GREASE WEEKLY (LEFT)	14
3.	70391613	DECAL-GREASE WEEKLY (RIGHT)	15
4.	70392524	DECAL-ROTATE CRANE WHILE GREASE	5
5.	70393671	DECAL-TH OPERATION WARNINGS	2
6.	70393672	DECAL-DANGER TH OPERATION	2
7.	70398903	DECAL-DIAMOND IMT 5.00X10.00-REFLECTIVE	2
8.	72661638	TACK-METAL	2
9.	70399423	DECAL-CP TH15K160	2
10.	70399422	DECAL-IDENT TH15K160	2
REV. A			

# TH15K160 - Troubleshooting

SYMPTOM	PROBABLE CAUSE
	E-stop on remote pressed in.
	Remote not turned on.
	Pump not engaged - if supplied with electric clutch
Overhold foliate encountry	Hydraulic oil supply is low.
Controls fail to respond	Hydraulic pressure line is ruptured.
	Suction line shut-off valve is obstructed.
	Faulty hydraulic pump.
	Incorrectly set relief valve.
	Hydraulic oil supply is low.
	Hydraulic pump is operating at a reduced speed.
	Relief valve is set too low.
	Pump or cylinder is worn.
Operation slows down.	Pump is slipping due to excessive oil temperature.     (This is a factor which will increase with worn components.)
	Dirty filter.
	Inoperative valve spools.
	Obstructed cylinder holding valve.
Rotation control slowed or erratic.	Internal port orifices are clogged.
Rotation control slowed of effatic.	Rotation gears are locked or damaged.
Arms and nada drift when loaded and	Hydraulic oil is bypassing at piston rings.
Arms and pads drift when loaded and controls neutralized.	Cylinder holding valves are defective or contaminated.
	Pump captivation due to low hydraulic oil supply.
	Loading is excessive.
	Restriction or collapse of suction line.
Unusual noise in operation.	Bypass settings on relief valve are too low.
	Relief valve is damaged.
	Valve closure is obstructed due to particle accumulation.
	Bearings need lubrication.
Side step chatters or slows.	Mechanical damage to bracket
	Lower cylinder damaged.
A was also than an in air a	Arms need both internal and external lubrication.
Arm chatter or noise.	Bearing damaged.

### TH15K160 - Cylinders

The Tirehand uses similar cylinders in all functions. Common disassembly and repair instructions apply. Check the Parts section for specific information.

#### **CLAMP CYLINDER REMOVAL & INSTALLATION**

#### To remove the clamp cylinder:

- 1. Rotate the Tirehand until the clamp cylinder is in a horizontal position.
- 2. Extend the cylinder full stroke.
- 3. Shut off the carrier vehicle's engine. Relieve the internal hydraulic pressure by cycling the controls.
- 4. Remove the cover from the body (refer to the appropriate body drawing) and disconnect the hydraulic hoses at the cylinder port block. Cap the hydraulic hoses.
- 5. Support the hand assembly with a lifting device and straps capable of supporting the assembly. Take up slack in the lifting device.
- 6. Disconnect and cap any hydraulic lines leading to the pad rotation mechanism.
- 7. Remove the cylinder rod pin by removing the 3/4-10 cap screws and washer securing the pin. Drive out the pin.
- 8. Support the hand assembly. Remove the two smaller hand/arm pins by removing the 3/4-10 cap screws securing the pins. Drive out the pins.
- 9. Lift the hand assembly away and place on a clean surface. Keep dirt out of the bushing surfaces.
- 10. Support the clamp cylinder with a lifting device and straps capable of supporting the cylinder.
- 11. Remove the cylinder base pin securing screw and washer. Drive the pin only far enough to release the cylinder.
- 12. Lift the cylinder away and repair as necessary.

#### To install the clamp cylinder:

- 1. Position the cylinder in the slings of the lifting device and line up the base end pin boss and pin. Seat the pin and secure using the 3/4-10 cap screw and washer. Torque to 265 ft-lb (36.6 kg-m).
- 2. Lift the hand assembly with the slings and position the pin bosses in line with the pins. Drive in the pins and secure using the 3/4-10 hardware. Torque to 265 ft-lb (36.6 kg-m).
- 3. Connect the hydraulic hoses to the clamp cylinder and axial rotation motor.
- 4. Start the engine. Cycle the CLAMP and PAD controls through at least five cycles to purge any air trapped in the system. Check for leaks.
- 5. Check the hydraulic fluid level with all cylinders retracted. Fill if necessary.
- 6. Test the unit with a simulated job operation before proceeding to the job site.

#### SIDE SHIFT CYLINDER REMOVAL AND INSTALLATION

#### To remove the side shift cylinder:

- 1. Rotate the Tirehand so that the side shift cylinder is in a horizontal position.
- 2. Disconnect the hydraulic hoses from the cylinder port. Cap the hoses.
- 3. Remove the retaining rings and bushings from the rod end and base end of the cylinder. Drive out the pins.
- 4. Disassemble and repair the cylinder.

#### To install the cylinder:

- 1. Line up the cylinder base end pin boss with the holes in the base. Drive in the pin and install the machinery bushing and retaining ring.
- 2. Connect the hydraulic hoses to the cylinder port.
- 3. Extend and retract the cylinder until the rod-end pin boss lines up with the holes in the sub- base. Drive in the pin and install the machinery bushing and retaining ring.
- 4. Extend and retract the cylinder through five (5) complete cycles to purge air that may be trapped in the system. Check for leaks.
- 5. Check the hydraulic reservoir fluid level with all cylinders retracted. Fill if necessary.
- 6. Conduct a simulated job operation before proceeding to the job site.

### TH15K160 - Replacement Parts

#### **COUNTER BALANCE VALVES**

Counterbalance valves are considered non-repairable and must be replace if defective.

#### HYDRAULIC PUMP

The installer or manufacturer of the carrier vehicle must supply 12 gpm (45.4 Lpm) of hydraulic fluid at 3000 psi (207 bar).

## TH15K160 - Hydraulic Motors

Four hydraulic motors are used on the Tirehand: two for Tirehand rotation and one each side for pad rotation. These motors are not considered field repairable and should be replaced if defective.

#### HYDRAULIC MOTOR REMOVAL AND REPLACEMENT

#### To remove rotation motor:

- Disconnect and cap the hydraulic hoses.
- Remove the two motor mounting bolts.
- 3. Remove the counterbalance block and hose fittings from the old motor.

#### To install the new motor:

- 1. Install the counterbalance block and hose fittings from the old motor. Do not use the old o-rings, they should be replaced.
- 2. Position the motor on the base and install the two mounting bolts. Torque them to the proper value (See Torque Table).
- 3. Connect the hoses.
- 4. Start the engine, rotate the Tirehand five (5) times in both directions and check for leaks.
- With all cylinders retracted, check the fluid level in the reservoir and fill if necessary.

### TH15K160 - Relief Valve Adjustment

The hydraulic system is designed to operate at a pressure requirement of 3000 psi (207 bar) with an optimum oil flow of 12 gpm (45.4 Lpm). To adjust the relief valve:

- Start the vehicle and engage the pump.
- With the vehicle transmission in neutral, operate any function full stroke, and with function lever still
  engaged at end of stroke, read the pressure on the gauge at the control valve. It should read between
  3000 psi (207 bar).
- If the pressure reading is low, shut off the engine and adjust the relief valve. Loosen the nut on the relief
  valve adjustment screw, then turn the screw to adjust the pressure. Check the pressure, and continue
  adjustment if needed.

### TH15K160 - Bearings

This section includes instructions on the removal and installation of turntable gear-bearings and bushings.

#### TURNTABLE GEAR-BEARING

#### To remove the Tirehand rotation gear-bearing:

- 1. Disconnect and cap the hydraulic hoses from the valve bank.
- 2. Support the clamp arms with an overhead lifting device capable of supporting the weight of the unit. Take up the slack in the lifting device.
- Remove the cover, then remove the bolts that secure the body to the gear-bearing. Slowly work the
  hoses out of the rotation adapter while simultaneously withdrawing the body. Set the body carefully to
  one side.
- 4. Disconnect the grease fitting extension from the turntable gear-bearing.
- 5. Remove the gear-bearing mounting bolts and remove the gear bearing.

### **A** WARNING

The lifting device must be fastened to the tirehand in such a manner that will prevent shifting of the load due to slippage.

#### TO INSTALL THE GEAR-BEARING:

- 1. Position the gear-bearing and torque the mounting bolts (see Torque Table).
- 2. Install the grease fitting extension.
- 3. Carefully position the body and clamp arms until the holes in the body line up with the holes in the gear-bearing. Install the mounting bolts and torque to the proper value (see Torque Table).
- 4. Connect the hydraulic hoses to the valve bank.
- 5. Start the engine and cycle all of the Tirehand controls at least five (5) times in both directions to purge the air in the system.
- 6. Check the system for leaks and repair any that are found.
- 7. With all cylinders retracted, check the fluid level in the reservoir and fill if necessary.

#### **Axial Rotation Gear-Bearing:**


#### To remove the axial rotation gear-bearing:

- 1. Remove the pad mounting bolts.
- 2. Disconnect the grease fitting extension.
- 3. Remove the gear-bearing mounting bolts and remove the bearing.
- 4. Position the bearing so that the holes align with those in the arm. The grease fitting extension port must be toward the pinion gear. Install and torque the mounting bolts (see Torque Table).
- 5. Install the grease fitting extension.
- 6. Position the pad over the gear-bearing, install and torque the mounting bolts (see Torque Table).

#### **BUSHING REMOVAL AND INSTALLATION**

#### To replace a bushing:

- 1. Remove the weldment containing the bushing.
- 2. Position the bushing removal tool as shown and extract the bushing.
- 3. To install the bushing, assemble the tool as shown and press the bushing in.



Bushing removal illustration

Bushing installation illustration


## **TH15K160 - Turntable Bearing Inspection**

Turntable bearings may experience wear. One of the following conditions may indicate turntable bearing wear:

- Metal particles present in the bearing lubricant.
- 2. Increased drive power required to rotate the crane.
- 3. Noise emitting from the bearing during rotation.
- 4. Rough rotation.
- 5. Uneven or excessive wear between the pinion gear and turntable gear.

If one or more of the above conditions exists, further inspection may be required. Contact IMT for assistance.


# TH15K160 - Camera Kit Dual (40724922)



### **40724922 PARTS LIST**

ITEM NO.	PART NO.	DESCRIPTION	QTY.
1.		BODY-WLDMT	REF
2.	60136590	CAMERA MOUNT	2
3.	60139306	GUARD - CAMERA MNT	2
4.	71414717	NUT25-20 CHANNEL	4
5.	72060004	CAP SCR .25-20X 1.00 HH GR5 Z	4
6.	72060046	CAP SCR .38-16X 1.00 HH GR5 Z	8
7.	72063003	WASHER .38 FLAT	8
8.	72063049	WASHER .25 LOCK	4
9.	72063051	WASHER .38 LOCK	8
10.	77734564	CAMERA OPTION-DUAL	1
REV. INITIAL F	RELEASE		

## TH15K160 - Turntable Bearing Thread Tightening Sequence



#### NOTES:

Refer to the Turntable Bearing Thread Tightening diagram for proper tightening-torquing sequence of the turntable bearing to the crane base and crane mast. The total quantity of cap screws varies on crane model.

#### **TIGHTENING PROCEDURE**

- Refer to the torque data chart to determine the proper torque value to apply to the size of cap screw used
- 2. Follow the tightening sequence shown in the diagram. Note the crisscross pattern as shown in the diagram.
- 3. Torque all cap screws to approximately 40% of the specified torque value, by following the sequence.
  - (Example: .40 X 265 ft-lb = 106 ft-lb)
  - (Example-metric: .40 X 36 kg-m = 14.4 Kg-m)
- 4. Repeat step 3, but torquing all cap screws to 75% of the specified torque value. Continue to follow the tightening sequence.
  - (Example: .75 X 265 ft-lb = 199 ft-lb)
  - (Example-metric:  $.75 \times 36 \text{ kg-m} = 27 \text{ kg-m}$ )
- 5. Using the proper sequence, torque all cap screws to the listed torque value as determined from the torque data chart.

## TH15K160 - Thread Torque Chart (English)

FINE THREA	D BOLTS (EI	NGLISH)			
SIZE	BOLT DIA.	GRADE 5  SAE J429 GRADE 5	<b>&gt;</b>	GRADE  SAE J429 GRADE 8	
(DIA-TPI)	(INCHES)	PLAIN	PLATED	PLAIN	PLATED
		(FT-LB)	(FT-LB)	(FT-LB)	(FT-LB)
5/16-24	0.3125	19	14	27	20
3/8-24	0.375	35	26	49	35
7/16-20	0.4375	55	41	78	58
1/2-20	0.5	90	64	120	90
9/16-18	0.5625	120	90	170	130
5/8-18	0.625	170	130	240	180
3/4-16	0.75	300	225	420	315
7/8-11	0.875	445	325	670	500
1-12	1	645	485	995	745
1 1/8-12	1.125	890	670	1445	1085
1 1/4-12	1.25	1240	930	2010	1510
1 3/8-12	1.375	1675	1255	2710	2035
1 1/2-12	1.5	2195	1645	3560	2670

COARSE TH	READ BOLT	S (ENGLIS	H)		
SIZE	BOLT DIA.	GRADE  SAE J429 GRADE 5		GRADE  SAE J429 GRADE 8	
(DIA-TPI)	(INCHES)	PLAIN	PLATED	PLAIN	PLATED
		(FT-LB)	(FT-LB)	(FT-LB)	(FT-LB)
5/16-18	0.3125	17	13	25	18
3/8-16	0.375	31	23	44	33
7/16-14	0.4375	49	37	70	52
1/2-13	0.5	75	57	105	80
9/16-12	0.5625	110	82	155	115
5/8-11	0.625	150	115	220	160
3/4-10	0.75	265	200	375	280
7/8-9	0.875	395	295	605	455
1-8	1	590	445	910	680
1 1/8-7	1.125	795	595	1290	965
1 1/4-7	1.25	1120	840	1815	1360
1 3/8-6	1.375	1470	1100	2380	1780
1 1/2-6	1.5	1950	1460	3160	2370

#### NOTES:

- 1. Tightening torques provided are midrange.
- 2. Consult bolt manufacturer's particular specifications, when provided.
- 3. Use flat washers of equal strength.
- 4. All torque measurements are given in foot-pounds.
- 5. Torque values specified are for bolts with residual oils or no special lubricants applied. If special lubricants of high stress ability, such as never-seez compound graphite and oil, molybdenum disulfide, colloidal copper or white lead are applied, multiply the torque values in the charts by the factor .90. The use of loctite does not affect the torque values listed above.

### **A** WARNING

Anytime a gear-bearing bolt is removed, it must be replaced with a new bolt of the identical grade and size. Once a bolt has been torqued to 75% of its proof load and then removed, the torque coefficient may no longer be the same as when the bolt was new thus giving indeterminate clamp loads after torqueing. Failure to replace gear-bearing bolts may result in bolt failure due to metal fatigue causing death or serious injury.

## **TH15K160 - Thread Torque Chart (Metric)**

FINE THRE	AD TORQUE	CHART (N	METRIC)		
TIGHTEN	IING TORQ	UE			
SIZE (DIA- TPI)	BOLT DIA. (INCHES)	SAE J429 GRADE 5	$\rangle$	SAE GRAI	
		PLAIN (KG-M)	PLATED (KG-M)	PLAIN (KG- M)	PLATED (KG-M)
5/16-24	0.3125	3	2	4	3
3/8-24	0.375	5	4	7	5
7/16-20	0.4375	8	6	11	8
1/2-20	0.5	12	9	17	12
9/16-18	0.5625	17	12	24	18
5/8-18	0.625	24	18	33	25
3/4-16	0.75	41	31	58	44
7/8-11	0.875	62	45	93	69
1-12	1	89	67	138	103
1 1/8-12	1.125	123	93	200	150
1 1/4-12	1.25	171	129	278	209
1 3/8-12	1.375	232	174	375	281
1 1/2-12	1.5	304	228	492	369

COARSE 1	THREAD TORG	UE CHAR	T (METRIC)		
TIGHTEN	NING TORQU	JE			
SIZE (DIA- TPI)	BOLT DIA (INCHES)	SAE J429 GRADE 5		SAE JA GRADI	
		PLAIN (KG-M)	PLATED (KG-M)	PLAIN (KG-M)	PLATED (KG-M)
5/16-18	0.3125	2	2	3	2
3/8-16	0.375	4	3	6	5
7/16-14	0.4375	7	5	10	7
1/2-13	0.5	10	8	15	11
9/16-12	0.5625	15	11	21	16
5/8-11	0.625	21	16	30	22
3/4-10	0.75	37	28	52	39
7/8-9	0.875	55	41	84	63
1-8	1	82	62	126	94
1 1/8-7	1.125	110	82	178	133
1 1/4-7	1.25	155	116	251	188
1 3/8-6	1.375	203	152	329	246
1 1/2-6	1.5	270	210	438	328

#### NOTES:

- 1. Tightening torques provided are mid-range.
- 2. Consult bolt manufacturer's particular specifications, when provided.
- 3. Use flat washers of equal strength.
- 4. All torque measurements are given in kilogram-meters.
- 5. Torque values specified are for bolts with residual oils or no special lubricants applied. If special lubricants of high stress ability, such as never-seez compound graphite and oil, molybdenum disulfide, colloidal copper or white lead are applied, multiply the torque values in the charts by the factor .90. The use of loctite does not affect the torque values listed above.

### **A** WARNING

Anytime a gear-bearing bolt is removed, it must be replaced with a new bolt of the identical grade and size. Once a bolt has been torqued to 75% of its proof load and then removed, the torque coefficient may no longer be the same as when the bolt was new thus giving indeterminate clamp loads after torqueing. Failure to replace gear-bearing bolts may result in bolt failure due to metal fatigue causing death or serious injury.

## TH15K160 - Radio Remote

For Radio Remote operation instructions, features, specifications, and programming, see the TireHandler<sup>™</sup> Radio Remote System manual P/N 99905678.



Transmitter P/N 70734590



Receiver P/N 70734591

## **Revisions**

1724924	CN241-1 REV. F
	CIN241-1 REV. F
5724919	CN793
1727622 1727651 3540632 0727614 0727628 0727629	CN883
0727416	CN1058
1. 3: 0. 0.	727622 727651 540632 727614 727628 727629



### IOWA MOLD TOOLING CO., INC.

P.O. Box 189 Garner, IA 50438 Tel: 641.923.3711 Fax: 641.923.2424

www.imt.com

IMT reserves the right to make changes in engineering, design, specifications, add improvements or discontinue manufacturing at any time without notice or obligation.