



# IMT Series III Telescopic Cranes Quick Reference Guide

**Association - Radio Remotes**  
**70734956, 70734957, 70734958 & 70735093**

## Association

**Note:** You must have a direct line-of-sight between the transmitter and receiver.

1. Power OFF transmitter and receiver (PTO and / or ignition switch OFF).
2. Release the STOP button on the handheld by twisting it clockwise.



3. Locate both association arrows (A) on face plate.
4. Push and hold both switches in the direction indicated by the arrows. All LEDs will turn on (TX, RX, BATT, WARNING).
5. Once all LEDs turn off, except TX, turn ON the power to the receiver (PTO and / or ignition switch).
6. Release switches on the transmitter.
7. Both TX and RX LEDs on the transmitter should be blinking rapidly.
8. If not, repeat Steps 1-6.




This chart is to be used as a "quick reference" guide only.  
It should never be substituted for a thorough review of the manual.



# IMT TELESCOPIC CRANES QUICK REFERENCE GUIDE

70734957 & 70734958 Fully Proportional Radio Remote

## Setting Parameters




This chart is to be used as a “quick reference” guide only.  
It should never be substituted for a thorough review of the manual.



# IMT TELESCOPIC CRANES QUICK REFERENCE GUIDE

70734956 Single Proportional Emulator Radio Remote




This chart is to be used as a “quick reference” guide only.  
It should never be substituted for a thorough review of the manual.

71490252

# IMT TELESCOPIC CRANES QUICK REFERENCE GUIDE

70735093 Single Proportional Radio Remote



This chart is to be used as a “quick reference” guide only.  
It should never be substituted for a thorough review of the manual.

71490252